




ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Barks

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

dleRAND'SI APOUD

SrCToku	AackrtiutCp
/:01-5/:::	7uffer solution
/:01-:/:::	7uffer solution
/:01-0/:::	7uffer solution
:::-015::5::	TUNS PTTT6 8G3NUT4E ASGM4UNFL 2NU LMSCGE / pcs O:5
84F27T: /	2inal 2ilter for Rure Water Rroduction Lystem lilli HxPU6
894T:/CRE	RolypropyleneK R942 2ilter
GAWD:1VLB	I2Hlebranen
GAWR:1V::	I2 membranes
I8:::/z5	Lamplur for 8oliform 8ounting
IGR8:/z5	Cotal 8ount immersion tester
L3DS:-SL	lilleXHDS --mm Sylon .z:um SonHsterile 5:Kpk
IRDR:z:/	8onsumables for ultrapure water production equipment
GAWR:1V:: P/X/:::pcs6	lembrane 2ilter
LIWR:1V:: K /:1:/V	
RU:DC38L/	Rretreatment Rack
xDAU4::U/ K //:::z/	xHDAU4 /
xCFIIR(E) K //:::z0	NUDASE) xFASCFI WTCG IT33TRA(
L32G:5:/	lilleXH2G 2iltereinheiten
LRU::LTA/	Fitrapure water production equipment consumables
LRU::LTAz	LmartRak purification pack
LMS:/5F9/	8onsumables for ultrapure water production equipment
CAS(IR(:-	8onsumables for ultrapure water production equipment
/:0050:::/	Lodium hydroXide solution
WRB/zz:5:	8hemical vaccumKRressure Rump
j2-:::1--	power supply board
j3)F93R:/ K //:::151	
j3)F93R3/	F9 lamp
jlxF93R:/ K //:::-5	F9 lamp
/:1:/:::/	Rotassium chloride solution saturated with silver chloride - mol
-:/::/z:z5.	SA/zKz5, 4iaphragm RC2E
G2LAIR3E:z	Gi 2low Rlus
G2LAIR3E:1	Gi 2low Rlus
8DER:zC2-	
8DER:/C2-	
G9GR/1z5: R942	4urapore lembranfilter
G9RGz0-z5 4FUARNUE .15F RG:7 z0-II z5R(	

Product	Description
BT6-T5-43BG-P9C	Industrial Pressure Transducer
BPS34GEM0002BAPQ1	Electronic Dual Pressure Switch
B1T-H32SS-FX	Bourdon Tube Pressure Switch
D1H-A80SS-FX	Housed Diaphragm Pressure Switch with NEMA 4X Enclosure
A9692X-2CC-3	Explosion-Proof Compact Pressure Switch
208128 / 906-0045	Screw
208129-C / 906-0040	Pressure Transducer
4518014742 / UNS-PP16/18	float switch
BT5-Q50-16BG-P9C	Industrial Pressure Transducer
0406u106 / 9681X-1CC-2	pressure switch
BT5-T4-16BG-C	Industrial Pressure Transducer
0801U152 / 6182S3HC3-MC	Valve
B2T-M12SS/ 0405-300	pressure switch
425T4-22	Temperature Switch
T96201-BB3-T2-Z17	Pressure Switch
ART.NR.: 0417-294 / TYPE: 8161-PL1-V-LH-GE42	Pressure Switch
UNS1000-S-VA/T1-KLS1 BN18HV-L1/3-CBM Lo82	level temp sensor
0122-260 / UNS1000-VA/T1-KL6-VA27-L1/1(2)-HT Lo82-1000	Level Gauge
908-0361	Connector
0113=1290	Level Switch
P/N: 0403-113, Type: E1H-H500-P6-F2	pressure switch
0801u126 / 6142R3HC3	Valve
P/N: 0111-708, Type: PP18-DM-GE301	PVC-Cable
0713-354.2/ BFS-30-O-G1-MS-WE-ST	Flow Switch
P1X-B30-S0426	Pressure Switch
0711-257.7	Flow meter
P/N: 0401-459, Type: D2X-M150SS-EX	pressure switch
0401U934 / D2T-H18SS-CS-U	Pressure switch
P/N: BPS32NVM0150P, Type: 150p/420-1/1/4NE/F	ELECTRONIC DUAL PRESSURE SWITCH
0111-591 / UNS-VA1/4NPT-K5- VA52/1(2) 5m PVC-Cable	Stainless Steel Level Switch with 5m PVC Cable
0111-594 / UNS-VA1/4NPT-K5-VA52/3 5m PVC-Cable	Stainless Steel Level Switch with SPDT Contact and 5m PVC Cable
0111-715 / UNS-VA1/4NPT-K5-VA52/3- HT 5m Si-cable	High-Temperature Stainless Steel Level Switch with SPDT Contact and 5m Silicone Cable
0403U095 / E1H-H15	UL Pressure Switch
B2T-M12SS D	pressure switch
0405U270 / B2T-M32SS-CS	Pressure Switch
0402U123 / DPD2T-A150SS	pressure switch
D2T-M80SS-EXI / 0401-418	Pressure switch
P/N: 0416-116, Type: KLM-025-M4-ST0-1	pressure switch
P/N: 0401-373, Type: D2T-H18SS	pressure switch
0416-119, KLM-025-M4-ST0-1-V 0501 328 133	Compact Pressure Switch
B1X-M12SSEX / 0405-184	pressure switch

Product	Description
P/N: 0406-038, Type: 96201-BB3-T2	pressure switch
9681X-1CC-2-S0271	Pressure switch
0122-153 / UNS1000-VA/T1-KX4-VA27- L2/1(2)-Exi Lo147-500	Level sensor
0801-120 / 6141R3HC3	Directional hydraulic valve
0225-108 / USE3200-VA/FLS-KLS-VX80 R12-900-DR- MUEx Lo1350	level sensor
P/N: 0111-717, Type: UNS-PP16-PP18-G3/4-GE301	10m PVC-Cable
P/N: 0431-620, Type: UPA2-DMP343-100-1000-1-3 - 100-100-000	sensors
L96211-BB2SS-S0639	Pressure Switch
0406u103 / 9692X-1CC-4	Ex-proof pressure switch
P/N: 0603-093, Type: T1X-H351S-A-EX	temperature switch
UPA2-LMK382-H-566-XXXX-K-2-H-1-4-B-003-000	pressure switch
P/N: 0405-223, Type: B2S-M48SS	pressure switch
0113=1432	Multi-Level Switch
0431-0620	level sensors
PSA30.BPS3.4.G.V.M.0100B.P	Electronic pressure switch and transmitter
BTS312VM0050M1	Temperature sensor
9692X-1CC-3 / 0406U103	Pressostat
BLP2/P/XmWs/PVXm/F	level probe
0332-604	Level Switch
0402-102 / DPD2T-M80SS	pressure switch
P/N: 0403-074, Type: E1H-H15-P6-T	pressure switch
0111-710 / UNS-PP16-PP18-G3/4-GE301	Sensor
0712-263.10 / BFS-20-O-G1-MS-NO-ST	Sensor
0417-136 / 8151-PL1-B-LH	pressure switch
P/N: 0303-027, Type: GK03-EXI with 3 m Si-Kabel	Limit switch
P/N: 0801-088, Type: 6145R3HO3	valve
BPS344VM0400B	Electronic Dual Pressure Switch
RK1457	Repair Kit for Shear-Seal® Valve
0405-028 / B1S-M12SS	pressure switch
E1H-H90-Z27	Pressure switch
0122-144 / UNS1000-MS/T1-STDB-BN25- L2/1(2) Lo107...500 Gr.3	Multi-Level Float Switch
0221-374 / XT-R12 5250 >= Lm > 5000	Transmitter for Bypass Level Indicators
0419-037 / 9A21-PL1-V	pressure switch
BPS34GVM00.5BP (500mbr/420-2/G1/4E/E)	Pressure switch
BPS34GVM0001BVP	electronic pressure switch
P/N: 0403U401, Type: E1H-G90-RD-LC	Pressure switch-UL
BT5-T5-36BG-P16P	Temperature Switch
E1H-R-VAC-P6/ 0403-179	Econ-O-Trol Mechanical Pressure Switch
E1H-H500-P8/ 0403-118	pressure switch
BNA-S22-3/4"150-RF-VA30/ /02-MA-GE409 LM=1,0<1,5m (0332=1037)	Mini Bypass Level Indicator
UTA2/0+120C/420/G1/4E/F/ (0631-063)	Temperature Transmitter

Product	Description
455ET4-01-P4-Z050	Intelligent Pressure Transmitter
0801U057 / A147R3WC2	Valve
BPS312FM0040BPQ6	pressure switches
BPS342FM0040BPQ6	pressure switch
UPA2-DMP333	Electronic Pressure Transducer
506925	Fresh water level sensor
0711-339.7	Flow Switch
6143R3HC3/ 0801-130	High Pressure OEM Valve
82C1-PL1-B-UL	pressure switch
XT-R12-LM600	LEVEL TRANSMITTER
T96201-BB3SS-T5-W36	Compact Pressure Switch
0602-121 / T2H-H251S-A	temperature switch
0417-385/ 8141-PL1-B-LH-ES	pressure switch
9681X-1CC-2-W79	PRESSURE SWITCH
CERTIFICATE OF COMPLIANCE-B	Certificate of Compliance
P/N: 0303-038 Type: GK03L 2m	Limit Switch for Bypass Level Indicator
0111-704 / UNS-PP16-PP18-G3/4-GE298 5m PVC-Kabel	Level Switch
0417-710	Pressure switch
9681X-1CC-3-B-K	PRESS SWITCH, EXPLOSION PROOF
BFS-30-N-G1-MS-WE-ST / 0713-349.6	
BFS-30-N-G1-MS-WE-ST / 0713-349.10	
P/N: 0231-016	
P/N: 0499-027	
0111-631	BILGE LEVEL SWITCH
0112=1086 / UNS1000-MS/T1/2-M12x1	
0402-169 / DPD2T-GH150SS-ST3	pressure switch
96201-BB2-T2-P1Z17	Pressure Switch
0417-021 / 8251-PL1-B	pressure switch
906-0919	
906-0946	
906-0947	
BPS34GEM0600BP	Pressure Sensor
230VAC SN H190043801 CXVE-217-0812-15L	TERMINAL BOX
926-0811	Junction Box
0406U123 / 96201-BB2-T2	pressure switch
0406U172 / 96201-BB2-T2-P1	Pressure switch
0417-775	
UNS2000 SN H190043801 CXVE-217-0812-15L	FLOAT SWITCH
0332-592/ BNA-S22-DN15/PN16-VA30/02-MA	
PN: E1H-H90	Dia-Seal Piston Pressure Switch
0111-759 / UNS-VA/SB5-PE33/2 NC	
ML1S-100-I-Q	temperature switch
0406-114 / TC9622-2	
0406-113 / TC9622-2	

Product	Description
5625R6WQ3	Valve
KD2447	MAJOR REPAIR KIT
0111-468 / UNS-MS1/8-K3-BN25/3 3m PVC-K. WE	Float Switch
0112-829	liquid level probe
pn 0113-776 / UNS2000-ABS/VA/FLS-PG-K316318.1/001	sensor
0332-628 / BNA-S22-R1/2"Male- TT30/02P- MA LM<1.0m	
0112-557	
0401-462 / D2X- M150SS-UL	Pressure Switch
UNS2000-VA/T3/4-ST1-VA52 T-HT-GE392-L1/1 Lo135	
0303-056 / GK03-UL	
0713-351.1 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.2 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.3 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0713-351.4 / BFS-30-L-G1/2-SS-WE-ST	Flow Switch
0111-652 / UNS-VA/SB5-PE33	
PN: 0711-257.5 / Type: BFS-10-N-G1/2-MS-NO-ST	flow switch
D2X-M80SS-UL	Explosion Proof Diaphragm Pressure Switches
0232-014 BLP2/C/xbar/PUxM/E	
0499-026	
8251-PL1-B-D-LH-PC-GE380 typ 0417-716	
BT5-T4-41BG-P9P	Transducer
BPS35EVM3000P	
0710-023.4 / BFS-10-N-AIR-G1/2-SS-WE- ST 10...35 NL/min	
0403U407 / E1S-H90-PLS	pressure switch
UNS2000-special 230V AC/ 0113=1433	junction box
0801U474 / 921P3WQ3	Shear-S. Valve Pnl mount
6181S3HC3-MC	VALVE
8142R1HO3-O/SN:082317	Control Valve
0405-344 / B2X-H12SS-UL	PRESSURE SWITCH
0801-128 6142R3HO3	
E1H-H90-P6-PLS	
B1T-M12SS	Pressure switch
0403-081 / E1H-H250-P4-EXI	Pressure switch
0225-025	
0603-081 / T1X-H251S-A-EX	temperature switch
0711-257.8	
L96211-BB4-S0074	Pressure Switch
0416-176	
B2T-H32SS	pressure switch
BFS-10-N-G1/4-MS-NO-ST / 0711-256.6	flow switch
E1H-R15-BR-V	

Product	Description
0711-261.1 BFS-10-N-G1-SS-NO-ST	
423T4-13	Barksdale Control Products Transducers, 420 Series
0401-404 / D2T-M18SS-EXI	pressure switch
0417-582 8151-PL1-B-D	pressure switch
0122-178	
0601-331 / MT1H-M251S-12-A	temperature switch
28-010099/0111-739	
0111-577/ UNS-VA1/8NPT-K1- VA27/1(2) 1m PVC-Cable	level switch
BPS31EVM3000P	3000p/2SP/7/16E/F
A923R3WQ2-B / TBD	
6922M3HC3	
PN: 0401-116, type: D1T-GM3SS-EXI	Pressure switch
425H3-04-U	Transducer
625H3-16-Z23	PRESSURE TRANSMITTER
B1T-A32SS	HIGH AND LOW PRESSURE SWITCH
0423-126	pressure switch
BT5-H3-04BG-P	
8141-PL1-B/0417-014	
BPS38GVM0020B	20b/420-2 IOL/G1/4E/F El. pressure switch