




ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Hirose Valve

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
GNT-03	Needle Valve Screwed
HF-4211-10-23	Directional Control Valve
HG-4211-32-23	2 STOP VALVE
HG-4211-50-23	
HIC-FJ-25-A04-12	Hirose brand Inline Check Valve
Q-B15B16010 (HK-4251-32-S STOP VALVE CARTRIDGE FOR HYDRAULICS)	Stop valve cartridge for hydraulics
HRV-M01-W-25-21	Relief Valve
HSO-G02-A10C-LZ	HIROSE VALVE
HSO-M03-W-D02C	valve
HT-0210-10	
HT-720-01-S	Grease valve QB14XEI010
HT-728N-04	valve
HG-4211-10-23	Stop Valve
HG-6211-20-50-25	Hirose valve
HG-4211-D-10-23	Hirose valve
HF-4211-50H-23	2" MK stop valve
QR/P1-16S-C(51)	Connector
QR/P1-16P-C(51)	Connector
HF-6211-20-25	CHECK STOP VALVE
HF-6211-32-25	CHECK STOP VALVE
HF-6211-40-25	CHECK STOP VALVE
HF-4211-20-23	STOP VALVE
HF-4211-25-23	STOP VALVE
BV-T03-21	VALVE BALL
HF-8210-15-24-166	Stop Valve
HF-1280-32-11 OEM	
FDC-T08-70-61	Flow Divider/combiner valves
HSO-M03-W-D02C-21	SOLENOIDE VALVE
HR10-7P-6P	socket
HF-4211-50-23	Stop Valve
HG-4211-20-23	Stop valve
HRV-M01-A-25-21	
HFZ-4211-80-23	STOP VALVE
DF13-30DS-1.25C	
HF-8210-20-H	NEEDLE VALVE 3/4"

Product	Description
HF-9210-10-H	THROTTLE AND CHECK VALVE 3/8"
HT-1211-20-23	STOP VALVE
FDC-T03-10-72	Split and split flow valves
3763M3VVC3-233-1	
HIC-FJ65-A-04-12	
HGZ-4211-32-23	seal kit
W-HG-4211-10J-23	VALVE
JMV-10-SC	
JMV-06-SC	
HRM(V)-306S	Connector Jack
HSO-G02-D02C-LZ-31	
HT-728-02	
W-HF4211-20-23	STOP VALVE
W-HG4211-50-23	STOP VALVE
W-HF4211-65-23	STOP VALVE
W-HG-4350-10-23	STOP VALVE
HF-4211-32-23	
HF-4211-40-23	
HAPT-03-11	check valve
HG-4211-10J-23	Globe valve
HG-4211-08-34	
HF-4211-80-22	
HRV-M06-W-25-21	Hydraulic Valve RELIEF VALVE,250kg/cm2
HRV-M03-A-25-21	DIRECT RELIEF VALVE
HRV-M06-A-25-21	Direct operated relief valve (HRV)
HRV-M03-B-25-21	Direct operated relief valve
HRV-M06-B-25-21	DIRECT RELIEF VALVE
HTICZ-R-03-04-21-SS	Stainless steel valve (for hydraulic / water pressure)
GV-G22-N	Stop valve
HT-0210-15	Stop valve
HT-4211-10-23	Stop valve
HT-4211-20-23	Stop valve
HT-4211-32-24	Stop valve
W-HT-4211-20-23	Stop valve
GNT-02	Throttle valve
GNT-02-L	Throttle valve
GNT-03-L	Needle valve
GNT-04	Needle Valve Screwed
HT-720-01	Check valve
HT-930-10-P	Throttle valve
HTIC-03-04-10	CHECK VALVE
HTIC-03-35-10	Check/Pilot Check Valve
HTIC-04-04-10	Check / pilot check valve
HTIC-06-04-10	Check / pilot check valve

Product	Description
HTICZ-G-10-04-21	Check / pilot check valve
OFSV-T03-50-11	Excess flow shutoff valve
HSO-T03-D02C-LZ	Electromagnetic operated stop valve
HSO-T03-D02F	Electromagnetic operated stop valve
BV-T02-21	Ball Valve
FDC-T03-15-72	Split and split flow valves
FDC-T03-6-72	Split and split flow valves
FDC-T06-50-61	Split and split flow valves
F-HT-4211-10-23	Stop valve
FVP-720-T02-12	.
FVP-720-T04-12	Throttle valve
HFC-4211-65	Check / pilot check valve
HGC-4211-50-23	Check / pilot check valve
RMV-06-SCC-E	Maintenance valve for relief valve
HIC-FJ80-A-04-12	Compact flange check valve
HIC-FJ15-B- 04-12	Compact flange check valve
HIC-FJ20B-04-12	Check valve
HSO-G02-D02C-LZ	Electromagnetic operation stop valve
FMTC-06-W-X-21	
JMVZ-G-04-SC	
KMOVZ-04-AB-OS-Y2	
KMOVZ-04-AB-SS-Y2	
HGZ-4211-10-23	
HGZ-4211-10J-23-166	
HGZ-4211-10-23-166	
HGZ-4211-20-23	
HGZ-4211-20-23-166	
HGZ-4211-32-23-166	
W-HG-4211-20-23	stop valve
HGZ-6211-20-25-166	valve
HGZ-6211-32-24-166	valve
HF-4211-25-24-166-7M	valve
HFZ-ACC-20x10-M42-23	valve
HFZ-ACC-32x10-M60-R-23	valve
HGZ-ACC-32x10-23	valve
RG 174	174 TYPE RG
HF-8210-32-24-166	valve
HSO-M03-A-A22C	
HF-4211-K-32-24	Stop valve
HT-728-04-S	Throttle valve
HFZ-ACC-32x10-23-2	Accumulator Stop valve
HG-6211-32-24	CHECK STOP VALVE
JMV-01-SCC-E	MAINTENANCE VALVE
JMV-01-SC-E	PT port control maintenance valve
JMV-01-SS-E	MAINTENANCE VALVE

Product	Description
JMV-03-SCC-E	MAINTENANCE VALVE
JMV-03-SC-E	MAINTENANCE VALVE
JMV-03-SCS-E	MAINTENANCE VALVE
JMV-03-SS-E	MAINTENANCE VALVE
JMV-06-SC-E	MAINTENANCE VALVE
JMV-06-SS-E	MAINTENANCE VALVE
PT # HFZ-ACC-32 x 10 -23-2	Accumulator stop valve
LF10WBR-4P	
HR10A-10P-12P(73)	Connector
HR10A-10R-10P(male)	
HR10A-7R-4SC(female)	
HR10A-10R-10S(female)	
HG-4211-8-34	length stop valve
FMPCD-06-B-20-22	
HSO-G02-A10F	Solenoid valve
HF-4211-50-23-166	
HSO-M03-A-A22C	SOLENOID OPERATED DIRECTIONAL valve
JMV-10-SCC	hydraulic sandwich check valves
HT-728-03	Valve
HSO-G02-A11F	SOLENOID OPERATED STOP VALVE
HSO-G02-D02F	Normal Open Stop Valve
HTIC-08-04-10.	CONTROL VALVE
HTIC-10-04-10.	CONTROL VALVE
W-HF-4211-25-24	Valves SBV
HF-8210-15-24	
HF-8210-25-24	
HF-8210-10-24	
HG-4350-10-23	stop valve
HBV-F04SS-14	Hydraulic Valve BALL VALVE
HIPT 03-04-22	VALVE
W-HG-4211-32-24	
JMV-R-06-SC-E	
JMV-R-10-SC-E	
HF-9210-20-23	HYDRAULIC VALVE
HG-6211-20-25-Y	
HGD-4211-10J-23	
HGD-4211-20-23	
HGD-4211-32-23	
HGD-4211-50-23	
HF-4211-80-23	lock valve
HF-8210-10-23	Valve
HK-4251-32-S	
HRV-M01-B25-21	Relief Valve
HPCZ-102-10G-40-D-30	Check valve
HF-4211-15-23	Directional Control Valve

Product	Description
F-HRV-G03-25-11	
HGF-4211-20-23-25 FL-ASI	Valve
HSO-M02-W-D02C-LZ	
HSOH-G06-D02C-LZ-21	
HG-735-02-33	
HG-6211-10-25-Y-166	valve
HSO-M02-W-D02C	Valve
HR22-SC-122	Small High Performance Circular Connector
HF-8210-20-24	Hirose Valve
HS0-G02-A10F	VALVE
FDC-T04-40-72	flow divider/combiner
HSO-G03-D02C-LZ	valve
HT-728-03-S	valve
HSO-M03-A-D02C-21-432	
HT-720N-02	1 / 4" VALVE
HS0-G02A10C	
JMV-03-AB-SS-E	Isolation valve
JMV-G-03-SC	Iso 5 isolation block
HSO-T03-D02C-31	STOP VALVE
Lever for HBV-T03-0833	
OFSV-F06-180-11	Overflow cut-off valve
DF14-30S-1.25C	
DF14-2628SCFA	
OFSV-F06-180-12	Adjustable overflow shutoff valve
HT-4211-8-23	Stop valve
GNG-02	
DF62B-3EP-2.2C	CONN PLUG HOUSING 3 POS BLK
DF62-2428SCF	CONN CRIMP SKT 22-28 AWG
DF11-4DS-2C	4 PIN CRAMP PLUG CONNECTOR
DF11-2428SCF	24-28AWG CONNECTOR PIN
DF11-4DP-2DS (24)	4 PIN CONNECTOR
HR10A-10P-10PC(73)	
HR10A-10P-10P(73)	
HT-720N-01	Throttle valve
RMV-03-SCC-E	
HF-1280-40-11	Stop valve (valve remote control line)
HR10A-13P-20P(73)	
HIIC-03-10-375	
Gasket sets for HF-4211-32-23	Gasket sets
Gasket sets for HF-4211-40-23	Gasket sets
JMVZ-03-SCC-166	hydraulic valve
HT-728-04	check valve
JMV-R-01-SC-E	valve
HF-4211-K-25-24	
HF-4211-25-24	STOP VALVE 1" MK

Product	Description
HF-4211-32-24	stop valve
HK-4251-20-S-10	CARTRIDGE SHUT-OFF VALVE
HGZ-4211-50-23	SHUT-OFF VALVE
JMV-10-SCC-166	Maintenance valve
HRV-G06-25-11	
GT17H-4S-HU	
GT17H-4S-R	
HSO-T03-D02C	Electromagnetic operated stop valve
FMCQ-06-A-07-21	
HDF-4211-K-65-23	
HBV-GF-12-32	
FDCS-G04-30-61	Valve
FDCS-G03-15-61	Valve
FDCS-G03-20-61	Valve
HG-8210-32-22	
11-9BP6P	round plug
HSO-G03-A22C-LZ-21-432	
HSO-M03-W-D024C-21	
HFP-T02-1.0-12	FIXED FLOW CONTROL VALVE FV HYDRAULIC
HVR-M10-A-25-21	
HSO-G02-A20C-31	
DF11-10DS-2C	Connector
HSO-G02-A22C-31	Valve
HF-4211-65-23	Stop valve
F-GNT-02-L	throttle valve
F-GNT-03	
HBV-G03-1032	
HSO-M03-W-DC24VC-21	Solenid valve
HSO-G02-A10C-31	
HT305/DF50-2830HC	
JMV-CR-06-SC	
JMV-06-SCC	
OFS-T03-20-12T	Valve
JMV-06-AB-SS	AB port control maintenance valve
JMV-10-AB-SS-E	AB port control maintenance valve
HT-728-06	
JRC-SC2-112	
HG-9210-10J-23	
HSO-SOL02-A20	