




ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Kinetrol

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
034-100-2104	
Model 054-100	Rotary actuator
05A-100	slewing drive
074-044EL0000M	EL Positioner
074-070EL0000	EL positionerelectro-pneumatic
074-100Z	Pneumatic actuator, double-acting without coupling
074-104U002000M	turn actuatordouble acting
004-000AP0400	positions
0M0-100	Quarter-turn actuator, double-acting
103-700EL1000	EL actuator
147-100L	
12A-100	
SP 042 FOR(SOL 15)	ACTUATOR SEAL REPAIR KIT
074-040EL0000	
KINETROL 120-100	
SP 053 (Modell 16)	
Q-CRD-500000	Continuous Rotation Dashpot
SP 253	Spare parts for model 120
05-520AP00F0C	actuator
054-400EL0000M	actuator
207-100	
073S030-1016	
124-104U005004M	ACTUATOR
054-520AP0000 + SP 978 Pos.	KINETROL-Stellantrieb
SP 978	Stellungsanzeigedom linksdrehend
030-100	Turn pneumatic Actuator range
Kinetrol 140	Seal Kit
Kinetrol 160	Seal Kit
09A-100	Schwenkantrieb
09B-100- alternativ	
140-100	Rotary actuator
164-100	Schwenkantrieb
09B-100	swivel drive
127-400EL0000M	actuator, 4-20mA double-acting
X03086	
SP 942	Servo valve kit

Product	Description
004-004XE0B034A	limit switch unit
024-120Z	Quarter turn actuator
Coupling for 074-100	Coupling
053-400EL0000	
143-100	swivel drive
053-700EL0000	EL actuator
Repair Kit For: 124-107U002000M	Repair Kit
054-120	Single-acting slewing drive
094-120	quarter turn actuator
094-900AP6710	actuator
164-104U002000	Turn actuator with limit switch
057-500AP0000C	
LA3-DD	
103-602MP0000	
093-100	slewing drive
Modell 124-100	Felt
124-107U002000M	
SP 046	Kinetrol Wear Set for Model 12
SP 946	
05B-124U002000	KINETROL-Schwenkantrieb
07B-124U002000	KINETROL-Schwenkantrieb
143-400EL0000	
12B-100	
054-040EL0000	Electropneumatic positioner
Type: 024-100	Pneumatische Stellantriebe, Standard
074-104U002000	
05B-100L	
09B-100L	
103-400EL10C0M	Drive
124-400EL10C0M	Drive
094-400EL2000	EL-Stellantrieb
143-401EL1000	
SP 054 (für Modell 03)	
033-100	Rotational drive
SP 053	
SP 975	
097-120	
077-040EL1000M	Positioner
SP1609	Positioner mounting flange
054-400AP0100	
90AK032FP22DC05310001-000000	
103-400EL1000	
09A-106U002050	
084-500AP00G0C	Model 08 Double Acting Actuator
95K1241S00-2164	

Product	Description
SP 151	
054-600AP0000	AP Positioner
054-030	Spring lock unit
054-100	quarter-turn drive
054-10NU002000	Rotary actuator
Seal kit for valve Model 07	
Seal kit for valve Model 05	
Seal kit for valve Model 09	
144-520-49MP1000	Actuator
127-104U005004M	
054-104U002000	Semi-rotary drive
SP 056	Wearing parts set
10A-P100-5790	KINETROL quarter turn actuator
054-100Z	KINETROL-turn actuator
053-100	DIN/ISO mount Model 5, female drive.
033F120	
073-400EL0000	EL actuator
054-420EL00C0	
SP 045	Repair kit
SP 047	Model 14 Seal Kit
014-900-9810	Slewing drive
074-104UV02000	Part-turn actuator
074-070EL1000M	KINETROL EL positioner
SP 262	
SP 371	
143-40NEL10C0 (Modell 143-406EL1000)	Pneumatic actuator with electric positioner
054-020	spring-action unit
SP 353	Spare parts for model
SP 783	Seal spring base plate for Model 05
SP 042	Wear parts set
05A-104U002000	Rotary actuator
184-100	ACTUATOR
95K10A14T0-2167	
10300	clutch
034-133U002000	
054-103U002000	swivel drive
127-100	ACTUATOR
077-500AP0000C	Double-Acting Actuator with AP Positioner
007-800XP	I/P
APWPKIT	WP Kit
123-100	KINETROL quarter turn actuator, double acting
SP1609 (for positioner actuator size 12/14/15)	MOUNTING ADAPTER
SP1280	Repair kit
123-400EL1000	Actuator

Product	Description
094-020 (Spring for 094-120)	spring return unit
127-004EL1000M	Positioner
P3094-17002D130	
S-CRD-500000	Rotary dampers
KD-A3-DD-P7/2	
054-500AP0000	AP actuator
054-500AP1000	AP Actuator
034-100	quarter turn actuator
050-100-2103	Swing actuator
074-050AP3000C	Kinetrol AP Pneumatic Positioner
054-400EL0000	pneumatic actuator - double acting
07B-10NUV02000	actuator
103-100	Pnumatic valve positioner
054-10NUV02000	swivel drive
KD-F65-FAC	rotary damper
057-020-0074	Spring connection unit with overtemperature release
127-700EL1000M	Kinetrol-EL actuator
SP 241	Spare parts for model 120
SP 267	Position Indicators
053F120	quarter-turn drive
124-704EL1000	
SP 034	
074-100	swivel drive
073F020-1006	Spring locking unit
053F020-1006	Spring connection unit
033F020-1006	Spring connection unit
084-P10-3900	Quarter Lap Drive
054-104UV02000	Actuator
SP 146	Position Indicators
074-040EL1000M	"EL" electropneumatic positioner
600-122	
600-122 - VLS	
SP 937	Gasket Set for EL Positioners
SP 043	Wear parts set
S-CRD-30000	kinetrol rotary damper
SP 271	
144-100	quarter-turn drive
07AF120	Quarter Lap Drive
07A-100	quarter turn actuator
077-400AP0300C	
074-040EL00C0M	EL Electropneumatic Positioner
054-074EL0000	Kinetrol-hand positioner
034-120	slewing drive,
024-100	slewing drive
077-P505EL5460	

Product	Description
SP1007	
054-900-5402	air cylinder
054-1001	
123-700EL1000	
077-040EL00C0M	EL Positioner
147-100	Swing actuator
120-004U0010000	Limit switch module, assembly 2xV3, DIN 41635
074-040EL0000M	electro-pneumatic positioner
034-020	
124-100	slewing drive
094-100	quarter turn actuator
SP 045	Set of wearing parts
SP 054	Kinetrol rebuild / repair kit for model 03
054-100-2100	
054-401AP4100C	
074-600AP4000C	
074-134UV02000	valve with pneumatic actuator
074-050MP5000	MP positioner
SP1364	retaining plate
124-734EL1000M	POSITIONER
054-700EL0000	Kinetrol EL actuator
107-100	Kinetrol "DA" Double-Acting Actuator
073-100	slewing drive
P3094-10000-100	CARD POSITIONER FOR ACTUATOR PENUMATIC
074-400EL0000	EL actuator
DSP 801	spare part
SP1602P	XLS square adapter
SP1608	mounting flange
SP 045 for Model 09	
103-700EL10C0M	Kinetrol EL actuator
103F720EL10C0M	actuator
05B-100	actuator
094-600AP0000	Double Actuator
084-100	Part-turn actuator
057-100	Foam Actuator
054-100-2104	Actuator
CV.KIN.094-900AP6717 / 094-900AP6717	
033F020-1006/F04	Spring closing unit
073-700EL0000	Kinetrol EL actuator
057-520AP00V0	AP actuator
024-100Z	quarter turn actuator
020-100Z	
034-121U002000A	Part-turn actuator
084-120	Part-turn actuator
103F120	Part-turn actuator

Product	Description
DSP 810	coupling
SP 900	ACTUATOR REPAIR KIT
SP 979	Monitor Kit CW
SP703	Indicator Assembly
103-100-2148	Part-turn actuator
094-124UV02000M	
P3124-17002D110	kinetrol three-position drive
SP 041	repair kit model 02
073-400EL2000	
P3094-14002-120	
054-600AP00V0C	
124-104UV02000	Actuator
X03088	Actuator
073-700EL1000	
077-700EL0000M	
SP 121	Vane complete with seals for model 050/054
034-100Z	slewing drive
07B-100	swivel drive
10A-100	Double-acting rotary drive
077-040EL0000M	positioner
074-074EL0000	EL positioner
103-704EL1000	Actuators
070-404EL00C0M	
074-044EL1000	Kinetrol EL positioner
090-100	KINETROL slewing drive
SP 639	NAMUR adapter
097-100	swivel drive
077-124UV02000	swivel drive
057-124UV02000	swivel drive
037-124UV02000	swivel drive
074-070EL1000	
077-100	Kinetrol rotary drive, double-acting
074-124UV02000	swivel drive
077-520AP0000	AP actuator
DSP811	
074-040EL5000	POSITIONER
SP1449	
ADH1109S	
074-044EL5000M	EL positioner
187-100	
124-104UV02000 (2xV3)	a pneumatic rotary actuator (which goes on the butterfly valve) with limit switch unit
020-900-4660	swivel drive
074-900AP6713	
0749009650	

Product	Description
033F180	PNEUMATIC ACTUATOR
077-004UV05004M	Kinetrol VLS limit switch box ANSI
123-400EL1000M	
074-020	
084-020	
0M0-900-7861	
OMO-100	
077-040EL5000	
163-100	swivel drive
P3074-07002D130 - without drive	
124-007V6131	
07B-MP020U100	PNEUMATIC ACTUATOR
124-107XE0B0050	
95K07310D0-9100	
MV-SP056	
054-900-7920Z	slewing drive
103F020	
057-124UV02000M	slewing drive
127-700EL0000M	
027-100	slewing drive
074-104UV02000M	
074-004UV02000M	
PC5075315	
SP 743	
074-130	
P00EL2755	
SP352	lock to pneumatic actuator
SP 355	
124 704EL1000M	
147-120	ACTUATOR
074-060AP7000	AP positioner
097-600AP0000C	AP servomotor
SP1735	solenoid valve adapter plate
SP1734	solenoid valve adapter plate
127-144DP301D00	
074-040EL2000M	positioner
093-600AP0000	
057-104UV02000M	
SP 055	
00899658339 127-100	Pneumatic actuator
074-040EL1000	
710288	
074-600AP2000C	
074-700EL0000M	
103-704EL1000M	servomotor

Product	Description
094-020	
103-700EL1000M	
CERTIHK	
074-400EL2000	
repair kit for Kinetrol 14	PNEUMATIC ACTUATOR REPAIR KIT
074-04EL2000	EL Electropneumatic Positioner
074-040EL2000	
016760	
SP1021	
057-400AP0300C	
X03085	Actuator
SP1291	GASKET KIT
074-104UV02004M	
10A-1040UV02000	
077-400EL2000M	
077-700EL2000M	
024-100BU	Kinetrol rotary drive, double-acting
14B-104UV02000	
077-420EL1000	Valve
03A-100	
074-040EL10C0M	Kinetrol "EL" Electropneumatic Positioner