



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Penny & Giles

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
I-JC2000-T-XY-PPPO-25-S1-S-P-S	
JC100-006	joystick
JC120-0005	Joystick
JC150-GENW-0002	JOYSTICK CONTROLLER
I-JC200 -B-S-1-K1-Y	Joystick, Type JC200
JC400-GENERIC-0154 (I-JC400-A-XY-QQ-MA-ZC-S-P)	joystick
JC600GENNH-0001	joystick
JC6000-GEN-0943 // I-JC6000-XY-PNN-M-S-NL-N-STN-MG02	Industrial Joystick
SLS190/0200/L/50/01/N	
SLS190/0100/L/50/01/N (DSLS190L-GEN-0004)	
SRH280DP/360/360/A4/5/S/50/P5	Sensor, Type SRH280DP
EICT/I Electronic Module Plastic Box IP66 EICT	Electronic Module Plastic Box IP66 EICT
CM Stromausgangsmodulkarte	Stromausgangsmodulkarte
VM Signalaufbereitungselektronik, VM-Karte	Signalaufbereitungselektronik, VM-Karte
STT280/60/P2	Sensor
SLT190/0075/B/06	Linearer Wegaufnehmer
JC400-GENERIC-0128	joystick
SLS190/0025/L/50/01/N	
D45726/0100/04K/L/66/01	Linear-Potentiometer
SRH280DP/360/360/A4/5/D/68/P5	Kontaktloser Winkelsensor, Type SRH280DP
SLS190/0100/L/66/10/N	Linear-Potentiometer, Type SLS190
SLS190/0175/L/66/10/N	Linear-Potentiometer, Type SLS190
JC400-GENERIC-0227	
SLS190 (SLS190/0100/L/50/01/N)	Linear-Potentiometer
JC150-Y-R-M-WT05-STN	
SLS190/0100/L/66/01/P	Linear-Potentiometer
SLS190/0200/L/66/01/N	
HLP190-FS-01-5K-125-NA	
JC400-B-X-D-D-MD*	
NRH280DP/120/120/A1/3/B/P5	Sensor, Type NRH280DP
D21020	
JC400-GENERIC-0056	Joystick
SLS190/75/3K/L/50/1	
D20493* RCP18/2S/1+1K	Feedback potentiometer P/N: R11

Product	Description
I-JC400-A-XY-NN-/-MA-ZC-S-P	Joystick, Type JC400
JC300-GEN-0036 (JC300-X-A-R-0-ZC-C-0)	Joystick, Type JC300
SLS190/100/L/50/01/N	
JC150GENW-0005	Joystick
Type JC100	
JC400-GENERIC-0181	
SLS190/0100/L/50/01/N	Linear potentiometer, type SLS190
JC150GENHK-0005	JOYSTICK
Coppus Jectair 6-HP	COPPUS Jectair HP and Hornet HP High-performance, highly efficient Venturi air movers
I-JC400-B-XY-QQ-/-MA-ZC-S-P	Joystick
DS3410/3	Position Sensor
JC6000-0071	Joystick
SLS190/0075/L/66/01/N	linear sensor
SLS190/25/1K/L/50/1/N	Position Sensor
JC3000-NY-131-SW5-M-A- D5H-STN-ZCS	Joystick, Type JC3000
JC3000-GEN-0124	Joystick, Type JC3000
SLS130/0050/L/50/01/N	Linear-Potentiometer
JC6000-GEN-0385	joystick
SLS190/0200/C/50/01/N	Linear-Potentiometer, Type SLS190
JC2000-T-XY-PPPO-40-E1-P-P-S	joystick
JC400-0056 (I-JC400-B-XY-NN-MA-ZCS-S-N-SPL)	Joystick
JC2000-GEN-0168	MULTI AXIS CONTACTLESS JOYSTICK
Type JC120	Joystick,
Type JC400 (I-JC400-B-XY-QQ-/-HA-ZC-R-N)	Joystick
Type JC400 (I-JC400-A-XY-RR-/-MA-ZC1-S-P)	
KX92711	
SLS190/0125/L/50/01/N	Linear potentiometers
SLS130-25-C-66-01-N	Linear Position Sensor
JC120-0002	SINGLE AXIS JOYSTICK
ICS100/IN/0500/H/01	
ICS100/IN/0500/H/10 (1-5 pcs)	
SLS095/0010/0.4K/P/50	Linear-Potentiometer
JC120-0006	
JC6000-NY-PN-M-NL-N-STN-MG01 (JC6000-GEN-0944)	Joystick
SLS190/0175/L/66/01/N	
SLS190/0125/L/66/01/N	Linear potentiometers
JC120-0004 1481214314	
D150473 RCP18/2S/2+2K/CT/LIN	potentiometer
SLS190/0050/C/66/01/N	
D20493 RCP18/2S/1+1K/LIN (111RC001802-P)	POTENTIOMETER
I-JC400-B-XY-NN-/-MA-ZC-S-N (JC400-GENERIC-0056)	Joystick, Type JC400

Product	Description
JC6000-XY-PNN-M-S-NL-STN-A60B	
I-PGF5000/C/1/X	
111RC001805-P	Potentiometer
Type: SLS190. Order code: SLS190/0175/L/50/01/N	Linear-Potentiometer
SLS190-25-L-01-N	linear rule
SLS190/0050/L/50/01/N (DSLS190L-GEN-0012)	
SLS190/0075/L/50/01/N	LINEAR DISPLACEMENT SENSOR
SLS190/125/L/50/1/N	Linear displacement sensor
SLS190/0150/L/50/01/N	LINEAR DISPLACEMENT SENSOR
SLS190 (SLS190/0200/L/50/01/N)	Linear-Potentiometer
SLS190/225/L/50/01/N	LINEAR DISPLACEMENT SENSOR
SLS190/0300/L/50/1/N	LINEAR DISPLACEMENT SENSOR
SLS190/0200/C/50/01/N (DSLS190C-GEN-0020)	
SLS190/0350/C/50/1/N	LINEAR DISPLACEMENT SENSOR
SLS190/0225/L/50/01/N Type SLS190	Linear-Potentiometer
SLS190/125/L/66/1/N	LINEAR DISPLACEMENT SENSOR
SLS190/0200/L/66/1/N	LINEAR DISPLACEMENT SENSOR
SLS190/0350/L/66/01/N	LINEAR DISPLACEMENT SENSOR
SLS190/0025/C/66/01/N	
SLS190/0125/C/66/1/N	
SLS190/0075/L/50/10/N	LINEAR DISPLACEMENT SENSOR
SLS190/50/C/50/10/N	LINEAR DISPLACEMENT SENSOR
SLS190/0025/L/66/10/N	
SLS190/0150/L/66/10/N	
SLS190/0200/L/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS190/300/L/66/10/N	
SLS190/0200/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS190/0250/L/50/01/P	LINEAR DISPLACEMENT SENSOR
SLS190/125/L/66/1/P	LINEAR DISPLACEMENT SENSOR
SLS190/0075/L/50/10/P	LINEAR DISPLACEMENT SENSOR
SLS190/0100/L/66/10/P	Linear displacement sensor
SLS190/0200/L/66/10/P	Linear-Potentiometer, Type SLS190
188968	Crossfaders
JC025-R-STD-BLK	SINGLE AXIS ROCKER
JC025-Q-V00-BLK	SINGLE AXIS ROCKER
I-JC030-E-VOO-BLK / JC030-Generic-0004	direction selector
I-JC030-R-V00-BLK (JC030-GENERIC-0001)	
JC030-N-V00-BLK (JC030-GENERIC-0003)	SINGLE AXIS ROCKER
I-JC030-E-V00-BLK	SINGLE AXIS ROCKER
JC120-0001	JOYSTICK
JC120-0011	
JC120-0003	Joystick
JC120-0013	SINGLE AXIS JOYSTICK
SLS095/0100/4.0K/P/50	

Product	Description
SLS095/10/0.4K/R/66	LINEAR DISPLACEMENT SENSOR
SLS095/0030/1.2K/R/66	LINEAR DISPLACEMENT SENSOR
SLS095/0010/0.4K/P/66	LINEAR DISPLACEMENT SENSOR
SLS095/30/1.2K/P/66	LINEAR DISPLACEMENT SENSOR
SLS095/0050/2.0K/P/66	
SLS130/0075/L/50/01/N	
SLS130/0050/C/50/01/N	LINEAR DISPLACEMENT SENSOR
SLS130/0075/C/50/01/N	LINEAR DISPLACEMENT SENSOR
SLS130-025-L-66-01-N	
SLS130/0050/L/66/01/N	LINEAR DISPLACEMENT SENSOR
SLS130/0125/L/66/01/N	LINEAR DISPLACEMENT SENSOR
SLS130/0050/C/66/01/N	Linear Displacement Sensor
SLS130/0100/C/66/01/N	Linear Displacement Sensor
SLS130/0125/C/66/01/N	sensor
SLS130/0150/C/66/01/N	sensor
SLS130/0200/C/66/01/N	sensor
SLS130/0025/L/50/10/N	LINEAR DISPLACEMENT SENSOR
SLS130/0050/L/50/10/N	
SLS130-100-L-50-N	LINEAR DISPLACEMENT SENSOR
SLS130/125/L/50/10/N	LINEAR DISPLACEMENT SENSOR
SLS130/0200/L/50/10/N	LINEAR DISPLACEMENT SENSOR
SLS130-150-L-66-10-N	
SLS130/0075/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS130/0150/C/66/10/N	Linear-Potentiometer, Type SLS130
SLS130/0200/C/66/10/N	Linear-Potentiometer, Type SLS130
SLS130/0150/L/50/01/P	LINEAR DISPLACEMENT SENSOR
SLS130/0175/L/66/10/P	
SLS130/0200/C/66/10/P	LINEAR DISPLACEMENT SENSOR
SLS320/0300/L/66/01/N	
SLS320/0350/L/66/01/N	potentiometer
SLS320/0550/L/66/01/N	LINEAR DISPLACEMENT SENSOR
SLS320/0800/C/66/01/N	LINEAR DISPLACEMENT SENSOR
SLS320/450/L/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/0800/L/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/0400/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/0450/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/0650/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/0700/C/66/10/N	LINEAR DISPLACEMENT SENSOR
SLS320/750/C/66/10/N	
SLS320/0550/L/66/01/P	LINEAR DISPLACEMENT SENSOR
SLS320/1350/C/66/01/P	LINEAR DISPLACEMENT SENSOR
SLS320/0400/L/66/10/P	LINEAR DISPLACEMENT SENSOR
SLS320/0550/L/66/10/P	LINEAR DISPLACEMENT SENSOR
SLS320/0450/C/66/10/P	
SLS320/0800/C/66/10/P	LINEAR DISPLACEMENT SENSOR

Product	Description
SLS320/0650/L/66/01/P	Linear-Potentiometer
SLS320/0800/C/66/00/P	LINEAR DISPLACEMENT SENSOR
SLT190/300/A/01	LINEAR POSITION TRANSDUCER
SLT190/0350/B/01	LINEAR POSITION TRANSDUCER
SLT190/0450/B/01	LINEAR POSITION TRANSDUCER
SLT190/100/A/06	LINEAR POSITION TRANSDUCER
SLT190/0125/B/06	LINEAR POSITION Transducer
EICTM	SIGNAL CONDITIONING MODULE
JC400-C-XY-QQ-MA-ZC-S-P	Joystick, Type JC400
JC6000-GEN-0035	joystick
SLS190/0100/L/66/01/N	LINEAR DISPLACEMENT SENSOR
AF145/0150	
AF145/0100	
UCM	
JC6000-GEN-1324	Multi-axis joystick
SA47269	I-Kit. -connector
D22720Rev02	POTENTIOMETER
JC150GENHK-0003	
111RC001801-P (D20492 RCP18/1S/1K/LIN)	Potentiometer
JC6000-0040 (JC6000-XY-PEE-H-S-NL-N-STN-HB2)	Joystick
JC400-A-Y-N/-HA-ZC/-N	
SLS320/0700/L/50/01/N	Linear-Potentiometer, Type SLS320
I-JC1500-Y-A-PP-S-M-NL-D1-MG00-R-S	Joystick
SLT190/0300/B/06	Linearer Wegaufnehmer
SLS130/0175/C/66/01/N	linear encoder
JC400-A-Y-QQ-MA-ZCS-P	Joystick
HLP190/BS1/0100/4K	Linear-Potentiometer
HLP190/BS1/0050/2K	
JC-100-07	Joystick, Type JC100
I-JC150-Y-N-HKN-STN-FLD1	Joystick, Type JC150
SLS320/1200/C/66/01/P	Linear-Potentiometer
SLS320/0650/L/66/10/P	Linear-Potentiometer
I-JC150-Y-E-M-HKN-STN	Joystick
EICT	ICT/SLT sensor conditioner
SLT190/0050/B/06	linear displacement sensor
AF145 (Bestell Code: AF145/0025)	LVDT displacement transducer
SLS130/0200/C/50/10/N	Linear-Potentiometer, Type SLS130
JC6000-GEN-0007	joystick
SLS190/0250/L/50/01/N	
JC400-GENERIC-0171	Joystick
JC150GENHK-001	
JC6000-XY-PNN-N-S-NL-N-STN-HKN	
JC6000-GEN-0944	Joystick
JC6000-XY-PNN-M-S-NL-N-STN-MG02	CONTROL SWITCH

Product	Description
JC6000-XY-PEE-M-S-NL-N-STN-MG02 (JC6000-GEN-0205)	Joystick
JC400-GENERIC-0471	
SLT190/0500/B/01	Linear position transducer
JC6000-GEN-0036	joystick
JC150GENHK-001 (JC105-Y-L-M-HKN-STN)	Joystick, Type JC150
JC6000-XY-PNN-N-S-NL-N-STN-MG02	
SLS190/0150/C/50/01/N	Linear potentiometer
JC400-GENERIC-0300	joystick industrial
JC400-B-XY-RR-/HA-ZA-S-P	Joystick
JC400-B-XY-RR-/HA-ZA-S-P (10 pcs)	Joystick
JC100-007-x	Joystick
SLS095/0050/2.0K/R/66	potentiometer
MZ137A39P2	SOLENOID ASSEMBLY
JC120-0012 914071211 see JC120-0012	Joystick
P304856M	Neoprene boot
I-JC400-A-XY-NN-LA-ZCS-S-N	Joystick
SA47363	I-Kit,connector-JC300
SRH280DP/380/360/A1/5/S/68/P5	contactless rotary sensor
W107841/0530	SCREW
W107841/0540	SCREW
JC150-Y-E-M-HKN-STN	Joystick single axis-5K POT
SLS190/0075/L/66/10/N	LINEAR DISPLACEMENT SENSOR
JC6000-GEN-0943	Joystick
MGMF-GEN-0002	
ICS100/EM/0940/H/01	
JC400-C-XY-NN-MA-ZC-S-P-SPL (JC400-0088)	Joystick
JC6000-GEN-1320	
JC6000-GEN-1276	
JC030-GENERIC-0003 (I-JC030-N-V00-BLK)	Joystick
D20492 RCP18/1S/1K/LIN	
JC400-B-Y-N-MA-ZCS-N (JC400-GENERIC-0065)	Joystick
SLS095/0050/2.0K/R/50	Transducer
I-JC400-A-XY-NN-/MA-ZCS-S-P	
I-JC6000-XY-PEE-M-S-NL-N-STN-NHF	
HLP190-FS1-125-5K	Potentiometer
ICS100/IN/0500/H/10 (6-9 pcs)	
STT280/60/P5	
SLS320/0500/L/50/01/N	Linear potentiometer
SLS190/0325/C/66/10/N	Linear displacement sensor
JC200-0011 / I-JC200 -B-S-1-K1-Y	joystick
SSC	sensor signal conditioning module
DSLS130C-GEN-0009 / SLS130/0050/C/50/01/N	Linear displacement sensor
HLP190FS1/0025/1K	
SA59019	flange mount kit

Product	Description
I-JC6000-XY-PNN-M-S-NL-N-STN-A60D	JOYSTICK CONTROLLER
I-JC6000-XY-PNN-M-S-NL-N-STN-A2HD-HN-V	JOYSTICK CONTROLLER
SRS880/090/05/AL	
SLS095/0075/3.0K/P/50	LINEAR DISPLACEMENT SENSOR
SA47931	16-pin connector
D150312	POTENTIOMETER
D20493	POTENTIOMETER
SRS280/340/S/68/A	Sealed rotary sensor
SLS190/0250/L/66/01/N	Linear Sensor
SLS190/0150/L/66/01/N	LINEAR DISPLACEMENT SENSOR
JC120-0004	
SLS095/0020/0.8K/P/50	Cylinder
I-JC2000-T-XY-POPOO-40-HL-S-P-H	Joystick
JC2000-T-X-PNOOO-40-E1-1-N-S	
JC400-GENERIC-0032 / I-JC400-B-XY-RR-/MA-ZCS-S-N	JOY-STICK
SLS320/0600/L/66/01/N	
SLS190/0150/C/66/01/N	Potentiometer
D3410/3 (H-RP15/1E)	
SA21016	H-CLAMP SYNCHRO ASSEMBLY
JC2000-T-XY-PPPP0-40-E2-P-P-H	JC2000SW-GEN-0147
SLS320/0600/L/50/01/N	Linear Displacement Sensor
JC400-0009 (JC400-B-XY-QQ-MA-ZCS-S-N)	
JC400/B/XY/RR-/MA/ZC/S/N	
SLS130/0100/L/50/01/N	LINEAR DISPLACEMENT SENSOR
JC6000-GEN-0555	joystick
DS3410/MK2	Potentiometer
P/N: 112744, Type: TK1-4131AB024MC2351	SICHERHEITSSCHALTER
SLS190/00075/L/50/01/N	SENSOR
SLS190/00075/L/66/01/N	sensor
SLS320/0700/L/66/01/N	Linear-Potentiometer, Type SLS320
JC150-Y-R-M-HKN-STN	
JC6000-NY-PU-H-/NL-N-STN-A30D	joystick
SLS190/0050/L/50/01/N	LINEAR DISPLACEMENT SENSOR
I-JC150-Y-R-M-MG02-STN	
10121522	Drive Steer Joystick
D3410/2	
JC400-GENERIC-0410	Joystick, Control, Dual Axis
VPT351/25/A3/1/P2/C0	VALVE POSITION SENSOR
JC100-002	Joystick
I-JC6000-XY-PEE-M-S-NL-N-STN-MG11	joystick
SLS095/0030/1.2K/R/50	Linear sensor
JC2000SW-GEN-0029	
JC600-XY-NN-M-A60D-STN-CG-SPL	joystick
I-JC400-F-XY-RR-/MA-ZC-C	Multi-Axis Joystick Analogue Output

Product	Description
I-JC400-F-XY-RR-/-MA-ZC-S-P	Multi-Axis Joystick Analogue Output
I-JC400-A-XY-RR-MA-ZC-S-P	MULTI AXIS JOYSTICK
ICS100/EM/0200/H/01	IN-CYLINDER LINEAR DISPLACEMENT SENSOR
SRH280DP/120/120/A1/4D/68/P2	
SLS190/0100/L/50/01/N KX109852	
PAP1750	
PA1334L	
REM13341456	
PRT12121944	
SLS130/0025/C/50/01/N	Linear Displacement Sensor
JC6000-GEN-0699	Joystick
SLS130/0100/L/66/01/N	Linear Displacement Sensor
I-JC150-Y-L-M-MG03-STN	
JC150GENFLK-0021	joystick
D1315	TRANSDUCER 0-10V
SLS130/0075/C/66/01/N	
JC400-GENERIC-0186 (I-JC400-A-Y-Q-MA-ZC-N)	
JC400-A-XY-NN-LA-ZC-S-N	
SA301649	I-Connector Assy
CM	
I-JC400-A-XY-RR-/-MA-ZC1-S-P	JOYSTICK
ICT050/EM/TM/0030/L/P5	
D45726/0100/04K/SA/L/66/01	linear potentiometer
JC400-GENERIC-0297	
M12 61-169-102	
I-JC2000-T-X-PPOOO-40-HL-1-N-S	
SA202195/MK2	
I-JC2000-T-XY-PPPPPO-40-HL-S-P-S	
SLS320/0800/L/66/01/P	
MLS130/0050/R/N	
MLS130/0075/R/N	
MLS130/0100/R/N	
MLS130/0150/R/N	
JC400-GENERIC-0148	JOYSTICK
SRS880/090/02/AL	
I-JC400-B-Y-R-/-MA-ZC-/-N (JC400-GENERIC-0023)	
SLS190-200-L-50-01-N	
SLS130/0025/L/66/01/N	
SLS190/0200/C/66/01/N	sensor
ICT100/EM/SC/0600/B/H/01	
SLS190/25/L/50/01/N	
SLS130/0125/C/50/10/N	Linear motion sensor
JC400-GENERIC-0174	I-JC400-A-XY-RR-/-MA-KW-S-P
JC150GENMG-0043	I-JC150-Y-R-M-MG10-STN

Product	Description
8624350	
JC025-GENERIC-0004	switch
d21039 art.no 111RC001806-P	
JC100-007	joystick
D150179	
JC600-023	I-JC600 Cross-gate Joystick
ICT100/EM/SC/0260/B/H/01	
TPS280DP/100/100/A1/x/P2/C0	potentiometer
P49780	I-Cable Harness
SLS095/0050/2K0/R/66	linear position transmitter
RCP18/2S D20493	
JC400-A-XY-QQ-/-MA-ZC1-R-P	BIAXIAL JOYSTICK
I-JC2000-T-XY-PNPNO-25-K1-R-N-S	
JC120-0012	switch
SLS190/0250/L/50/10/N	
SLS190/0050/C/50/01/N	
JC600-0062	I-JC600 terex trigger handle
I-JC100/X/-S-0-4K0-SWT-0%	joistic
SA59640/10 - 10m extension kit	extension kit
SLS190/100/L/66/01/N	LINEAR DISPLACEMENT SENSOR
ICT100/IN/SC/0200/A/H/01	Contactless In-Cylinder Linear Transducer
SLS190-275-C-50-01-P	Linear displacement sensor
SLT190/0075/A/06	transducer
JC400-GENERIC-0124	Joystick
111RC001804-P (D22505 RCP18/1S/5K/LIN)	Potentiometer
STT280/30/02	
JC-400A-Y-Q-HA-ZC1-N	UNIAXIAL JOYSTICK
JC6000-NY-PE-M-S-NL-N-STN-HKN	joystick
GSV2500	leak detection gun
JC030-GENERIC-0001	Control button
P307388 I-JC100	
VM	VMcard
SA204323/100	
JC400-B-XY-QQ-/-HA-ZCS-S-P	
Perma-Slik® RGAC	
SLS220/020/0.8K	
SRH220DR/034/034/A1/3/D/D	
SA208983	Drive lever kit
SLS320/450/C/66/10/N	
NRH300DP/360/A1/3/M/P5	
SLS130/0150/L/66/10/N	
JC2000SW-GEN-0147	
JC2000SW-GEN-0148	
JC120-0007	Miniature Single-Axis Control Joystick
SLS095/0020/0.8K/R/50	

Product	Description
GTMAX050P40	
SLS130/100/C/66/1/N	
SLS130/0100/L/50/10/N	sensor
SLS190/0125/L/50/1/N	
JC400-GENERIC-0189	Joystick
W107830	Case for batteries
W109623-1	Rechargeable Battery Packs
I-JC6000-XY-PNN-M-S-NL-N-STN-MG11	Arm Joystick
SLS130 / 25 / L / 50/10 / N	
D41036	sensor
SLS190/0300/L/66/01/N	
STT280/30/P5	SEALED ANGLE SENSOR
JC6000-GEN-0363	joystick controller
SRS880/350/02/AL	potentiometer
JC400-0021	joystick
D45978/0400/06	
JC400-GENERIC-0506	Manual Switch JOYSTICK
JC400-0056	
ICT800/E/T/1000/0000/0000/A1/C01	
JC6000-GEN-0184	joystick
JC400-0009	
JC150GENLK-0002	
JC2000SW-GEN-0028	
JC2000SW-GEN-0126	
JC2000SW-GEN-0193	
JC2000SW-GEN-0194	
SRS880/090/05/SS	Rotary position sensor
ICT100/EM/SC/0150/B/L/06	transducer
I-PGFM3200/-/M/--/E/I/Z/X No.D460667	
SLS190/0050/L/66/10/N	Linear-Potentiometer, Type SLS190
SLS130-100-L-66-01-N	
SLS190/0325/L/50/01/N	Linear-Potentiometer
JC150GENHK-0004 // I-JC150-Y-S-M-HKN-STN	
SLS190/0325/L/66/01/N	
I-JC150-Y-E-M-A500-STN	
000000-0502-836 OEM	
JC025-Generic-0008	wicket
JC400-0108 // I-JC400-F-XY-RR-/MA-ZC-C-SPL	
SRH301/090/A1/1/D/P2/NC0	
I-PGF3210/D/U/----/A	
I-PGF3210/D/M/----/A/SPL	
TPS280DP/090/090/P2/5/P5/CO	
SCM100/V	
JC400-C-XY-NN-/MA-ZC-S-P	Multi-Axis Fingertip Joystick Controller
JC120-0006 1333523713	

Product	Description
HLP190FS1/0050/2K	potentiometer
131JC015005	potentiometer
SLS190/0350/C/66/01/N	
I-JC400-D-XY-QQ-/-LA-ZC-S-N	MULTI-AXIS FINGERTIP JOYSTICK CONTROLLER
ITC100/EM/TM/0440/A/L/01	Lienarsensor
111RC001803-P	POTENTIOMETER
JC400-F-XY-RR-/-MA-ZC1-S-P	
JC6000-GEN-0402	
JC6000-GEN-0345	
ICT080S-GEN-0013	
SLS190/0125/C/66/01/N	
NRH300DP/090/A1/3/P/P5	
SLS130/0075/L/50/10/N	LINEAR DISPLACEMENT SENSOR
D44035	
SLS190/0125/C/50/01/N	
SRS280/350/S/68/A	
SRS280/090/S/68/A	
SLS320/300/12K/L/66/01 /N	
SLS320/0300/L/66/01/P	
I-JC2000-T-X-PPOOO-40-S1-1-N-S	
JC2000-T-XY-PPPPPO-40-K1-S-P-S	
JC6000-Gen-0180	
AF111/0150	
SLS320/0550/C/66/01/N	
JC400-C-XY-DD-D-MD-ZC-R-N	
JC2000-T-XYZ-POPOP-40-E1-S-N-S	
JC2000-T-XYZ-POPOP-40-E1-D-N-S	
SLS190/0150/L/66/01/P	LINEAR PLACEMENT TRANSDUCER
JC3000-XY-P31-SW5-M-A-D5H-STN-ZC1	Two-axis joystick
JC3000-NY-131-SW5-M-A-D5H-STN-ZC1	Uniaxial joystick
JC600-043	joystick
JC2000-T-XYZ-POPOP-40-E1-S-P-S	
SLS095/030/1.2K/R/50	
SLS095/030/1.2K/R/66	
JC400-C-Y-N-/-MA-ZC-/-N	
HPL190/FS/01/4K/100	
SRH280DP/360/360/A1/4D/68/P2	
SLS095/0050/2.0K/P/50	potentiometer
SLS320/0750/L/66/01/N	LINEAR DISPLACEMENT SENSOR
JC6000-NY-PR-M-S-NL-N-STN-MG03	
JC6000-NY-HC1-H-S-NL-N-JR1-NHF-SPL	joysticks
SLS130/0125/C/50/01/N	
SRS880/350/02/SS	Rudder bar angle indicator potentiometer
JC6000-WI-00027	Control joystick
SA47932	I-Conn & pins.12/16way amp 040 series

Product	Description
D20825/CRv02	potentiometer
JC400-D-XY-NN-MA-ZC-S-P	Joystick
JC2000SW-GEN-0020	
JC400-GENERIC-0152	
JC2000-T-XYZ-POPOP-40-HL-S-P-H	
ICT100/EU/SC/1720/A/H/06	
SLS19050L6601N	
JC400-GENERIC-0090	Joystick
SLS095/0075/3.0K/R/66	LINEAR DISPLACEMENT SENSOR
SLS320/0500/C/66/01/N	
SRS280/090/S/68/B	
D22505 var6 iss7	potentiometer
JC400-A-XY-RR-MA-ZA-S-P	Multi-Axis Joystick
SLS320/0900/L/50/01/N	
SLS130/0075/L/50/10/N KD20828	
JC2000-WI-00021	
SLS190/00250/C/66/01/N	
SLS190/0175/C/66/01/N	
JC400-D-XY-Q-LA-ZC-S-N	
JC2000-T-XY-PPPPO-25-S1-S-P-S	Joystick
SRH880P/090/A/1/05/AL	
JC150-Y-S-M-CL-STN	Joystick
SLS190/0100/L/50/01/P	
SLS190/0125/L/50/01/P	
SLS190/0225/L/50/1/N	
JC400-GENERIC-0076 (003620092016)	joystick
JC2000SW-GEN-0108	
SLS320/0900/C/66/01/N	
TPS280DP/110/110/A1/5/P2/C0	
ICS100/EM/0180/H01	
JC400-GENERIC-0162	
I-JC400-A-Y-N-/MA-ZCS-/N	
I-JC150-Y-L-M-CL-STN	
D1315 (H-DC LVDT)	Cylinder
SLS130/0075/L/66/01/N	
ICT100/EM/SC/1380/A/H/01	
ICT080/EM/TM/0125/A/H/01	
SRH880P/090/A*/02/AL	
SLS190/0100/C/50/01/N	
51181	Wired Stereo Fader
D319223	
RH302/360/A1/4/S/P2/CC0	rotary sensor
SLS190/0050/L/66/01	POTENTIOMETER
SRH302/360/A1/5/S/P2/NC0	Sensor
I-JC400-A-XY-RR-/MA-KW-S-P	

Product	Description
SRS880/100/02/AL	
SLS130/0100/L/66/10/N	position transducer
SRS880/180/02/AL	
SLS190/150/L/66/01/N	
SRH280DP/025/025/A1/5/S/68/P5	
I-JC6000-XY-PRR-H-S-NL-N-STN-HKN	Joystick Controller
I-JC400-C-Y-N/-MA-ZCS/-N	joystick
I-PGF8110/D/M/----/A	
JC3000-GEN-0074	joystick
ICT100/EU/SC/0510/A/H/06	
SLS320/0650/L/50/10/P LVDT	
SLS190/0100/C/50/10/N	Linear potentiometer
I-JC6000-XY-PSS-M-S-NL-N-STN-A1RT-RR-S	
SLS190/0225/L/50/01/N	
SRH280DP/360/360/A1/4/S/68/P5	dual track rotary position sensor
SLS190/0025/C/50/01/N	
JC2000-T-XYZ-POPOP-40-HL-P-P-H	joystick
D468004	
CM Electronic card	
JC1500-Y-A-PN-S-M-NL-D1-A000/-/-R-STA	
JC6000-NY-PE-M-NL-N-STN-MG01	
SLS320/0750/C/66/10/P	
SLS320/0450/L/50/01/N	
JC150-Y-E-M-CL-STN	Joystick
D370535	ROTARY TRANSDUCER
JC400-0057	joystick
SA59020	
SLS190/0300/L/50/01/N	
I-JC2000-T-X-PP000-40-S1-1-N-S	
I-JC2000-T-X-PN000-25-S3-1-N-S	
TPS280DP/180/180/A1/3/P2/C0	
TPS280DP/180/180/A1/4/P2/C0	
SLS190/0075/C/50/01/N	
JC2000-0004	joystick
SLS130/125/L/66/01/N	INDUSTRIAL LINEAR POTENTIOMETER
I-JC6000-NY-PN-M-S-NL-N-STN-MG01	joystick
JC2000-GEN-0004	
SRH302/045/A1/3/S/P2/NC0	
ICT100/EM/TM/0400/A/H/06	sensor
ROMANI00E08A0	
JC6000-GEN-0979	
SLS190/150/L/66/01/P	LINEAR DISPLACEMENT TRANSDUCER
P304856MOD01	
D46273/0850/C/66/10/N	
JC6000-GEN-0736	Joystick

Product	Description
SRH280DP/360/360/A1/3/D/68/P5	
JC400-0009 / I-JC400-B-Y-R/-MA-ZC/-N-SPL	Joystick
JC3000-GEN-0153 (I-XY-S25-PE4-M-A-D00-STN-HL0)	Joystick controller dual axis
ICT100/EM/TM/0200/B/H/01	position sensor
SRS880/040/05/A	
SRH220DR/100/100/A4/3/D/D	
D150098 RCP09/1S/5K/LIN iss. 6	
ICT100/EM/SC/260/B/H/06	cylinder sensor
SLT190/0200/A/06	
EICT + CM	
divET	
JC400-B-XY-DD-D-LD-ZC1-D-P	
I-JC6000-SY-PE-S/-NL-N-STN-MG11	Joystick
I-PGF8122/D/M/---/A	faders
2105798	JOYSTICK
ICS100-GEN-0162	Cylinder Linear Position Sensor
D51615-202-013-090	Data Acquisition Flight Recorder
SA109680	
SLS320/0350/L/66/01/P	
SRS280/270/D/68/A	sealed rotary sensor
SLS320/0750/L/66/01/P	
JC2000-GEN-0108	joystick
ICT080/IN/SC/0065/B/H/01	transducers
SLS190/250/L/50/01/N	potentiometer
I-JC400-A-Y-R/-MA-ZC1/-N / 117558092012	
SLS320/0450/L/66/10/N	sensor
SLS320/450/L/66/01/	
I-JC400-F-XY-NN/-MA-ZC1-S-P	
JC400-GENERIC-0191	
JC150GENFLK-0002	
ICS100/EI/0170/H/01	
JC6000-XY-PNN-M-S-NL-N-STN-MG08	LEFT JOYSTICK CONTROLLER
JC6000-XY-PNN-M-S-NL-N-STN-MG11	
111RC001814-P	
ICT050/EM/FF/0070/H/01	
SLS095/0075/3.0K/R/50	Transmitter with plug connector
JC150GENHK-0002	SW JOYSTICK
I-JC150-Y-E/-HKN-STN-FLD0	joystick
JC150-WI-00015	Replacement handle
MG03	Replacement handle
JC150-Y-N-M-WT10-STN	Single Axis Joystick Controller
JC150-Y-N-M-MG03-STN	Single Axis Joystick Controller
JC6000-XY-PEE-M-S-NL-N-STN-MG06	biaxial joystick
SLS320/0400/L/66/01/N	

Product	Description
DS150281 ISS 3	Precision Potentiometer
SLS130/75/C/50/1/N	
ICT050/EM/FF/0030/H/01	
ICT050/EM/FF/0045/H/01	
ICT050/EM/FF/0035/H/01	
ICT050/EM/FF/0075/H/01	
ICT050/EM/FF/0055/H/01	
ICT050/EM/FF/0100/H/01	
ICT050/EM/FF/0060/H/01	
ICT050/EM/FF/0090/H/01	
ICT050/EM/FF/0040/H/01	
SLS095/30/1.2/R/66	
JC6000-GENHI-0026	Hi Grip Joystick
ICT050/EU/SC/030/H/01	
SRS280/320/S/66/A	angle sensor
TPS280DP-WI-00014	
SRS280-320-S-68-A	
ICT100/EM/SC/0270/A/H/01	measurement system
JC400-GENERIC-0299	
SLT190/0175/B/06	TRASD. POSITION
P201968	CONVERTER
J C 4 0 0 - C - X Y - R R - / - M A - Z C - R - P	
LI-JCBL-JC6000-1000-16	
LI-JCBL-JC6000-1000-12	
D20493 RCP18/2S/1+1K/LIN	
ICT100/EM/SC/1380/A/H/04	
Permaslik RGAC 1 Gallon	
ICT100/EM/SC/0260/B/H/06	
SRH302/045/A5/5/S/P2/CC0	
I-JC6000-XY-PEE-H-S-NL-N-STN-MG11	Command
JC400-GENERIC-0190	Joystick
SLS130/0200/L/66/01/N	
D150281 RCP15/1S/2K/LIN	
ICT080/IN/SC/0150/A/H/06	sensor
HLP190/FS/01/0125/5K	
JC120- 0006 1329343613	potentiometric lever
HLP190/FS/01/0150/6K	
ICT100-WI-00017	
SLT190/0100/A/01	
ICT050/RM/TM/0100/H/06	
JC6000 XY-PEE-M-S-NL-STN-A20D	
SRS880/180/05/SS, KD30532	rotary sensor
JC400-GENERIC-0022 I-JC400-B-Y-Q/-MA-ZC/-N	
JC150GENLK-0001/JC150-Y-L-M-CL-STN	control stake

Product	Description
SLS320/0650/L/66/10/N	
SLS190/0100/C/50/01/N	
SLS190/0100/C/50/01/P	
AF145/0005 LVDT AF145/0005	
SRH501P/360/A3/1/S00	sensor
SLS320/0450/L/66/01/N	TRANSDUCER
SA200265/0100	
JC200-0011 /JC200-B-S-1-K1-Y	
D150281	prescision potentiometer
D20493.VAR6 ISS5	
JC3000-XY-P31-SW5-M-A-D5H-STN-ZCS	
JC3000-GEN-0089 (I-XY-P31-SW5-M-A-D5H-STN-ZCS)	Joystick
JC3000-GEN-0090 (I-NY-131-SW5-M-A-D5H-STN-ZCS)	Joystick
SLT190/0175/A/06	linear transducer
JC600-WI-00004	
JC600-WI-00005	
I-JC600-Y-R-M-HB0-STN-S	
I-JC600-XY-RR-M-HBO-STN-S	
HLP190FS1/0100/4K	
JC025-GENERIC-0005	
JC2000-GEN-0076	joystick
ICS100/EM/0050/H/01	SENSOR;IN-CYLINDER LINER POS
SRH280DP-GEN-0151	