



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Rabourdin

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

| Product                               | Description                                      |
|---------------------------------------|--------------------------------------------------|
| <a href="#">1005-10-20</a>            | Guide ring flange                                |
| <a href="#">1021-16-160</a>           | SHOULDER BOLT                                    |
| <a href="#">1021-5-32</a>             | Hexagon socket shoulder screw                    |
| <a href="#">1021-8-20</a>             | Shoulder Bolt 12.9                               |
| <a href="#">1021-8-30</a>             | SHOULDER BOLT                                    |
| <a href="#">R1031-8-20 (151309)</a>   | lead screw                                       |
| <a href="#">387-16-120</a>            | guide bolt                                       |
| <a href="#">387-8-10</a>              | GUIDE SHAFT                                      |
| <a href="#">521-6-20</a>              |                                                  |
| <a href="#">5940.02.75</a>            | Door left detector L75                           |
| <a href="#">10016040</a>              | guide screws                                     |
| <a href="#">1005-16-32</a>            | (Gleitführungsbuchse with collar without spigot) |
| <a href="#">1005-40-56</a>            | ring                                             |
| <a href="#">REF1021-12-90</a>         | (Lead screw)                                     |
| <a href="#">527-10-35</a>             | (Cylinderhead screw)                             |
| <a href="#">1021-6-25 / 3221-6-25</a> | GUIDE SCREW                                      |
| <a href="#">1021-6x30/3221-6-30</a>   | GUIDE SCREW                                      |
| <a href="#">1021-6-12</a>             | GUIDE SCREW                                      |
| <a href="#">R1031-6-25</a>            | Führungsschraube                                 |
| <a href="#">R1031-6-12</a>            | Führungsschraube                                 |
| <a href="#">355-25-44</a>             | color:green                                      |
| <a href="#">SN2520-25-44</a>          | Systemfeder                                      |
| <a href="#">R1021-20-80</a>           | Schraube                                         |
| <a href="#">R1031-12-70</a>           | Führungsschraube                                 |
| <a href="#">R1031-16-80</a>           | Führungsschraube                                 |
| <a href="#">R1031-8-32</a>            | Führungsschraube                                 |
| <a href="#">1005-18-20</a>            | socket                                           |
| <a href="#">5737-40 61</a>            | Ring                                             |
| <a href="#">5741-40 70</a>            | Ball Cage                                        |
| <a href="#">5522-3</a>                | Mounting flange                                  |
| <a href="#">1021-4-40</a>             | Hexagonal screw                                  |
| <a href="#">1031-10-30</a>            | screw shoulder                                   |
| <a href="#">1054-32-46</a>            | Ring                                             |
| <a href="#">1006-40-52</a>            | ring                                             |
| <a href="#">601-40-180</a>            | column guide                                     |
| <a href="#">5412-40-224</a>           | Column                                           |

| Product                         | Description                              |
|---------------------------------|------------------------------------------|
| <a href="#">5432-25-140</a>     | Column                                   |
| <a href="#">5511-32</a>         | Half ring                                |
| <a href="#">5511-40</a>         | Half ring                                |
| <a href="#">1052-40-80</a>      | ring                                     |
| <a href="#">1052-25-50</a>      | ring                                     |
| <a href="#">5412-32-224</a>     | Column                                   |
| <a href="#">357-20-76</a>       | SPRING                                   |
| <a href="#">1052-32-80</a>      | ring                                     |
| <a href="#">357-16-25</a>       | strong red spring load                   |
| <a href="#">385-16-2</a>        | spring washer                            |
| <a href="#">501-6-24</a>        | Cylindrical pin                          |
| <a href="#">501-3-12</a>        | Cylindrical pin                          |
| <a href="#">501-3-28</a>        | Cylindrical pin                          |
| <a href="#">501-8-36</a>        | Cylindrical pin                          |
| <a href="#">501-8-20</a>        | Cylindrical pin                          |
| <a href="#">5940 02 150</a>     | ENS. LEFT DOOR DETECTOR                  |
| <a href="#">5410-25-100</a>     | Column holding a screw                   |
| <a href="#">5722-40-250-48R</a> |                                          |
| <a href="#">5741-40-104</a>     |                                          |
| <a href="#">5734-40-48</a>      |                                          |
| <a href="#">5731-40-48R</a>     |                                          |
| <a href="#">5721-20-125</a>     |                                          |
| <a href="#">5711-20</a>         |                                          |
| <a href="#">387-10-40</a>       | Axe de guidage                           |
| <a href="#">3112-10-40</a>      | PHOSPHATED CYLINDRICAL PIN               |
| <a href="#">3122-10-30</a>      |                                          |
| <a href="#">3122-10-24</a>      |                                          |
| <a href="#">3122-8-24</a>       |                                          |
| <a href="#">3122-8-20</a>       |                                          |
| <a href="#">1005-14-16</a>      | Ring with collar                         |
| <a href="#">636-8-150</a>       |                                          |
| <a href="#">628-1.4-100</a>     |                                          |
| <a href="#">628-5-160</a>       |                                          |
| <a href="#">673-36-32-245</a>   | Guide column with OXA stud               |
| <a href="#">1073-32-196</a>     |                                          |
| <a href="#">629-3.5-1.2-160</a> |                                          |
| <a href="#">629-4-1.2-160</a>   |                                          |
| <a href="#">1021-20-90</a>      |                                          |
| <a href="#">1021-20-110</a>     |                                          |
| <a href="#">1021-20-120</a>     |                                          |
| <a href="#">358-63-203</a>      | RESSORT CHARGE EXTRA FORTE COULEUR JAUNE |
| <a href="#">385-20-3</a>        | RONDELLE RESSORT                         |
| <a href="#">1071-50-100</a>     | Flanged ring with stud                   |
| <a href="#">501-10-24</a>       | Cylindrical pin                          |
| <a href="#">1021-12-20</a>      |                                          |

| Product                       | Description                                               |
|-------------------------------|-----------------------------------------------------------|
| <a href="#">1021-12-100</a>   | shoulder bolt                                             |
| <a href="#">521-10-24</a>     | Tapped cylindrical pin                                    |
| <a href="#">1021-5-8</a>      | screw 6 pans                                              |
| <a href="#">501-6-16</a>      | DOWEL PIN                                                 |
| <a href="#">1021-8-32</a>     | Screw 6 pans                                              |
| <a href="#">Rab.</a>          | certificate of conformity                                 |
| <a href="#">1005-25-20</a>    | Bushes                                                    |
| <a href="#">601-25-80</a>     | Guide pins                                                |
| <a href="#">626-3-125</a>     |                                                           |
| <a href="#">626-5-75</a>      |                                                           |
| <a href="#">1031-6-8</a>      | Bolt M6x8 stainless steel                                 |
| <a href="#">1031-8-10</a>     | Fitting screw M8x10 stainless steel                       |
| <a href="#">651-32-63-100</a> | Column                                                    |
| <a href="#">1007-32-56</a>    | Bush                                                      |
| <a href="#">5312-50-80</a>    |                                                           |
| <a href="#">1021-8-50</a>     | SHOULDER BOLT 12.9                                        |
| <a href="#">1021-5-25</a>     | shoulder bolt                                             |
| <a href="#">356-16-305</a>    | Blue medium load spring                                   |
| <a href="#">637-8-12-250</a>  | Tubular ejector cone                                      |
| <a href="#">1031-6-32</a>     | Stainless steel with hexagon socket                       |
| <a href="#">1005-20-16</a>    | Flange guide ring                                         |
| <a href="#">1007-10-17</a>    | SMOOTH GUIDE BUSH                                         |
| <a href="#">628-10-1350</a>   |                                                           |
| <a href="#">628-12-1350</a>   |                                                           |
| <a href="#">628-16-1350</a>   |                                                           |
| <a href="#">628-20-1350</a>   |                                                           |
| <a href="#">626-4-200</a>     |                                                           |
| <a href="#">626-10-325</a>    |                                                           |
| <a href="#">626-10-350</a>    | tubular ejector cylindrical head nitrided lap-in          |
| <a href="#">626-10-275</a>    |                                                           |
| <a href="#">355-20-115</a>    |                                                           |
| <a href="#">355-25-38</a>     | RECTANGULAR WIRE DIE SPRING                               |
| <a href="#">356-20-127</a>    |                                                           |
| <a href="#">395-30</a>        |                                                           |
| <a href="#">601-14-90</a>     |                                                           |
| <a href="#">324-20-102</a>    | RECTANGULAR WIRE DIE SPRING PURPLE COLOUR LIGHT EXTRALOAD |
| <a href="#">387-16-50</a>     | GUIDE BOLT                                                |
| <a href="#">387-25-160</a>    |                                                           |
| <a href="#">1005-20-25</a>    |                                                           |
| <a href="#">501-16-100</a>    |                                                           |
| <a href="#">501-16-150</a>    |                                                           |
| <a href="#">601-32-240</a>    | guide pin                                                 |
| <a href="#">601-20-240</a>    | GUIDE PILLAR                                              |
| <a href="#">390-20-32</a>     |                                                           |
| <a href="#">522-26-30</a>     | DOWEL PIN                                                 |

| Product                      | Description                              |
|------------------------------|------------------------------------------|
| <a href="#">522-20-25</a>    | DOWEL PIN                                |
| <a href="#">522-26-18</a>    | DOWEL PIN                                |
| <a href="#">5741-20-46</a>   | BALL RETAINER                            |
| <a href="#">387-10-50</a>    | Guide pin                                |
| <a href="#">411-24-300</a>   |                                          |
| <a href="#">641-32-1000</a>  | ROUNDED NITRIDE CYLINDRICAL HEAD EJECTOR |
| <a href="#">641-7-200</a>    | extractor                                |
| <a href="#">641-8-200</a>    | extractor                                |
| <a href="#">641-10-250</a>   | extractor                                |
| <a href="#">641-8-315</a>    | extractor                                |
| <a href="#">641-14-250</a>   | extractor                                |
| <a href="#">641-10-160</a>   | extractor                                |
| <a href="#">641-8-400</a>    | extractor                                |
| <a href="#">641-32-500</a>   | extractor                                |
| <a href="#">641-32-800</a>   | extractor                                |
| <a href="#">641-6.2-630</a>  | extractor                                |
| <a href="#">1628-16-1000</a> | extractor                                |
| <a href="#">1628-16-800</a>  | extractor                                |
| <a href="#">1628-20-1000</a> | extractor                                |
| <a href="#">1628-20-800</a>  | extractor                                |
| <a href="#">1021-10-32</a>   | Shoulder screw with hexagon socket       |
| <a href="#">1021-6-32</a>    | Shoulder screw 6x32                      |
| <a href="#">1021-16-40</a>   | shoulder screw                           |
| <a href="#">1031-8-20</a>    | Fitting screw M8x20 stainless steel      |
| <a href="#">1005-25-37</a>   | COMPASS-TABLE                            |
| <a href="#">5383-40-30</a>   | BUSH-MOLD                                |
| <a href="#">1601-25-200</a>  | COLUMN-TABLE                             |
| <a href="#">5432-40-200</a>  | COLUMN-MOLD                              |
| <a href="#">711-14.2-100</a> |                                          |
| <a href="#">711-3.4-100</a>  |                                          |
| <a href="#">711-4.7-100</a>  | CYLINDER PUNCH - CONICAL HEAD            |
| <a href="#">711-9.4-100</a>  |                                          |
| <a href="#">356-50-102</a>   | Spring                                   |
| <a href="#">601-12-100</a>   |                                          |
| <a href="#">5741-32-104</a>  |                                          |
| <a href="#">5741-63-127</a>  | Ball cage                                |
| <a href="#">1005-10-16</a>   | .                                        |
| <a href="#">1005-10-23</a>   |                                          |
| <a href="#">1021-5-12</a>    | Shoulder screw                           |
| <a href="#">5741-12-38</a>   | Ball bearing cage                        |
| <a href="#">713-1.5-100</a>  | Punch                                    |
| <a href="#">713-4.8-100</a>  | Punch                                    |
| <a href="#">5431-63-355</a>  | Movement push bars                       |
| <a href="#">5383-63-48</a>   | Movement sliding bush                    |
| <a href="#">1021-10-40</a>   | Hanger screw                             |

| Product                           | Description                          |
|-----------------------------------|--------------------------------------|
| <a href="#">1021-8-90</a>         | Hexagon socket screw                 |
| <a href="#">1007-16-17</a>        | tin                                  |
| <a href="#">712-9-80</a>          | cylindrical head punch               |
| <a href="#">712-3-80</a>          | cylindrical head punch               |
| <a href="#">644-18-200</a>        | ejector                              |
| <a href="#">1021-5-30</a>         | screw                                |
| <a href="#">1052-40-40</a>        | Head guide                           |
| <a href="#">1021-5-60</a>         | Spacer                               |
| <a href="#">601-18-140</a>        |                                      |
| <a href="#">1005-18-32</a>        | Headed Guide Bushes                  |
| <a href="#">5737-50-78</a>        | socket                               |
| <a href="#">5741-50-92</a>        | socket                               |
| <a href="#">5522-4</a>            | holder                               |
| <a href="#">1021-6-25</a>         | Screw                                |
| <a href="#">1021-6-10</a>         | screw                                |
| <a href="#">1021-5-10</a>         | screw                                |
| <a href="#">1021-6-60</a>         | screw                                |
| <a href="#">601-16-100</a>        |                                      |
| <a href="#">601-16-120</a>        | Targeting column                     |
| <a href="#">1071-16-40</a>        |                                      |
| <a href="#">601-18-160</a>        |                                      |
| <a href="#">611-32</a>            | Centering Pad                        |
| <a href="#">5523-40</a>           | clamp                                |
| <a href="#">1052-32-40</a>        |                                      |
| <a href="#">356-12.5-51</a>       |                                      |
| <a href="#">356-20-305</a>        |                                      |
| <a href="#">5741-25-106</a>       | BALL RETAINERS                       |
| <a href="#">355-20-51</a>         | SPRING LIGHT LOAD                    |
| <a href="#">5741-63-168</a>       | ball cage                            |
| <a href="#">357-40-64</a>         |                                      |
| <a href="#">1021-12-40</a>        | SHOULDER BOLT 12.9                   |
| <a href="#">1021-10-12</a>        | Hex Socket Shouldered Screw          |
| <a href="#">1021-6-63</a>         |                                      |
| <a href="#">1031-6-6</a>          | SHOULDER BOLT                        |
| <a href="#">1021-10-110</a>       |                                      |
| <a href="#">1005-10-12.5</a>      | Collared Guide Ring                  |
| <a href="#">1021-10-20</a>        |                                      |
| <a href="#">522-18-20 GR 1017</a> |                                      |
| <a href="#">1021-10-30</a>        | Shoulder screw with hexagon socket   |
| <a href="#">1021-10-60</a>        | Shoulder screw with hexagon socket   |
| <a href="#">1021-6-16</a>         | 12.9 A 6-sided socket shoulder screw |
| <a href="#">1021-6-40</a>         | guide screws                         |
| <a href="#">611-25-M</a>          | Centering Stud Male                  |
| <a href="#">611-25-F</a>          | Centering Plot                       |
| <a href="#">611-16</a>            | Centering Plot                       |

| Product                                 | Description                                 |
|-----------------------------------------|---------------------------------------------|
| <a href="#">108630 (R1628-14.0-315)</a> | Ejector                                     |
| <a href="#">359-50-203</a>              | Ressort hyper fort bronze                   |
| <a href="#">1021-16-140</a>             |                                             |
| <a href="#">1020-36-25</a>              |                                             |
| <a href="#">501-4-12</a>                | DOWEL PIN                                   |
| <a href="#">521-20-120</a>              | EXTRACTABLE DOWEL PIN                       |
| <a href="#">521-20-50</a>               | EXTRACTABLE DOWEL PIN                       |
| <a href="#">521-6-24</a>                | EXTRACTABLE DOWEL PIN                       |
| <a href="#">521-8-20</a>                | EXTRACTABLE DOWEL PIN                       |
| <a href="#">527-10-16</a>               | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-10-22</a>               | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-10-60</a>               | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-12-120</a>              | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-16-100</a>              | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-16-130</a>              | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-16-220</a>              | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-3-12</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-5-70</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-5-90</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-6-18</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-6-22</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">527-8-65</a>                | HEXAGON SOCKET HEAD CAP SCREW               |
| <a href="#">530-3-8</a>                 | HEXAGON SOCKET COUNTERSUNK HEAD CAP SCREW   |
| <a href="#">530-5-12</a>                | HEXAGON SOCKET COUNTERSUNK HEAD CAP SCREW   |
| <a href="#">530-6-12</a>                | HEXAGON SOCKET COUNTERSUNK HEAD CAP SCREW   |
| <a href="#">531-6-40</a>                | HEXAGON SOCKET SET SCREW WITH FLAT POINT    |
| <a href="#">1020-16-16</a>              | LOCKING GRUB SCREW                          |
| <a href="#">1020-20-16</a>              |                                             |
| <a href="#">1020-30-20</a>              |                                             |
| <a href="#">1021-12-160</a>             |                                             |
| <a href="#">1021-8-160</a>              | SHOULDER BOLT                               |
| <a href="#">533-10</a>                  |                                             |
| <a href="#">1021-8-63</a>               |                                             |
| <a href="#">1020-16-20</a>              | LOCKING GRUB SCREW                          |
| <a href="#">521-8-16</a>                |                                             |
| <a href="#">521-6-16</a>                |                                             |
| <a href="#">391-40-40</a>               |                                             |
| <a href="#">1021-8-25</a>               |                                             |
| <a href="#">1005-12-12.5</a>            |                                             |
| <a href="#">1005-32-50</a>              | guide bushing                               |
| <a href="#">1005-12-37</a>              | headed guide bush                           |
| <a href="#">601-12-60</a>               | guide pillar                                |
| <a href="#">664-1.5-100</a>             | EJECTOR PIN HARDENED WITH CYLINDRICAL HEAD  |
| <a href="#">1031-5-30</a>               | STAINLESS STEEL HEXAGONAL SOCKET SCREW      |
| <a href="#">651-32-125-40</a>           | Stepped guide pillar without centering plug |

| Product                        | Description                                    |
|--------------------------------|------------------------------------------------|
| <a href="#">601-25-160</a>     | guide pillar                                   |
| <a href="#">1005-32-32</a>     | Headed guide bush                              |
| <a href="#">601-25-220</a>     | .                                              |
| <a href="#">1005-20-23</a>     | .                                              |
| <a href="#">1021-16-20</a>     | shoulder bolt                                  |
| <a href="#">611-12</a>         | F+M centering stud assembly                    |
| <a href="#">1021-12-140</a>    |                                                |
| <a href="#">601-25-200</a>     |                                                |
| <a href="#">601-25-250</a>     |                                                |
| <a href="#">1005-25-32</a>     | headed guide bush                              |
| <a href="#">1005-25-50</a>     |                                                |
| <a href="#">395-24</a>         | Elastomer stripper                             |
| <a href="#">1005-30-46</a>     | Flanged guide ring                             |
| <a href="#">1052 40-100</a>    | bronze ring with flange                        |
| <a href="#">1021-20-30</a>     | COLLAR SCREW                                   |
| <a href="#">1021-20-32</a>     | COLLAR SCREW                                   |
| <a href="#">1021-6-30</a>      | SHOULDER BOLT 12.9                             |
| <a href="#">1021-8-60</a>      | Hexagon socket shoulder screw                  |
| <a href="#">1021-8-10</a>      |                                                |
| <a href="#">5721-40-250</a>    | Cylindrical column set                         |
| <a href="#">355-10-51</a>      | D10 compression spring                         |
| <a href="#">324-20-152</a>     | D20 compression spring                         |
| <a href="#">356-40-254</a>     | D40 compression spring                         |
| <a href="#">1005-63-100</a>    | guide bush                                     |
| <a href="#">5733-40-48</a>     | guide bush                                     |
| <a href="#">621-63-100-400</a> | guide column                                   |
| <a href="#">5741-40-118</a>    | ball cage                                      |
| <a href="#">1021-16-250</a>    | Shoulderpass screw                             |
| <a href="#">358-25-115</a>     | Extra strong yellow spring                     |
| <a href="#">1031-12-50</a>     | Shoulder Bolts                                 |
| <a href="#">501-5-10</a>       | Cylindrical pin                                |
| <a href="#">1021-10-120</a>    |                                                |
| <a href="#">6804-80-6</a>      | Heating collar                                 |
| <a href="#">1021-10-25</a>     |                                                |
| <a href="#">1021-16-80</a>     |                                                |
| <a href="#">1021-6-20</a>      | Shoulder screw M6                              |
| <a href="#">1021-8-16</a>      | Shoulder screw 6 hollow sides M8 lg. 16        |
| <a href="#">1021-12-12</a>     | SHOULDER BOLT                                  |
| <a href="#">671-25-160-50</a>  |                                                |
| <a href="#">1071-25-80</a>     | FLANGE RING WITH CENTERING PAD FOR 651 AND 671 |
| <a href="#">1051-25-40</a>     |                                                |
| <a href="#">501-4-10</a>       |                                                |
| <a href="#">501-5-30</a>       |                                                |
| <a href="#">1007-16-27</a>     | Smooth guide ring                              |
| <a href="#">521-8-30</a>       |                                                |

| Product                        | Description                                |
|--------------------------------|--------------------------------------------|
| <a href="#">521-10-30</a>      |                                            |
| <a href="#">1021-10-16</a>     |                                            |
| <a href="#">1021-5-40</a>      | Hexagon socket shoulder screw              |
| <a href="#">1021-20-40</a>     | bolt                                       |
| <a href="#">1005-16-16</a>     | Flanged guide ring                         |
| <a href="#">1031-5-10</a>      |                                            |
| <a href="#">601-25-70</a>      | Guide column                               |
| <a href="#">601-25-240</a>     | Guide column                               |
| <a href="#">601-30-100</a>     | Guide column                               |
| <a href="#">601-30-240</a>     | Guide column                               |
| <a href="#">1021-8-40</a>      | 12.9 A 6-sided socket shoulder screw       |
| <a href="#">1051-16-40</a>     |                                            |
| <a href="#">1051-16-50</a>     |                                            |
| <a href="#">671-16-160-40</a>  | Stepped guide column with centering stud   |
| <a href="#">671-16-200-40</a>  |                                            |
| <a href="#">274-2.5-125</a>    |                                            |
| <a href="#">502-4-20</a>       | Stainless Steel Dowel Pin                  |
| <a href="#">523-6-20</a>       | Stainless Steel Extractable Dowel Pin      |
| <a href="#">523-8-30</a>       | Stainless Steel Extractable Dowel Pin      |
| <a href="#">523-16-50</a>      | extractable dowel pin                      |
| <a href="#">5850-50-165</a>    |                                            |
| <a href="#">612-20-180</a>     | Stopped column                             |
| <a href="#">522-18-20</a>      | Tapped centering socket                    |
| <a href="#">1005-16-20</a>     |                                            |
| <a href="#">1021-12-30</a>     | shoulder bolt                              |
| <a href="#">1021-16-30</a>     | shoulder bolt                              |
| <a href="#">1021-16-70</a>     | shoulder bolt                              |
| <a href="#">1021-16-100</a>    | shoulder bolt                              |
| <a href="#">200-1-300-75-4</a> |                                            |
| <a href="#">6802-250-12</a>    | Nozzle body                                |
| <a href="#">6800-250-212</a>   | nozzle                                     |
| <a href="#">992-13</a>         | O-ring                                     |
| <a href="#">527-6-350</a>      | HEX SOCKET SCREW CHC 12.9                  |
| <a href="#">712-14-100</a>     | Cylindrical punch                          |
| <a href="#">1021-8-14</a>      | Shoulder bolt                              |
| <a href="#">671-32-125-50</a>  | SHOULDERED GUIDE COLUMN WITH CENTERING PAD |
| <a href="#">1005-32-46</a>     | GUIDE RING WITH FLANGE                     |
| <a href="#">613-25</a>         | stop tie bar                               |
| <a href="#">612-25-220</a>     | set tie bar with stop                      |
| <a href="#">751-10-100</a>     |                                            |
| <a href="#">521-16-40</a>      | Cylindrical pin with threaded hole         |
| <a href="#">621-50-100-500</a> | STEPPED GUIDE PILLAR                       |
| <a href="#">1021-16-60</a>     | shoulder bolt                              |
| <a href="#">356-40-76</a>      | Blue medium load spring                    |
| <a href="#">1021-16-25</a>     | Shoulder bolt 12.9                         |

| Product                                 | Description                                    |
|-----------------------------------------|------------------------------------------------|
| <a href="#">1021-16-16</a>              | Hexagon socket shoulder screw                  |
| <a href="#">5737-63-98</a>              |                                                |
| <a href="#">5741-32-81</a>              | Ball cage                                      |
| <a href="#">1021-5-16</a>               | SHOULDER BOLT                                  |
| <a href="#">1072-40-160</a>             | guide bushings                                 |
| <a href="#">5411-63-450</a>             | Lower Retainer Column Assembly                 |
| <a href="#">1053-16-22</a>              | Guide ring without centering pin               |
| <a href="#">651-16-80-50</a>            | Shouldered guide column without centering stud |
| <a href="#">612-20-160</a>              | Stop column assembly                           |
| <a href="#">641-8-100</a>               |                                                |
| <a href="#">1061-20-12-25</a>           | Shouldered guide ring                          |
| <a href="#">601-20-220</a>              | Guide column                                   |
| <a href="#">551-16-80</a>               | Smooth centering socket                        |
| <a href="#">551-16-112</a>              | Smooth centering socket                        |
| <a href="#">551-12-71</a>               | Smooth centering socket                        |
| <a href="#">551-25-71</a>               | Smooth centering socket                        |
| <a href="#">551-16-71</a>               | Smooth centering socket                        |
| <a href="#">R1031-8-90 / 151448</a>     | guide screw                                    |
| <a href="#">5721-63-355</a>             | Cylindrical column assembly                    |
| <a href="#">5521-63</a>                 | Square flange for median neck                  |
| <a href="#">5522-5</a>                  | Mounting flange                                |
| <a href="#">5733-63-123</a>             | Short bridle ring set                          |
| <a href="#">5113-70-150</a>             | Steel friction plate                           |
| <a href="#">664-5-250</a>               |                                                |
| <a href="#">5721-40-224</a>             | ESTR COLUMN                                    |
| <a href="#">5733-40-61</a>              | Short flanged guide ring assembly              |
| <a href="#">712-2-80</a>                | punch                                          |
| <a href="#">1007-30-49</a>              |                                                |
| <a href="#">1021-5-20</a>               | LIMITING SCREW                                 |
| <a href="#">356-16-25</a>               | Machine spring                                 |
| <a href="#">390-50X40</a>               | Elastomer spring                               |
| <a href="#">1007-8-17</a>               | smooth guide bush                              |
| <a href="#">5354-16</a>                 |                                                |
| <a href="#">5721-16-140</a>             | set bottom retained pillar                     |
| <a href="#">601-10-60</a>               | guide pillar                                   |
| <a href="#">601-12-90</a>               | Guide pillar                                   |
| <a href="#">402-3.2T-M20X150 female</a> | Coupling ejection male and female              |
| <a href="#">401-3.2T-M20X250 male</a>   | Coupling ejection male and female              |
| <a href="#">671-40-160-63</a>           |                                                |
| <a href="#">1031-5-20</a>               | CALIBRATED TCB SCREW                           |
| <a href="#">1628-4-160</a>              |                                                |
| <a href="#">1628-3-100</a>              |                                                |
| <a href="#">5421-80-400</a>             | COLON                                          |
| <a href="#">356-16-51</a>               | rectangular wire die spring                    |
| <a href="#">1021 8X25 1021-080-025</a>  | screw                                          |

| Product                             | Description                                               |
|-------------------------------------|-----------------------------------------------------------|
| <a href="#">634-12-200</a>          | stainless steel ejector pin                               |
| <a href="#">1007-50-80</a>          | Bushing                                                   |
| <a href="#">521-10-36</a>           | DEOWELL PIN                                               |
| <a href="#">601-14-80</a>           | GUIDE PIN                                                 |
| <a href="#">1005-14-23</a>          | GUIDE BUSHING                                             |
| <a href="#">1005-14-23 12.7X 23</a> | GUIDE BUSHING                                             |
| <a href="#">651-32-100-100</a>      | STEPPED GUIDE PILLAR WITHOUT CENTERING PLUG               |
| <a href="#">1071-32-125</a>         | HEADED GUIDE BUSH WIT CENTERING PLUG FOR 651 AND 671      |
| <a href="#">1061-32-16-32</a>       | SHOULDERED BUSH                                           |
| <a href="#">626-12.5-200</a>        | NITRIDED EJECTOR SLEEVE                                   |
| <a href="#">649-20-4-100</a>        | SPRUE BUSHING WITH DOWEL PIN FIXING                       |
| <a href="#">1021-6X16</a>           |                                                           |
| <a href="#">1021-10-100</a>         | shoulder bolt                                             |
| <a href="#">1031-6-16</a>           |                                                           |
| <a href="#">1021-6-50</a>           | Shoulder Bolt 12.9                                        |
| <a href="#">523-6-24</a>            | Stainless Steel Extractable Dowel Pin                     |
| <a href="#">324-25-203</a>          | RECTANGULAR WIRE DIE SPRING PURPLE COLOUR LIGHT EXTRALOAD |
| <a href="#">1031-10-60</a>          |                                                           |
| <a href="#">711-6-71</a>            | punch                                                     |
| <a href="#">5522-2</a>              | clamp                                                     |
| <a href="#">501-12-20</a>           |                                                           |
| <a href="#">1021-4-14</a>           | shoulder blot                                             |
| <a href="#">634-16-160</a>          |                                                           |
| <a href="#">356-63-76</a>           | Spring                                                    |
| <a href="#">501-16-50</a>           | DOWEL PIN                                                 |
| <a href="#">5411-30-125</a>         | lower retainer column assembly                            |
| <a href="#">5511-30</a>             | HALF-RING                                                 |
| <a href="#">5632-30-AP</a>          | self-lubricating lower base                               |
| <a href="#">387-6-10</a>            | GUIDE SHAFT                                               |
| <a href="#">1031-8-120</a>          |                                                           |
| <a href="#">5184-150-31</a>         | Friction plate                                            |
| <a href="#">501-8-16</a>            | DOWEL PIN                                                 |
| <a href="#">501-8-45</a>            | DOWEL PIN                                                 |
| <a href="#">1021-6-8</a>            | SHOULDER BOLT 12.9                                        |
| <a href="#">521-10-40</a>           | EXTRACTABLE DOWEL PIN                                     |
| <a href="#">1007-25-45</a>          | SMOOTH GUIDE BUSH                                         |
| <a href="#">601-16-90</a>           | GUIDE PILLAR                                              |