




ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Sontheimer

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
10002971 / A2/8ZM/F601	Off switch
A4/11ZM /Z33S	Off switch, 4 poles
NLT25/3VZM/Z33 /X83	On load switch
NLT125/3E/Z33/1/19	Emergency stop switch, 3 pole
NLT20/3ZM/Z20	Emergency stop switch
NS3/32EU1/Z33/SP230V	on — off selector switch
ST031/6ZM / 10000262	Step switch
ST31/11ZM/NS	Tap changer, 3 positions, 1 pole
P/N: 10000166. Type: U1/4ZM/NS/F611	switcher
U1/8ZM	Switch 60 °, 1 pole
U2/8ZM/X70S	
URR1/8ZM	Change-over switch, double-sided return
URR1/8ZM/X85	change-over switch with retreat on both side
URR2/8ZM/Z32/F312	SWITCH
WAB762/32ZM/NS-D1/Z8	Special cam switch / Central mounting with nut (1 hole)
10003275 / WAB911/32E/Z33S/21	selector
NLT16/4VZM/Z20/X83/FR/GB	isolator
WAW883/8ZM /Z32SF/X99	Wahlschalter
WS1/8ZM/F620	Changeover switches 60 °, 1 pole
WS2/8ZM/Z32	toggle switch
HLT 80/3E/Z33	Hauptschalter, 3 polig
10003061 - WAS2010/32VZM/Z33/55	selector switch
ST031/8ZM /Z32	Stufenschalter
A2/8ZM/NS/F601	2-pin off switch
WAF284/N2/11VZM/Z20/X83	selector
NS/D1	Nasengriff schwarz
WS2/12E	Change-over switch, 60°, 2 poles
WAF217/8ZM /Z54/X73	Wahlschalter
NLT125/4V/Z39/4x58/X83	Emergency stop switch
RLT32/3PM-D1/Z33 GB	Reparaturschalter, 3 polig
A4/8E /F601/X70S	Ausschalter, 4 polig
ST031/8E/Z31/X70S	
ST021/8ZM /X70S	Stufenschalter, 2 Stellungen + Nullstellung, 1 polig
U1/11E /X83	Umschalter 60°
WAF306/SORR4/11E /HS/Z53/Z8	Wahlschalter
SEA10/12E /Z16/X83	Pivoting push button

Product	Description
NLT63/4E/Z33/D2/1/4x58/2x62	Emergency stop switch, 4 poles
10005697 U3/8ZM/NS	Umschalter 60°, 3 polig
WAL419/NLT16/4V/Z33/71/X83	Selector
NLT125/4V/Z39	Not-Ausschalter
WS1/8ZM/Z32/F620	Wechselschalter 60°, 1 polig
WAV072/11ZM/NS/X99	selector
A3/11E /Z5/20/X71S/F804	Ausschalter, 3 polig
HLT125/3E/Z33	On load switch, 3 poles
N2/16EU1/Z33 /SP230V	
N3/16EU1/Z33 /SP400V / 10001524	Emergency stop switch
NLT25/3ZM/Z33	Emergency stop switch
X72/SO/D1 /F039	Zusatzschild + Plastikeinlage f. Z33
NLT32/3E/Z33	
A3/8ZM /Z33S	Ausschalter, 3 polig
10000820 - NLT80/3E/Z33	Emergency stop switch, 3 pin / 4-hole mounting
WAM1022/16SM /FG-D1/Z6	
WS1/11ZM/Z32	
WAO821/12E/NS/Z1 / 10011825	Special cam switch
WAW1506/6ZM /X79/85/Z54	Selector
NLT63/3V/Z33	Not-Ausschalter, 3 polig
NLT20/3ZM/Z33 (10002015)	Not-Ausschalter, 3 polig
U1/12E	
ST31/11ZM /Z32SF/X99/X84	Stufenschalter
ST031/11ZM /Z32SF/X99/X84	Stufenschalter
WAM778/20/16E/Z35/6/7/X85/AW/FS	switch
A2/12E /Z20GB/Z30	off switch
WAM432/8ZM/Z32SF/X99 / 10007943	Selector switch/Special cam switch
SEA1/8E /NS	Swivel button
U2/8E /NS	Changeover
R9/16PL M-25/Z33S/Z1/Z36	
R9/16PLM/Z33 S/Z1/Z36	
R6/16GLM /Z33S/Z1/Z36	
A2/8E /NS/X70A	
NLO16/3E/Z33	Emergency stop switch
NLT25/3E/Z33	Emergency stop switch, 3 poles
R9/16PLM/Z33 /3/36/D1	
NLT125/4E/Z33-D2/1/4x58/62	Emergency stop switch, 4 poles, 4-Hole mounting
R9/16PLM/Z33S/1/36/D1	Maintenance switch, 9 poles
A3/8E/Z33RG	Ausschalter, 3 polig
WAE1084/20E	Wahlschalter
NS/D1/Z9	Nose handle black
RLO32/3PM-D1/Z33GB / 10002071	Maintenance switch, 3
WAE2019/11ZM /NS/Z20R-GB/X85	2 POSITIONS SELECTOR
WAA1826/11ZM /Z20/rot-gelb	3 POSITIONS SELECTOR
NLT100/4V /HV11	Not-Ausschalter, 4 polig

Product	Description
NLT63/3V/Z33/45	
NLT125/3E/Z33	
WAB1176/32S	Special cam switch
NLT63/4E/Z33 -D2/Z1/4xZ58	Emergency stop switch, 4-pole
ZM-Antrieb/D0 /Z33	The complete front control including shaft.
WAL193/16S /BS	Wahlschalter
RLT25/3PM-D1/Z33GB	Maintenance switch, 3 poles
WAW1013/8ZM /Z32	Wahlschalter
NLT80/4ZM/Z33	
WAW922/LT80/3V /Z33RG/1/NGG/HV10	
WAS2288/NLO25/4ZM /Z20	
WAE1135/11E/NS/Z16/55/X85	Special cam switch
WAB798/32ZM /NS/-D1	Wahlschalter
WAH663/32E/Z33/55/FR/GB	selector
WAW1506/6ZM/X85/96	selector
NLT100/3V/Z33/44/x83	
WAO689/8ZM /NS/X79/85	
NLT63/4E/Z33/D2/Z1/4xZ58/2xZ62	
URR1/8ZM /Z15	
HLT100/3V /Z33-D2/45/62/HV11	
Z33/D2	
WAM432/8ZM/Z32SF/X99	selector
U4/16ZM	
WAP164/RLT40/6PM-D 2/Z1/33/2xH11	selector switch
U4/16E	Rotary Cam Switch
WAH471/LT20A/4VZM /Z20/X83/FR/GB	
BC09/6ZM/X72	
PN: 10017505 / Type: WAF306/SORR4/16E /HS/Z53	Wahlschalter
ST31/12E /FG/Z3/8/X70S	Stufenschalter, 3 Stellungen, 1 polig
URR1/11E/HS/Z8/16	toggle
NS/D0	Nasengriff schwarz
Nr. 10001835 Type WAB1014/4ZM/Z32/51/X99	Selector Switch
WAF306/SORR4/12E/HS/Z8	
HLT25A/4E/Z33	Hauptschalter
NLT25A/4ZM/Z20	
WAW1492/8ZM /X85	Special cam switch
NLT40/3E/Z20 /1 (3 polig)	Not-Ausschalter, 3 polig
A1/8ZM/F601	
WAH1227/8ZM /X85	
RLT100/3PM-D3/Z33	REPAIR SWITCH
RLT63/3PM-D3/Z33	REPAIR SWITCH
RLT63/6PM-D3/Z33	Maintenance switch
NLT40/3ZM/Z33 /3x58/62	

Product	Description
WAW1013/8ZM/Z32/X85	selector
4552003	Wahlschalter
ZM-Antrieb/D1 /NS	
HLT100/4V/Z35/3/64/X83	
NLT32/3V/Z33/45	Emergency stop switch
N2/8ZM/Z20	
A1/11ZM/NS	Switch with complete actuation
P/N: 10001701, Type: WAW1506/6ZM/Z54/X79/85	selector
HLT32/3E/Z33 /X72	main switch
T2583	Wahlschalter
NLT16/4VZM/Z20 /X83/69	Circuit breaker
WS4/8ZM /NS / 10001775	changeover switch
A1/6E/NS (A422061)	off switch
HV11	auxiliary contact
P/N: 10000392, Type: NLT40/3E/Z20/1	Emergency stop switch
HLO40/3ZM/Z20RS-D1	
WAW668/6ZM /NS/Z11	switch
WAB802/8ZM/Z32/X99	Wahlschalter
WAW1013/8ZM Z32 SF BJ	3 position rotary contact switch
U2/8ZM /NS / 10002738	switcher
NLT80/3ZM/Z33	Not-Ausschalter, 3 polig
HLT16/4E/Z33	Hauptschalter, 4 polig
WAE1199/8PLM /Z33SW/54/X85	selector switch
A1/8ZM /NS/X85 / PN: 10000160	cam switch
U1/4ZM	Changeover switch with zero position
WAB837/32S	Selector
WS1/11V/Z3/X85	changeover switch
ST42/11ZM /Z20S/OV/X99/X84	Switch
ST32/11ZM /Z20S/OV/X99/X84	Switch
WAW825/LT40/3ZM /Z33S/69/F901	selector
NLT125/3E/Z33 (10000822)	Emergency stop switch
ST41/8ZM	sequence switch
NLT25/3ZM/Z33 /62/HE20	
WAN298/NLT16/4VZM/Z20/69/X83	Special on load switch
WS2/20E	
WAH1260/6ZM/Z54/79/X85	selector
ST61/11ZM /NS	Step switch, 6 positions, 1 pole
NLT40/3ZM/Z33	Emergency off switch, 3 poles
WAM1434/NLT20/3ZM /Z20	switch
WAG1132/N3/7ZM /Z20/10/PE	selector switch
WAB857/16ZM /NS/X99	Switch
WAB911/32E/Z33S/21 / 10003275	selector
A2/8ZM /NS	ON/OFF SWITCH 2 POL
R6/16GLM/Z33S/1/HV11 / 10000175	repair switch

Product	Description
WAP162/RLT25/6pm-D2/Z33/1/2xH11	Special on load switch
WAB1739/16ZM /X83	selector switch
ST073/40E /Z35/F101	step switch
WAW937/8ZM/Z32	selector switch
WAHB414/RLT250/3B4 /Z20SW/1/HV11/..	selector switch
ULT125/3V /Z33S-D2/Z45/2xHV11	changeover switch
WAM976/250/16E /Z17/Z20	Wahlschalter
ZM-Antrieb/D0 /Z20	button
WAE1851/11ZM /NS/Z55/X85	Special cam switch
RM251	
ST31/8ZM	
ST31/6ZM	Step switch
WAT295/11ZM/NS/X99	Special cam switch
Z39/D1 (10003551)	Vorhängeschlosssperre mit
30-10+S	Isolators
HLO63/4E/Z33SW/1	main switch
ST36/8ZM/NS	sequence switch
WAH633/32E/Z33	Special cam switch
WAB882/32S	selector switch
WAW1788/HLT20/4E/Z33-D0/1/X82	Maintenance switch
A3/8ZM/Z20GB/FR/F901 (10004999)	
ST31/6ZM/Z32R/X84	sequence switch
WAM778/32E/Z35/Z6/7/X85/AW	Special cam switch
URR1/10ZM/X85	switch
U2/4ZM/NS/F611	switch
RLT16/3PM-D1/Z33/1/69/H11	Maintenance switch
PN12/16ZM/Z14	Pole change switch
WS4/12E	changeover switch
WAA434/12E/F101	Wahlschalter / Special cam switch
NLT20/3E/Z20 / 10006401	Emergency shut-off switch
WAS1923/16E/Z20GB/1	Special cam switch
WAB1264/32E/NS	Special cam switch
ULT125/3V/Z33S-D2/Z45/2xH11 (10006767)	
V3/16E	VOLTAGE SELECTOR SWITCH
R12/63K3/Z35/4xZ36/X85/H11/MS	Maintenance switch, 12 poles
WAB1773/16VZ/NS/Z37/X92	Special cam switch
RLO16/3PM-D1/Z33S/EMV	Maintenance switch, 3 poles
RLO63/3PM-D2/Z33S	Maintenance switch, 3 poles
NLT40/3E/Z33/1/PE	Emergency stop switch
BC4/8ZM	Selector 4 Position
BC5/8ZM	Selector 5 Position
BC6/8ZM	Selector 6 Position
BC8/8ZM	Selector 8 Position
R9/16PLM/Z33S/1/36/D1 (Art 10004387)	Switch

Product	Description
WAB943/32S (10000027)	Special cam switch
WAM1006/126/16E/Z20/X85/AW	Special cam switch, 4-Hole mounting
NLT40/3E/Z20/1 (10000392)	switch
WAB762/32ZM/NS/X99	Special cam switch
ST31/16E	Step switch
N4/40EU1/Z33/SP400V	Emergency stop switch
NLT125/4V/Z39/4x58/62/X83	Emergency stop switch, 4 poles / Base mounting
Z20/D1/Z39GBY	padlockable handle
WAB1650/11ZM/Z20S/X99	Special cam switch BL1934
WAB1667/11ZM/Z20S/X99 / 10008499	Special cam switch
BL1934 (WAB1650/11ZM/Z20S/X99)	Special cam switch
NLT125/4V/Z33/45	Emergency stop switch, 4 poles
NLT25/5E/Z33	Emergency stop switch, 5 poles
NLT20/3E/Z33	Emergency stop switch, 3 poles / 4-Hole mounting
NLO63/3E/Z33/1	Emergency stop switch, 3 poles / 4-Hole mounting
WS3/40E	Wechselschalter, 90°, 3 polig / Change-over
WS3/100E	Wechselschalter, 60°, 3 polig / Change-over
NLT63/3E/Z33/1/19	Emergency stop switch
U6/40PL-D2	Switch
URR2/8ZM/NS/F622	Changeover Selector switch
URR3/8ZM/NS/F622	Changeover Selector switch
ST34/12ZM	Step switch
ST51/8ZM	Step switch
WS2/8E	Changeover switch
WAE1851/11ZM/NS/Z55/X85 (10003362)	
HLO40/3ZM/Z20RS-D1 (Art.- Nr.10002149)	Main switch
RLT80/6PM-D3/Z33S	Repair switch
Nr.: 10004125 Type: WAV072/11ZM/NS/X99	Special cam switch
NLT100/3V/Z33/45/1/19/62/X83	Emergency stop switch, 3 poles
HLT63/6E/Z33/62/2xPE80E	On load switch, 6 poles / 4-Hole mounting
NLT125/3V/Z33/45/19/X83	Emergency stop switch
WAB760/32ZM	Special cam switch
WAB761/32ZM	Special cam switch
HLT125/4E/Z33	switch
R12/40B4H/Z33SW/1/H11/X82	Special on load switch
WAB1330/8VZM/Z20B/GB/X83	PAKO CHARTER HEAD
P/N:10005694; Type:ST61/8ZM/NS	Computator
NLO25/3V/Z33/71	Emergency stop switch, 3 poles
RLT25A/3PLKM-D1/Z33SW/H11 (10003835)	Repair switch
URR1/11E/X83	Change-over switch, double-sided return
WS2/12ZM/Z32	
ST072/16E/Z23	
10004424	toggle switch

Product	Description
VN30/8ZM/NS	Voltmeter - Switches
URR4/8ZM/NS/X85	Switcher
URR4/8ZM/NS/Z15/X85	Switcher
WS6/8ZM/Z32/X73/FKS256	toggle switch
10005198	Special on load switch
LT-FH7001 / WAP162/RLT25/6PM-D2/Z33/1/2xH11	Special on load switch
Nr.10001187 Type WAG1132/N3/7ZM/Z20/10/PE	Selector
HLT80/3ZM/Z20RS/1	On load switch, 3 poles
WAB855/8S/NS-D1	Special cam switch
NLT40/3ZM/Z33 (10000053)	Emergency stop switch, 3 poles
HLT125/3V	On load switch, 3 poles
URR1/16ZM	Switcher, retraction on both sides
WAM441/8ZM/Z6/51/FKS122	Special cam switch
HLT25A/3E/NS	On load switch, 3 poles, 4-Hole mounting
NLT80/3E/Z20/D1/Z1	3-pin emergency stop switch
U1/8ZM/NS/F643	Switcher 60°, 1-pole
ST41/8ZM/NS	Step switch, 4 positions, 1 pole
WS2/11ZM/Z20S/OV/X99	toggle switch
ST022/8ZM/X84/85	Step switch, 2 steps + off position
NLT40/3ZM/Z20	Emergency stop switch, 3 poles
WAB1172/32S	Special cam switch
ST71/11ZM/NS	tap-changers
10001835 / WAB1014/4ZM/Z32/51/X99	Special cam switch
A3/8E/NS/F952	Off switch, 3 pin, 90°
NLT20A/4VZM/FR/Z20/X83-Z9	Emergency stop switch
ST41/8E/Z31/NS	Step switch
RLO25/3PM-D1/Z33GB	3-pin repair switch
URR1/6ZM/NS/X73/FKS123	Change-over switch
ST61/8ZM	Step switch
WS2/8ZM/NS	Change-over switch
WAG935/16PLM/Z33S/1	Special cam switch, enclosed
WAB1418/12ZM/Z16/54/X83 (SEA10X2/12E-R Z16)	Special cam switch
WAI201/12ZM/X83	Special cam switch, Central mounting with nut (1 hole)
WAS1991/LT16/3VZM/Z20/FR/GB/X83	selector switch
Art.Nr.10013242 ST51/4ZM/NS/X84/F638	faucet changers
V30/8ZM/NS (10002985)	Voltmeter change-over switch
ST51/6ZM/NS	Step switch
WAM1276/100E/Z51/X72	Special cam switch, 4-Hole mounting
WAM1275/100E/Z51/X72	Special cam switch, 4-Hole mounting
WAH663/32E/Z33/55/FR/GB / 10000083	Special cam switch
NS3/40EU1/Z33/SP230V	disconnecter
WS2/11E/Z20	SWITCH

Product	Description
ZM-Antrieb/D2/Z33GB	
WAB947/16ZM/NS/X99	Special cam switch
WAK464/NLT16/4V/Z20/71/X83 (10003482)	Special on load switch
WAB758/32ZM	cam switch
WAB1303/NLT16/3ZM/Z20	Special on load switch
NLT40/3E/Z33	
10010222 - WAK438/NLT16/4VZM/Z20/X83	selector
5640300061 (WAM976/250/16E/Z17/20)	Special cam switch
WAB943/32S	Special cam switch
NLT20/4ZM/Z20	Emergency stop switch, 4 poles
10002648	selector
WAB762/32ZM/NS	selector switch/custom cam switch
10000709	Voltmeter
NLT63/4ZM/Z33/X72/F803	Pako switch
WAB814/8S/NS-D1	Selector switch
ST32/8E/NS/X84/F611	Step switch
WAW1506/6ZM/Z54/X79/85	Special cam switch
WAE1146/11ZM/NS/Z55/X85	selector
HLT180/3E/Z20	main switch
V3/8ZM	Voltmeter - switch
URR1/16E	transitional
U4/6ZM/NS	transitional
WAB1393/LT25A/4V/PE	selector
WOC085/8E/Z20/1/19	selector
A3/16E-R DS (WAB731/16ZM/X83)	ZM drive
WAB947/16ZM/NS/X99/92	selector
WAB1214/11E/Z20-D1RG/19/55	selector switch
p/n: 10000281 type: WAK472/8PLM/Z33SW/54/X85	Special cam switch
WAI087/11V/Z6	selector
P/N: 10000027, Type: WAB943/32S	selector
P/N: 10003234, Type: WAM441/6ZM/NS/Z51	selector
P/N: 10004406, Type: NLT180/3E/Z20/62	Emergency stop switch
P/N: 10000138, Type: RLT25/3PM-D1/Z33/H11	repair switch
P/N: 10005202, Type: A2/8ZM/NS/F910	off switch
P/N: 10002272, Type: ST31/11ZM/NS	tap changer
P/N: 10000416, Type: ST41/11ZM/NS	tap changer
P/N: 10002268, Type: ST51/11ZM/NS	tap changer
P/N: 10002112, Type: ST61/11ZM/NS	tap changer
P/N: 10015232, Type: WAB18328/11ZM/Z20GB	selector switch
P/N: 10015233, Type: WAB18329/11ZM/Z20GB	selector switch

Product	Description
P/N: 10015234, Type: WAB1830/11ZM/Z20GB/51	selector switch
P/N:10000016, Type: NLT20/4ZM/Z20	Emergency stop switch
P/N: 10015208, Type: RLT63/8B2/Z33S/HV11	repair switch
P/N: 10015209, Type: RLT25/8B1/Z33S/HV11	repair switch
P/N: 10015201, Type: WAB1578/32ZM/NS-D1/Z15/X99	selector
P/N: 10005234, Type: WAB761/32ZM	selector switch
P/N: 10004741, Type: Z20/D1/Z39GB	handle lock
TL.0130	
P/N: 10003551, Type: Z39/D1	padlock lock with door lock
P/N: 10012966, Type: NLT20A/4VZM/Z20/X83/FR/GB	Emergency stop switch
P/N: 10004125, Type: WAV072/11ZM/NS/X99	selector switch
P/N: 10002805, Type: WAM778/40E/Z35/Z6/X85/AW	selector switch
P/N: 10015311, Type: NLT25/3E/Z20/1	Emergency stop switch
WAM778/32E/Z35/6/7/X85/AW	selector
P/N: 10001610, Type: WAL419/NLT16/4V/Z33/71/X83	selector switch
10015440 / Type: NLT63/4V/Z39/4x58/62/X83	Emergency stop switch
P/N: 10002717, Type: NLT40/3E/Z20	Emergency stop switch
P/N: 10011019, Type: Z20/D0/S	handle lock
NLT16/4ZM/Z33	Emergency stop switch
P/N: 10015491, Type: A3/7ZM/F601	off switch
WAB897/8E/NS-D1/Z2	Special cam switch
P/N: 10015376, Type: WOC/A3/8ZM/Z32/F915	off switch
HLT20A/3E/Z20/10 / 10001932	main key
P/N: 10002233, Type: WAP250/RLT25/3B1/Z33S/H11	Special on load switch
P/N: 10001122, Type: WAM1432/NLT20/4ZM/Z20	selector
NLT20/4T/Z20	Emergency stop switch
WAW937/8ZM/Z32/X73	selector
P/N: 10015886, Type: ST32/11ZM/Z20S/X84/99/F641	tap-changers
W3/16E/NS	Reversing switch
P/N: 10000305, Type: NLT32/3ZM/Z33	Emergency stop switch
P/N: 10010220, Type: WOC150/8E/NS/Z1/51/X92	selector
NLT20/3ZM/Z33/X72/F033	Emergency switch
P/N: 10002155, Type: WAB761/32ZM/NS/X99	Special cam switch

Product	Description
P/N: 10005918, Type: N3/11VZM/Z33/X83	Emergency stop switch
WAE1080/11V	Switch
NLT63/3E/Z33/1	Emergency stop switch
NLT25A/4E/Z33-D0	
A2/11E/FS/F601	off switch
U1/11E/NS	switcher
U2/11ZM/Z32	switcher
10003971 - WAB802/8ZM/Z32/X99	Selector switch
NLT16/4V/Z33/Z45 / 10000931	Emergency stop switch
NLT40/4V/Z33/Z45 / 10000937	Emergency stop switch
A3/32E X84	off switch
SO6/16EFGZ31SFZ60	selector
A3/6ZM/Z20/X70GB	off switch
10006964	selector
10015970	switcher
10015969	switcher
WEA1147/8ZM/X85	selector
10008220	changeover switch
10003061	selector
WAS2911/32ZM/X82	selector
WAS2910/32ZM/X82	selector
10016253	
WAM1708/LT40/3V/N/PE/H11	selector
WAS1812/7E // 10005674	selector
10002630	Selector switch
10016695	Selector switch
10002112	Selector switch
WAD357/N2/16EU1/Z33/SP230V	Switch
A4/16E	off switch
10004990	changeover switch
10016894	selector
10004179 / NLT16/4VZM/Z20/X83/FR/GB	isolator
WAB481/6ZM/Z32/F101	3-position switch
WAB1667/11ZM/Z20S/X99 / BL1933/11ZM/Z20S/X99	
10001122	selector switch
U2/8ZM / 10000037	switcher
WAS2010/32VZM/Z33/55	hoist
WAB1667/11ZM/Z20S/X99	Special cam switch
A3/8E Z33S	
10017301	TRIANGLE STAR SWITCH
WAF284/N2/11VZM/Z20/X83 / 10002326	selector switch
WS1/12E	
NLT125/4E/Z33	
A1/8ZM/NS/F601 / 10000009	switch

Product	Description
10017452	swivel switch
10013642	
10002447	
10001284	selector switch
10001610	selector switch
NLT40/3E/Z33-D0/1	Emergency stop switch, 3 poles
10004387 / R9/16PLM/Z1/33S/36/D1	
A3/126E/A4/16E/Z33S/1/41	
A3/126E/A4/63E/Z33S/1	
WAG1046/NLT20/3ZM/Z20	Central hole mounting
10000083	Special cam switch
10017494	Special cam switch
10017760	selector
WAP164/RLT40/6PM-D2/Z33/1/2xH11	selector
WAM347/6ZM/NS/Z51/X85 / 10013634	selector
10001207	Selector switch
WAB1014/4ZM/Z32/51/X99 / 10001835	selector
10001427	selector
10003229	Step shifter
LO32/3V/Z91	
WAM1628/NLT20/4ZM/Z20	selector
WAB884/32S / 10001207	selector
10000207	Inverter key
WAB837/32S / Wahlschalter	selector
10003314	ZM drive/d0/z20gb
HLT63/3ZM/Z33	main switch
10001701	Special cam switch
10001699	Special cam switch
WAB1042/11ZM/NS/Z55/Z18 / 10013642	selector
10007931	
10001494	
10002941	Step switch
RLT32/4PM-D2/Z33 GB / 10015788	repair switch
WAW1013/8ZM/Z32/X85 / 10000434	selector
NLT40/3E/Z33/1 (10000187)	Emergency stop switch
ST32/11ZM/Z20S/oV/X99	Step switch
WAB762/11ZM/NS/Z8 / 10018519	selector
WAB436/12E/Z19/54/59/X70S/73/SO / 10004308	selector
WAG1289/N3/8ZM/Z20/PE / 10001427	selector
A3/11ZM/NS/Z8 / 10005490	Off switch
WAB884/32S	selector
RLT16/4PM-D1/Z33GB / 10000501	repair switch
WAB1653/12ZM/NS/Z16/55 / 10017494	selector
WOC/ST42/8ZM/NS / 10010855	Step switch

Product	Description
WA-SON/WS3/8ZM/NS	changeover switch
WA-SON/A2/8ZM/NS	Off switch
NLT80/3ZM/Z33 / 10000736	Emergency shut-off switch
URR2/8ZM/NS/F312	Changeover Selector Switchwith OFF and spring return to centre, 2 pole, 30deg switch Square front panel 48x48m, OPEN - 0 - CLOSE
URR3/8ZM/NS/F312	Toggle switch with spring return
WS6/8ZM/Z32	Changeover switch
N4/8ZM/Z20/PE19C	Emergency stop switch, 4 poles
N4/8ZM/Z20/PE	Emergency stop switch, 4 poles
HE10-40-04T HE104004T	Auxiliary contact
NLT63/3V/Z33/45/19/1/X83	Emergency stop switch, 3 poles/Emergency stop switch, 3 poles
WAB911/16E/Z33S/21R	selector
NLT20A/4VZM/Z20/1/X83	Emergency stop switch, 4 poles/Emergency stop switch, 4 poles
WS2/11VZ/NS	
ST41/8ZM/X70S	Stufenschalter, 4 Stellungen, 1 polig / Step switch, 4 positions, 1 pole
WAN359/NLT16/4VZM/Z2035Z	
NLT250/3E/Z20/1	Emergency stop switch, 3 poles
Z20/D2/GB	padlockable handle
WAN359/NLT16/4VZM/Z20/69/X83	Selector switch
HLT125/3V/Z33/44/X72/F803	Main switch, 3 pin/On load switch, 3 pole ground mount/Base mounting
HLT125/3V/Z33/44/X72/83/F803	Main switch, 3 poles/On load switch, 3 poles
ZM-Antrieb/D0/Z20GB	Drive for ZM-Fastening/Gear for One Hole Mounting
WAH1260/6ZM/Z54/X79/85	Special cam switch
WOC/A2/8ZM/NS	
ST51/6ZM	
URR1/8ZM/NS	
A2/40E // 10005182	
Z33/D1/GB	padlock round
WS1/8ZM/F622	
URR1/8ZM/F312	selector switch
HLT20/3ZM/Z33	
10010495 - NLT63/4E/Z33/D2/1	Emergency stop switch
HLT25/4ZM/Z33S/NVG40E	
WAE1843/11ZM/NS/Z55	
WAM441/6ZM/NS/Z51	Selector
NLT80/4V/Z33/45/1/X83	
SA2/12ZM/Z16	
WAR488/NLT20/4ZM/Z20	
WP12/6E	Reversible pin count switch
NLT20/2ZM/Z33	Emergency stop switch, 2-pin
10003373 / SEA10/12ZM/Z59	swivel switch
RLT16/3PM-D1/Z33/71/H11 / 10020307	repair switch
RLT25/3PM-D1/Z33/71/H11 / 10020308	repair switch
RLT25/3PM-D1/Z33/71/H11/EMV / 10020309	repair switch

Product	Description
RLT40/3PM-D2/Z33/71/H11 / 10020310	repair switch
RLT40/3PM-D2/Z33/71/H11/EMV / 10020311	repair switch
RLT63/3PM-D3/Z33/Z1/71/H11/EMV / 10020312	repair switch
NLT20/3E/Z20	3-pin emergency stop switch
10015405 / A4/16E	switch
HP2/11E/Z19	Auxiliary phase switch
10011120 / WA-SON/WS2/32ZM/NS	2-way switch
WAB911/32E/Z33S/21	
A2/8ZM/F601	
HLT25A/3E/Z33	
U1/8ZM/X70S	3-position switch for motor control
WAF402/NLO16/3V/Z20/75/X83	
WS2/11ZM/Z20/F101	
ST32/11ZM/Z20/F101	
NLT125/4V/Z39/4x58/62 / 10012615	Emergency stop switch
U2/7ZM	
10000175 R6/16GLM/Z33S/1/HV11	switch
WA-SON/ST42/8ZM/NS	
WS3/7ZM	
N2/13ZM/Z20B/1	
A3/6ZM/NS / 10004801	off switch
NLO40/3E/Z33	
NLT40/3V/Z33/45/1	
H11	
NLT25/6E/Z33	
P12/20E/KS/Z60/X83/84	
WAK464/NLT16/4V	
URR1/8ZM/NS/X73/FKS123	switch
URR1/6ZM/NS/FKS123	switch
10007947	ROTARY SWITCH
10002738	
10000003 / WAP165/RLT63A/6PM-D3/Z1/33/2xH11	Switch
WAW229/8ZM/NS	
NLT20/3ZM/Z33/X72	
WAM347/8ZM/Z6/51/NS/FKS122	
WAM347/6ZM/Z6/51/NS/FKS124	
10002015 NLT20/3ZM/Z33	
WAM551/20S/Z60/X82/FR-D1	2-position switch
10007217 / HLO40/4T/Z20/X101/74E/F908	main switch
10002531	Switch
10000824 - NLT250/3E/Z20	
WAG935/16PLM/Z33S/1 / 10000377	

Product	Description
NLT25/3ZM/Z33 / 10000400	Emergency stop switch
NLT125/3V/Z33/44/X72	
WAP142/RLT125/6PM-D3/Z33/1/2xH11 / 10000714	selector
WAP163/RLT25/6PM-D2/Z1/33/2xH11	selector
WAP165/RLT63A/6PM-D3/Z1/33/2xH11	selector
WAM482/6ZM/NS/Z6/51/X73 / 10003974	selector
NLT40/4E/Z33 / 10000373	
WAS2937/NLT125/4V/Z39/1/4x58/2x62/X83	door couple
ST34/8ZM/Z32/X84	Control Switch
WAU075/11E/Z11/19 / 10006619	selector
WS1/8ZM/Z32	
RL025/3PM-D1/Z33GN/71/H11	
WAF495/HLO16/3V/Z20/75/X83/IP67	
R9/16PLM/Z33S/1/36/D1 / 10004387	repair switch
Z39/D1/GB	
WAB1176/32S / 10001494	selector
ST053/32E	
WAO2235/HLT125/4E/Z33SW / 10001566	selector
WAM347/6ZM/NS/Z51	
NLT40/32M/Z33	Emergency stop switch
HE11 / PN: 10000115	
W3/32ZM/Z15/60	
ST041/8ZM/NS/Z2	
NLT100/3v/z33/4 5/1 / 1330621	Emergency stop switch
10008499 / WAB1667/11ZM/Z20S/X99	
WAB871/32ZM/NS-D1/X99	
NLT40/4V/Z33/45	
HLT32/3ZM/Z33/F R / 10008527	main switch
WAK436/NLT16/4VZM/Z20/X83 / 10005507	selector
URR1/8ZM/Z6/NS/FKS123	
10004704 WAJ545/8ZM/NS	selector
NLT16/4V/Z33/45	
PN: 10001773 / WAB759/32ZM/NS	Selector switch
WAT247/12ZM/NR/Z6/X99	switch
PN: 10008777 / WA-SON1237/8ZM/NS	selector
A3/32E/Z33S/1/F915	
NLT125/3V/Z33/67	switch
NLT16/4E/Z33/PE / 10001987	Emergency switch
NLT63/4E/Z33/D2/1/4x58/2x62 / 10012829	Disconnecter wrench
NLT63/3ZM/Z33/8 / PN: 10003527	Emergency stop switch
NLT25/3V/Z33/45	
HLT40/3ZM/Z20/TL.0511S	main switch
U3/8ZM/X70S	rotary switch
HLT40/3E/Z33/X72/F803	

Product	Description
WOC086/8E/Z20/1/19	
NLT40/32M/Z23	
ST81/6ZM / PN: 10004616	Rotary cam switches
ST053/20E / 10004236	
BC011/8E / 10005339	coding switch
10006510 WA-SON1007/7SM	
10005666 WAE769/8ZM/NS/X85	
10021483 RLT80/3PM-D2/Z33GB/71/H11	
10000110 A1/6ZM/NS	Control switch
10002182 U1/6ZM/NS	Control switch
10012185 ST031/6ZM/X84/F403	Control switch
10008103 WOC086/8E/Z20/1/19	
NLO16/3V/Z20/71	SWITCH
NVGO16V/Z62	AUXILIARY CONTACT
A4/32ZM / 10006151	Off switch
WAS1991/LT16/3VZM/Z20/NR/GB/X83	Special on load switch
ST34/8E / 10012126	step switch
NLT40/3E/Z20-D0/1/X83	
HLT25/3E/Z33	
HLO25/3V/Z20/71	main switch
NLT125/4E/Z33-D2/1/4x58	Switch
10002573 NLT16/3ZM/Z20	
WAM970/40/16E/Z7/X85	
10007183 WAB1772/8VZ/NS	selector
10001187/WAG1132/N3/7ZM/Z20/10/PE	Special cam switch
WAB883/32S	selector
N3/13E/Z33/1/30/59	SWITCH
WA-SON2127/32ZM	switch for rotating oven
ST024/12ZM/NS/Z11/X84	selector switch
NS3/32EU1/Z33/63/SP230V	
10013970 / NLT63/3V/Z33/45ZM	
NLT63/3V/Z33/45ZM/X83 / 10001691	Emergency stop switch
10025136	Handle
10000372 / NLT32/4E/Z33	breaker
10002264 HLT40/3E/Z33/X72/F803	Disconnecter
10005507 WAK436/NLT16/4VZM/Z20/X83	disconnecter
A2/6E/NR/X70GB / 10009441	Off switch
10000282	
WAS1991/LT16/3VZM/Z20/NR/GB/X83	
WAB2080/11E/NS/Z31/X85	
R6/40+1/16 PL Z1/33/36 CL / 10007519	repair switch
HLT180/4E/Z20 / 10000917	main switch
WAH663/32E/Z33GB/55	Special cam switch
BC07/4E/NS/X85	
10012829 NLT63/4E/Z33/D2/1/4x58/2x62	

Product	Description
NLO32/3E/Z33 / 10001103	Emergency stop switch
10004704	
10025476 / A3/11ZM/Z33RS	Off switch
WAI214/11ZM/Z32	
RLT25/6PM-D2/Z33/HV11 / 10001409	repair switch
HLT25/3E/Z33SW/1	main switch
SA2/10E / 10025572	swivel button
WAW828/11E/Z8	
W3/32E / AN25100768	reversible switch
Z20/D2/L/Rot	Grip lock
10000492 / WAB1418/12ZM/Z16/54/X83	selector
HLT16/3V/Z33/44/HV 11 / PN: 10014485	main switch
Z45/D1 / PN: 10013034	Door coupling with door lock
WAA559/NLT250/8V/Z20/65/1/H11/X83	
NLT63/4E/Z33/1/8/4xZ58/62	
WAM524/12FR/Z6 DG	
A3/63E/A2/16E/Z41/63/X70S/83 / 10004625	Off switch
WP12/8E/NG/X70S	reversible pole switch
10016590	Emergency stop switch
WA-SON/WS2/8ZM/NS/oV	
WAF472/NLO16/3V/Z20/75/X83 / 10002488	selector
NVGO16V / 10001352	Neutral conductor leading forward for LO
10003705 / WAM347/6ZM/NS/Z51	selector
10000221 / A1/8ZM/F601	2-POSITION SWITCH
10025932 / U2/8ZM/NS/F601	switcher
10007353 / U1/8ZM/F611	2-POSITION SWITCH
WS4/8ZM/NS / WS4/8ZM/NS	changeover switch
HLO40/6E/Z33 / 10001216	main switch
V30/6T	
WAB1824/11E/NS/Z8/53	selector
NS3/40EU1/Z33/SP230V/Z63	Emergency stop switch
NLO32/3V/Z33/71 / 10001243	Emergency stop switch
HLT63A/3V/Z33SW/71/1/62 / PN: 10016108	main switch
ST31/8E/Z31/X84 / 10011676	step switch
A4/8ZM/Z20R/59/X70GB / 10004901	Off switch
10000502 HV11	
A1/8T	Switch selector
10000645 / ST41/6ZM/NS/X99	4-position switch
HLT80/3V/Z33/45/3	
P12/8E/NS/Z19 ART.NR.: 10024763	
RLT20A/3PM-D1/Z33/1/2x14/2x36/H10/H11	Repair switch
V30/8ZM/BS/Z6 / 10026641	Voltmeter - Switch
AU31/8ZM/BS/Z6 / 10026642	ammeter switcher
10025572 / SA2/10E	Stop-Start switch
NLT63/3ZM/Z33	Emergency stop switch

Product	Description
NLO25/3V/Z33/44/1/62/X83 / 10026754	Emergency stop switch
10003020	switch
10001538	key
HLT20/3E/Z20/10 / PN: 10002642	Switch
10004525	repair switch
WA-SON7318/8ZM/NS / 10017195	selector
10000860 NLT25/3V/Z33/45	main switch
U4/32V/Z33GB/71/2xZ15/X83 / 10026861	switcher
WA-SON/A6/32ZM/NS / 10012735	Off switch
WAB790/8ZM/Z32 / 10000508	Selector switch
ARU1/12V	
R6/8PM/Z33GB/HV11 / 10010417	Repair switch
RLO16/3PM-D1/Z33/H11	SWITCH DISCONNECTOR
10009945 A4/8E/NS	