







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
<u>1434WA</u>	Sensor Board WAV15x Sensors
<u>16644WA</u>	Service Kit for Wind Sensors
HMT310 5A5A1BCX14BJAA1A2	Premium sensor
DMT143-G1C1A1A0A0ASA	
<u>DMT348</u>	Transmissor
DRD11A	Precipitation Detector
DRW010281SP	Metal Coated PPS Grid Filter with Stainless Steel Mesh, Female Thread
<u>GM45237SP</u>	Protective Sleeve for GMP222
GMP222 (B0N0 CO2 PROBE)	
P/N: HM70, Type: B1B1A0AA	Portable humidity and temperature meter
HMP155E1AA11A0B2A1B0A	Humidity and temperature sensor
HMT330 3E0A001BCAB200A0CAABAA1	Humidity and temperature sensor
<u>HMT120 TD0AXA11A2A0Z</u>	Humidity and temperature transmitter
HMT120 KB1A1B12A1Z0Z	Humidity and Temperature Transmitter, ±1.5 %RH, 420 mA
HMT330 3E0B141BCAD100A0AAAAAA1	Humidity and temperature transmitter
HMT360 1D22BCE1A2BA5A10	SENSOR
MM70F1A1A5A1A0A2B0	Handheld Moisture and Temperature Meter
PTB330 A1AAHAAPEB0A0B	digital barometer
PTU30011801A1BCAF1A4A1FAE0B0A	Pressure, Humidity and Temperature Transmitter
PTU300 12A01C1BCPF1A0A1BAB0B0A	(Pressure, humidity andMeasured temperature transmitter)
PWD Weather/visibility sensor	Visibility sensor
<u>WAA151</u>	Windgeschwindigkeitssensor WAA151
<u>WSP150</u>	Surge Protector no Connectors
<u>ZZ45036</u>	sensor cable
<u>ZZ45037</u>	sensor cable
<u>ZZ45048</u>	Signal cable 16 x 0.25 mm2
HMT330 -340B101CHAH100A01ACBAA1	TEMPERATURE TRANSMITTER
GMW93R	CO2+RH+T transmitter Voltage output
GMW94R	CO2+RH+T transmitter Current output
<u>219690</u>	USB cable
HUMICAP180R	Humidity sensor
<u>QMT110</u>	Ground Temperature Sensor
HMT 330 340A021CBAX100A01ACBAA1	Temperature Sensor
HM70A0C1A0AA	Humidity and Temperature Probe
HMD60U	Humidity Transmitter





Product	Description
DM70F5B1A3B1	Hand-held Dewpoint and Temperature Meter set with carrying case for Desiccant Dryers
DM70F5A1A3B1	Hand-held Dewpoint and Temperature Meter
<u>HMT360 4D22HHK1A2BE5A3K</u>	Measuring device for humidity and temperature
HMT330 1A0A121BCAB100A0AAABAA1	Feuchte und Temperaturmesswertgeber
POWER-1	External power supply module
HMT330 1A0A101BCAB100A11AABAA1	Feuchte und Temperaturmesswertgeber
WXT530 2C1B2A3D1B1B	Weather Transmitter
WXT530 6C1B2A3D2B1B	air sensor
<u>CLT321SP</u>	Transmitter Spare Part
PDT101-P4C	Differential Pressure Transmitter
<u>WXT520 AAD1BE31B0</u>	Weather Transmitter
<u>16644WA</u>	Service Kit
<u>WXT520-AAB1BC10B0</u>	Wettermesswertgeber
HM70D0A1A0DE	Portables Feuchte- und Temperaturmessgerät
<u>HMP235 – E2A1A1AA32A1A3B</u>	Dewpoint sensor
<u>HMT335</u>	
GMT222 G0A1B0NXA0A	CO2 Transmitter
WXT530 6C4B1A2B2B1B	
QML201C	AWS Logger MAWS
WXT536 / WXT5306B1B1A1A1A1B	Weather Transmitter
<u>HMT331</u>	Raumfühler zur Wandmontage
HUMICAP180L2	Feuchtesensor
<u>HM42</u>	Handheld Humidity and Temperature Meter with HM42PROBE
DMT340 6R0K1A111A1A001E2D6K0C0	Dry Sensor
<u>HMP110 V00C2C1A0</u>	
<u>HMT120 (KA1A1B12A1A0Z)</u>	
<u>HMP155 A2GB13A0A2A1A0A</u>	Humidity and temperature probe
HMT330 / 8X0B101BCAD100A0ADNGAA1	Humidity and Temperature Meter
<u>DMT152A1CBB10A010A1A</u>	Taupunktmesswertgeber
<u>GMM222</u>	
HMT330	Transmitter
MMT330 8W0F145QCAL100A02DMBAA1	Moisture and Temperature Transmitter for Oil
AQT420	Air Quality Transmitter for Pollutant Gases and Particulate Matter
HMT330 5N0B001GCAF100A01CGBAA1	Feuchte und Temperaturmesswertgeber
HMT315 // 5A5A1BCX14BH1A1A2	
AQT420 (10 pcs)	
226068	
WXTPTUSP	PTU-Module Spare Part for the WXT530 series.
<u>212792</u>	Ultrasonic Wind Sensor
DMT143 G1C1B1A3A0ASX	Miniature Dew Point Transmitter
HM70F4A1A0DB	
HMT330 3E0B101XCAX100A0AAACAA1	Humidity and temperature transducers
MMT330 8V0F101CQAE100A02DNBAA1	Moisture and Temperature Transmitter
<u>HMP110C15A0C3A0</u>	





Product	Description
DMT143 N1C1B1A3A0ASX	•
WAC155CB	Component Board
4H0B001BCAK100A0ACEBAA1 (HMT330)	Premium transmitter for humidity and temperature with metal housing
MMT330 2D0F121CQQC123A32DABAA1	Transducers for oil humidity and temperature with cable probes
HMP46	Thermohygrometer
GM P 22 2 B 0 N 0	e.iiie.iijg.e.iiie.ie.
HMT360	HumudityTempTransmitter
HMP155 A4JC11A0A0A1A0A	, and any company control of the con
WSP152	
HMT330 7S1D001GXCX103A0DAABAA1	Humidity and temperature sensor
WXT530 6A1A1A1A1B	Weather transmitter
8V0F121CPQL143C12E3BBA1	
GMP222G0N0	
WA15D7B	Wind sensor component set
219687	Connection Cable
<u>WM30 C1BA</u>	Connection Capit
15778HM	
PDT102-P2V	
HMT120 (KC0A1F12A2A0Z)	
DM70 / B0B1A3B1	Hand-Held Dewpoint Meter
DM70 A0B0A0A0	Portable dew point meter
DMT143L1CAA1A010ASX	DMT143 Transmitter
DMT143R1CAAFA011ASX	DMT143 Transmitter for Low Dewpoint
HMS82W	Bill 1 to Transmitter for Low Bompoint
HMD62	Temperature Transmitter
HM70A0E1A0AA	probe
DMT143 G1C1A1A3A0ASX	Miniature Dew Point Transmitter
DTR503A	Radiation Shield
HMP155 /A2JB11A0A0A1A0A	Humidity and temperature probe
Rosa DR322SYS	weather station with data logger
DRS511AB15	Road and runway surface with a cable
DTS12G3	Ground/Soil temperature probe
WA15	Wind set
DMT143 N1C2D1X4S0ASX	Transmitter for Low Dewpoint
HPP272 AB0B0N	Hydrogen Peroxide, Humidity and Temperature Probe
PTB330TS-SYSTEM	Digital Barometer
WXT530 6C1B1A3D1B1B	Weather Transmitter WXT530 Series
PTB330 B1AEJAACEB0A0B	Digital Barometer
HMP110A15A1C3B0	Probe
HMP60	Sensor
MMT330 (7S0F141QCAL100C02EKBAA1)	Moisture in Oil and Temperature Transmitter with Remote Probes
HM47280SP	Filter
HMT330 3E0B101XCAG100A0AACBAA1	Premium Humidity and Temperature Transmitter with metal enclosure
HMP360 3B5A1B2	Humidity and Temperature Probe
PTB210 A1B3B	Outdoor Barometer with RS232, RS485, 0-5 or 0-2.5V outpu
<u> </u>	





Product	Description
SPH210	static pressure head
SPH20	Static Pressure Head Heated
HMT310 FC5A1NRA17CRGG1B2	Humidity and Temperature Transmitter
HMT330 1A0B001BCAF100A0AAABAA1	Humidity and Temperature Transmitter
HMT330 3E0B101BCAC100G0AAABAA1	Humidity and Temperature Transmitter with Remote Probe
DMT340 6R0K1C121A1A001A2D6K4C0	Dew point and temperature transmitter
HMP60 A12A0A2B0	INTERCAP Humidity and Temperature Probe
HMP9	Compact Humidity and Temperature Probe
HMP360 1A5A1A4	Humidity and Temperature Transmitter
HMT360 1A22BCA2A4BA5A10	Humidity and Temperature Transmitter
CLB311-230SP	Window Blower
DRW010276SP	Sensor protective grid
HMT330 3E0B015BCAG100A0ACABAA1	Premium Humidity and Temperature Transmitter
HMP155 A4BG11A0A1A0A	HMP Humidity/Temperature Probe
	· · · · · · · · · · · · · · · · · · ·
HMT330 3G0B111DCAF100A0ACCBAA1	Feuchte und Temperaturmesswertgeber
HMT318 (8A5A1BCJ14BSAC1M2)	Premium Humidity and Temperature Transmitter
GMP251 A2B0C1C1	Carbon Dioxide Probe, GMP251 CO2 series
GMP251 A2B0C1C1	Carbon Dioxide Probe GMP251,CO2
WXT530 6C1B2A1D1B1B	weather sensor
1A22BCA1B2BA5A10 (HMT360)	Messgerät für Feuchte und Temperatur
212483	EX food separator
<u>210664</u>	Sicherheitsbarriere
<u>214101</u>	
JUNCTIONBOX-8	Junctionbox-8 Junction Box With 8-contacts Klemens
<u>WXT530, Order code : 6B1B1A3B2B1B</u>	WXT530 series weather sensor
<u>WAC151</u>	Sensor support arm including terminal box WAC151
HMP360 325A104	Humidity and temperature transmitters
HMT 360 3A22BCD1A4B25A10	Humidaity and Temperature Transmitter
<u>DSC211</u>	Remote Road Sensor
<u>HMT 140</u>	Data Logger
<u>GMP343</u>	Junction Box with 8 contacts
GMD20	Transmitter
HMT360 (p/n 1A22BCA1B2BA5A10)	Humidity and Temperature transmitter with Sensor Probes
PTU300-11A01A0AAAA1A4ABAE0B3A	Pressure, Humidity and Temperature Transmitter
<u>MI70F10</u>	Measurement Indicator MI70
<u>PTB330</u>	Digital Barometer
HMP155 // A2AB12A4A4A1D0A	Humidity & Temp Probe
<u>DM70 B5A1A3B1</u>	Portable dew point meter
PTU 303 (32D01A1BCPB1A0A1B1B0B0A)	Pressure, humidity and temperature transmitter
HMT330 (340A141BCAD100A0CAABAA1)	Humidity and temperature transducers
DM70 B5A0A4B1	Handheld Dewpoint Meter for Spot-Checking Applications
<u>HM70 B4A1A0DB</u>	Portable Humidity and Temperature Meter
HMD65	Humidity and temperature sensors
7S1D021XCAB200A0EAQBAA1	Premium Humidity and Temperature Transmitter
HM70 B0D1A0AB	Handheld Humidity and Temperature Meter





Product	Description
HM70F4E1A0DB	Multi-Sample
HMP360	temperature humidity meter
HM40S	HUMIDITY AND TEMPERATURE MEASURING DEVICE
HMP110	temperature/humidity sensor
17086SP	temperature sensor for HMD60Y Vaisala
HM46670SP	Sintered Stainless Steel Filter, Male Thread
HMT300TMK	MOUNTING KIT
HMP76	Relative Humidity Measurement Probe
HMP77	5 Meter Extension Cable Humidity Probe
DMPX	Dew Point and Temperature Probe
245931	Dew Form and Temperature Probe
	Humiditu and Tampanetura Matar
HMT360 3A22BCG1A2B15A1B	Humidity and Temperature Meter
215619	Duct kit
HMP110V00A0C1B0	
HMT330 350B101XCAL100A0AACBAA1	Maria B. Brita
DMT143G1C1A1B3A0ASA	Miniature Dew Point Transmitter
DMT143 G1G1A1A3A0ASX	Miniature dew point sensor
<u>GMP222C0N0</u>	Probe
HM40 D1BB	Humidity and Temperature Meter
HMW92D	Humidity and Temperature Transmitter
DMT340 6Q0K0A112A1A001A2D6K0C0	Low Dew Point Transmitter
<u>219452SP</u>	Sintered PTFE Filter, Female Thread
DMT143 G1G1A1A4A0ASX	Miniature Dew Point Transmitter
<u>DL1700SP</u>	Thermocouple Data Logger
HMT360 3A12BCD2A4B11A10	
HMT330 7T0B101BCAL100A0CALKAA1	hydrometer
DMT143 G1C1A1D3A0ASX	Miniature Dew Point Transmitter
WXT530 4C1B1A2D1B1A	Transmitter
HMT3301A0B101BCAB200A0ACABAA1	Temperature Transmitter with Integral Probe, with Display
DRW010335SP	Sintered filter Ø12 x 20
PTB330 A0AAHAAFEB5A01	Digital Barometer
MI70 C10	Measurement Indicator
DMT143L1C1A1A010ASX	Miniature Dew Point Transmitter
MMT162	Sensor for oil humidity and temperature
PDT101-W4C2	Differential Pressure Transmitter
HMM100 45A2DE	Humidity Module for Environmental Chambers
HMW93	Trainiarly Woodie for Environmental Gridinibers
HMP1	Temperature Probe
AQT530 TMP115	Air Quality Transmitter
TMP115	Wide Range Temperature Probe
HMW88D	Transmitter
PTU300	Transducers for pressure, humidity and temperature
TMD62	
INTERCAPSET-10PCS	Intercap Sensor Spare Part
P/N: R73000350 Type: DSP111	Surface Patrol with display and digital output





Product	Description
P/N: 340B001CBAL100A0ACCBAA1, Type: HMT330	Transducers
HM46PROBE	
HTM10SP	Humidity and Temperature Replacement Module
HMS82	Outdoor Humidity and Temperature Transmitter
HMT310 5B5A1BCX14BJDA1A2	Premium Humidity and Temperature Transmitter with metal enclosure
DM70F0B1A3A1	Tremium fluminity and remperature fransmitter with metal enclosure
WXT530	Weather sensor series WXT530
HM40 D2BB	Hand-held Humidity and Temperature Meter
WMT700 3A1A2B003B1A2	ultrasonic wind sensor series WMT700
HA0C1A022A1A0Z	Humidity Transmitter
DRW010525SP	Grid Filter
WMT701 B1A0C3EDB1B1	Ultrasonic wind sensor series
DMT345	Dewpoint Transmitters
DMT345	Dewpoint Transmitters Dewpoint Transmitters
867896	LED Bolt
HMS1102D0VA1NN	LLD DOIL
TMW92	
DMT143 G1C1A1A0A0ASX	Miniature dew point transducer
GM70 B4A1E1A2B	Portable CO2 meter
HMT330 3F0B101DCAB100B0AAABAA1	humidity and temperature transmitter
WMT700	number and temperature transmitter
HMP63	Vaisala INTERCAP® Humidity and Temperature Probe
GMP222E0N1	valsala in i Encar which indity and reinperature riobe
HMD83	transmitter
HMT360: 7D12HLK1A2CW5A1M+210664	Humidity sensor
HM70D4D1A0AB	Handheld temperature & humidity meter
221801	M170 Connection cable
221040	USB PC connection cable
2787HM	membrane filter
HMT315	Humidity & Temperature Transmitter
243261SP	Probe Mounting Flange For GMP251 and GMP252
GMP252 15C0B0N1	
<u>HM41</u>	Humidity and Temperature Meter
DMT143 G1C1A1D3A0ASA	Transmitter
DMT242SC	SAMPLING CELL
DMT242SC2	Sampling Cell
<u>5</u> A1A0A0A0A1	DEW POINT AND TEMPERATURE PROBE
<u>INDIGO201 1A1B0</u>	1A1B0 transmitter analog output
Certificate of Conformity	
G1C1A1A3A0ASX / DMT143	
MMT330 8V0F101CQAE100A02DABCA1	
GMP343 B1A1B0B0N0B	
INDIGO510-B1N1A1AAAN	Transmitter
<u>242659</u>	USB adapter





Product	Description
GMP25214A0B4N1	
HMP77B	Sensor for Handy Humidity Thermometer
HUMICAP	Sensor
<u>HM40</u>	indicator
<u>HMW110</u>	wall mount transmitter
HMP360 (8R5A3N2)	Humidity and temperature probe
DTR504A	Radiation Shield
<u>HMPX 7E1D0A0A0H0</u>	Humidity and Temperature Probe
TMPX 1A1A0A0A0B0	Temperature Probe
INDIGO520 A1N1B1AAAN	Transmitter
<u>USB2</u>	Indigo-compatible USB Adapter
<u>HMPX 3A2A1A0A0C0</u>	Humidity and Temperature Probe
INDIGO520 A3N3A3AAAN	Transmitter
<u>SP-1416-44V</u>	
HMPX 5C1B0A0A000	Humidity and Temperature Probe
INDIGO520 A1N1A4AAAN	Transmitter
<u>GMP251</u>	
<u>SHM40</u>	Humidity and Temperature Measurement Kit
WXT53/ 6G1C1A1A1B1B	Weather sensor
<u>HMP155 A4JB11A0A3A1A0A</u>	Humidity and Temperature Probe
HMPX / HMP7 / 7E1B2A0A0J0	Humidity and Temperature Probe
INDIGO520 /A2N3B5NAAN	INDIGO520 TransmiΣer
<u>HMP7 - 7E1B2A0A0G0</u>	
MMT330 830E 101CPAH100C12DMAAA1	
<u>DM70 DM70F0A1A0A1</u>	Handheld Chew Meter
<u>DM70 DM70F0A0A0A1</u>	Handheld dew Meter
G1G1A1A30ASX	miniature dew point sensor
<u>HMT310 5A5A1BCX14BJAC1A2</u>	Humidity and Temperature Transmitter
PWD B5NNNNNANENNDN	Weather/visibility sensor
<u>WXT530 / 6B1A2A1C2B1B</u>	
Mounting for PWD (pole with 60 mm diameter)	
Mast cable 35 m, PWD sensors	
HMD82	
<u>HMP110 V00B0C1A0</u>	Humidity and Temperature Probe
HMP155 / A2GB11A0A1A1B0A	
<u>HMP360 / 1A5A1A2</u>	Humidity and Temperature Probe
58PR53GC-A11A1A1A0A0N	process refractometer
MMPX 8A1A0B1D0C0	MMPX Moisture in Oil and Temperature Probe
<u>CBL210896-3MSP</u>	Probe cable
TMS82	Outdoor Temperature Transmitter
<u>HMT310 3B5A1BXA15DBAA1A2</u>	
<u>HMP110C15B0C3B0</u>	
HMT330 (340B141BCAD100A0CAABAA1)	Transmitter
Indigo80 + DMP80	





Product	Description
ASM210856SP	MEMBRANE FILTER PC WHITE UV STABILIZED
INDIGO80 (A1A1N1N0)	Handheld Indicator
WXT530 / 6B1B1A3B1A1B	Weather Transmitter
HMT310 5B5A1BCX14BJAA1A2	Transmitter
DMP80 (BG1A5AS0)	Handheld Dew Point Probe
GMP252 (61C0B8H3)	CO2 Probe for ppm Measurements
HMM100 / 12A1CE	· ·
HELACCRCAL-1	
PR53AC A 1 1 A 1 A 1 A 1 A 0 N	Refractometer
INDIGO520/ A3N3D0NLAN	Transmitter
HMP110 / HMP110C15A2C1A0	Humidity and Temperature Probe
HMP75	, ,
CLE321SP	
PTB330 A1AAHHACPB0A0B	Digital Barometer
DMT143 - L1C1A1A010ASX	Transmitter
RJ45 219685	
HMP155 A2GB11A0A1A1A0A	Humidity and Temperature Probe for Outdoor Applications
HMPX 5C1B0A0A0F0	Humidity and Temp. Probe
INDIGO520 B1N1AANAAN	Transmitter
INDIGO520	Transmitter
INDIGOCABLE10M	Probe Connection Cable (M12-M12), 10 m
TMP1	Temperature Probe
5L0B101XCAX100A0ACGGDA1 / HMT330	·
HMP155 A2JB11A0A4A1A0A	Humidity and Temperature Probe for Outdoor Applications
<u>58USB2</u>	USB adaptor
58KWF-2205-010	PR53 process refractometer cable
WXT535 / WXT5305G1A1A1B2B1B	SENSOR
WXT530 6B1B2A2B2B1B	Weather Transmitter
<u>HMP50Z300SP</u>	
WXT530 - 4B1B1A6D2B1A	Weather sensor
<u>19729HM</u>	LiCl Salt (11 %RH) for One Chamber
<u>19731HM</u>	Calibration Salt
PTB330 B1BAHAACEB0A0A	digital barometer
QML201	Controller
<u>HMPX-7E2B1A0A0B0, HMP7</u>	humidity and temperature probe
DMT143N1C1C1D4A0ASX	TRANSMITTER
<u>229104</u>	Nokeval transducer
<u>229110</u>	Nokeval programming kit
<u>HMP110-C15C0CFB0</u>	Humidity and Temperature Probe
GMP252 11A0A0N1	Pg/Measuring device-CO2 measuring device 1-2
HMT120 KC0A1E12C2A0Z	Humidity and Temperature Transmitter
DTR	
HMT330/ 82013121BCAH100A1CCVBAA1	
HMW88	RH + T Wall mount Transmitter
·	

Vaisala Page 8 / 9





Product	Description
PR-23-AP-73-BSS-GP-AA	
INDIGOCABLEHD10M	10M Probe Connection Cable, M12-5F - M12-5M, 10 m, Hygienic Design
INDIGO80	INDIGO80 Handheld Indicator D1N1N1N0
HMT370EX	Intrinsically Safe Humidity and Temperature Transmitter
<u>272075SP</u>	Probe Connection Cable (M12-M12), 1.5 m
230245SP	Light carrying case for HM40S / INDIGO80, spare part
DMT143 (N1C1A1D6A0ASX)	Miniature Dew Point Transmitter
<u>WXT536</u>	Compact weather station
<u>WXT532</u>	Ultrasonic Wind Speed And Direction Sensor
HMP7	Relative Humidity and Temperature Probe High Humidities
HMT310 5A5A1BCX14BHAC1A2	HUMIDITY TRANSMITTER
PN: INDIGO2011A1B0	INDIGO201 Analog Output Transmitter
HMP5	Relative Humidity and Temperature Probe
HMT310 7B5A5BCX17BP9A1A2	Humidity sensor
<u>DMP80</u>	
HMP80	
<u>HMP80 L1A1S0</u>	Handheld Humidity and Temperature Probe
INDIGO80 B1N0A1N0	Handheld Indicator
DMT143- L1C1AFA010ASX	Miniature Dew Point Transmitter
INDIGO520 A2A7BANAAN	Transmitter
MI70 B44	Measurement Indicator
HMP155 E1AA16A4B0A1C4A	Humidity and Temperature Probe for Outdoor Applications
DMPX 6C1C0A0A0B0	Dew Point and Temperature Probe
INDIGO520 A1N1A1AAAN	
HMP155 A2GB11A0A2A1A0A	Humidity and Temperature Probe for Outdoor
<u>HMP60 / C12C0A3A0</u>	Humidity and temperature probe
MMPX 8B1A1A0A0A0	
INDIGO300 A0C1CN1AFM2N0V1	
<u>DMT143 L1C1A1D410ASA</u>	Miniature Dew Point Transmitter
HMP155E1AA11A0A1E1A0A	
HMPX 3A2A1A0A0B1	
INDIGO520 A1N1B6NAAN	
USB2 compatible USB Adapter	
WXT536G1A1A1B2B1B	Transmitter
INDIGO300 A0A1NN1ACP0N0V1	Indigo300 Transmitter
DMT143L / L1C1A1A010ASX	miniature dew point sensor
HMP110 R00A0C1A0	Humidity and temperature sensor, ±1.5 %RH
HMPX 7E1A2A0A0J2	Humidity and temperature probe