







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





## Vaisala

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## **BRAND'S PRODUCTS**

Product	Description
<u>1434WA</u>	Sensor Board WAV15x Sensors
<u>16644WA</u>	Service Kit for Wind Sensors
HMT310 5A5A1BCX14BJAA1A2	Premium sensor
DMT143-G1C1A1A0A0ASA	
<u>DMT348</u>	Transmissor
DRD11A	Precipitation Detector
<u>GM45237SP</u>	Protective Sleeve for GMP222
GMP222 (B0N0 CO2 PROBE)	
P/N: HM70, Type: B1B1A0AA	Portable humidity and temperature meter
HMP155E1AA11A0B2A1B0A	Humidity and temperature sensor
HMT330 3E0A001BCAB200A0CAABAA1	Humidity and temperature sensor
HMT120 TD0AXA11A2A0Z	Humidity and temperature transmitter
HMT120 KB1A1B12A1Z0Z	Humidity and Temperature Transmitter, ±1.5 %RH, 420 mA
HMT330 3E0B141BCAD100A0AAAAA1	Humidity and temperature transmitter
HMT360 1D22BCE1A2BA5A10	SENSOR
MM70F1A1A5A1A0A2B0	Handheld Moisture and Temperature Meter
PTB330 A1AAHAAPEB0A0B	digital barometer
PTU30011801A1BCAF1A4A1FAE0B0A	Pressure, Humidity and Temperature Transmitter
PTU300 12A01C1BCPF1A0A1BAB0B0A	(Pressure, humidity andMeasured temperature transmitter)
PWD Weather/visibility sensor	Visibility sensor
<u>WAA151</u>	Windgeschwindigkeitssensor WAA151
<u>WSP150</u>	Surge Protector no Connectors
<u>ZZ45036</u>	sensor cable
<u>ZZ45037</u>	sensor cable
<u>ZZ45048</u>	Signal cable 16 x 0.25 mm2
HMT330 -340B101CHAH100A01ACBAA1	TEMPERATURE TRANSMITTER
GMW93R	CO2+RH+T transmitter Voltage output
GMW94R	CO2+RH+T transmitter Current output
<u>219690</u>	USB cable
<u>HUMICAP180R</u>	Humidity sensor
<u>QMT110</u>	Temperature sensor
HMT 330 340A021CBAX100A01ACBAA1	Temperature Sensor
HM70A0C1A0AA	Humidity and Temperature Probe
HMD60U	Humidity Transmitter
DM70F5B1A3B1	Hand-held Dewpoint and Temperature Meter set with carrying case for Desiccant Dryers





Product	Description
<u>DM70F5A1A3B1</u>	Hand-held Dewpoint and Temperature Meter
HMT360 4D22HHK1A2BE5A3K	Measuring device for humidity and temperature
HMT330 1A0A121BCAB100A0AAABAA1	Feuchte und Temperaturmesswertgeber
POWER-1	External power supply module
HMT330 1A0A101BCAB100A11AABAA1	Feuchte und Temperaturmesswertgeber
WXT530 2C1B2A3D1B1B	Weather Transmitter
WXT530 6C1B2A3D2B1B	air sensor
CLT321SP	Transmitter Spare Part
<u>PDT101-P4C</u>	Differential Pressure Transmitter
WXT520 AAD1BE31B0	Weather Transmitter
<u>16644WA</u>	Service Kit
WXT520-AAB1BC10B0	Wettermesswertgeber
HM70D0A1A0DE	Portables Feuchte- und Temperaturmessgerät
<u>HMP235 – E2A1A1AA32A1A3B</u>	Dewpoint sensor
<u>HMT335</u>	
GMT222 G0A1B0NXA0A	CO2 Transmitter
WXT530 6C4B1A2B2B1B	
QML201C	AWS Logger MAWS
WXT536 / WXT5306B1B1A1A1A1B	Weather Transmitter
<u>HMT331</u>	Raumfühler zur Wandmontage
HUMICAP180L2	Feuchtesensor
<u>HM42</u>	Handheld Humidity and Temperature Meter with HM42PROBE
DMT340 6R0K1A111A1A001E2D6K0C0	Dry Sensor
HMP110 V00C2C1A0	
<u>HMT120 (KA1A1B12A1A0Z)</u>	
HMP155 A2GB13A0A2A1A0A	Humidity and temperature probe
HMT330 / 8X0B101BCAD100A0ADNGAA1	Humidity and Temperature Meter
DMT152A1CBB10A010A1A	Taupunktmesswertgeber
<u>GMM222</u>	
<u>HMT330</u>	Transmitter
MMT330 8W0F145QCAL100A02DMBAA1	Moisture and Temperature Transmitter for Oil
<u>AQT420</u>	Air Quality Transmitter for Pollutant Gases and Particulate Matter
HMT330 5N0B001GCAF100A01CGBAA1	Feuchte und Temperaturmesswertgeber
HMT315 // 5A5A1BCX14BH1A1A2	
AQT420 (10 pcs)	
<u>226068</u>	
<u>WXTPTUSP</u>	PTU-Module Spare Part for the WXT530 series.
<u>212792</u>	Ultrasonic Wind Sensor
DMT143 G1C1B1A3A0ASX	Miniature Dew Point Transmitter
<u>HM70F4A1A0DB</u>	
HMT330 3E0B101XCAX100A0AAACAA1	
MMT330 8V0F101CQAE100A02DNBAA1	Moisture and Temperature Transmitter
HMP110C15A0C3A0	
DMT143 N1C1B1A3A0ASX	0 12 1
WAC155CB	Component Board





Product	Description
4H0B001BCAK100A0ACEBAA1 (HMT330)	Premium Humidity and Temperature Transmitter with metal enclosure
MMT330 2D0F121CQQC123A32DABAA1	Transducers for oil humidity and temperature with cable probes
HMP46	Thermohygrometer
GMP222	CO2 Probe (ppm)
HMT360	HumudityTempTransmitter
HMP155 A4JC11A0A0A1A0A	· ·
<u>WSP152</u>	
HMT330 7S1D001GXCX103A0DAABAA1	Humidity and temperature sensor
WXT530 6A1A1A1A1B	Weather transmitter
8V0F121CPQL143C12E3BBA1	
<u>GMP222G0N0</u>	
<u>WA15D7B</u>	Wind sensor component set
<u>219687</u>	Connection Cable
WM30 C1BA	
<u>15778HM</u>	
<u>PDT102-P2V</u>	
HMT120 ( KC0A1F12A2A0Z)	
<u>DM70 / B0B1A3B1</u>	Hand-Held Dewpoint Meter
<u>DM70 A0B0A0A0</u>	Portable dew point meter
DMT143L1CAA1A010ASX	DMT143 Transmitter
DMT143R1CAAFA011ASX	DMT143 Transmitter for Low Dewpoint
HMS82W	
HMD62	Temperature Transmitter
<u>HM70A0E1A0AA</u>	probe
DMT143 G1C1A1A3A0ASX	Miniature Dew Point Transmitter
DTR503A	Radiation Shield
HMP155 /A2JB11A0A0A1A0A	Humidity and temperature probe
Rosa DR322SYS	weather station with data logger
DRS511AB15	Road and runway surface with a cable
DTS12G3	Ground/Soil temperature probe
<u>WA15</u>	Wind set
DMT143 N1C2D1X4S0ASX HPP272	Transmitter for Low Dewpoint
WXT530 6C1B1A3D1B1B	Hydrogen Peroxide, Humidity and Temperature Probe  Weather Transmitter WXT530 Series
PTB330 B1AEJAACEB0A0B	
HMP110A15A1C3B0	Digital Barometer  Probe
HMP60	Sensor
MMT330 (7S0F141QCAL100C02EKBAA1)	Moisture in Oil and Temperature Transmitter with Remote Probes
HM47280SP	Filter
HMT330 3E0B101XCAG100A0AACBAA1	Premium Humidity and Temperature Transmitter with metal enclosure
HMP360 3B5A1B2	Humidity and Temperature Probe
PTB210 A1B3B	Outdoor Barometer with RS232, RS485, 0-5 or 0-2.5V outpu
SPH210	static pressure head
SPH20	Static Pressure Head
HMT310 FC5A1NRA17CRGG1B2	Humidity and Temperature Transmitter
THE TOTAL CONTINUENT OF IGGIDE	riamany and remperature transmitter

Vaisala Page 3 / 9





Product	Description
HMT330 1A0B001BCAF100A0AAABAA1	Humidity and Temperature Transmitter
HMT330 3E0B101BCAC100G0AAABAA1	Humidity and Temperature Transmitter with Remote Probe
DMT340 6R0K1C121A1A001A2D6K4C0	Dew point and temperature transmitter
HMP60 A12A0A2B0	INTERCAP Humidity and Temperature Probe
HMP9	Compact Humidity and Temperature Probe
HMP360 1A5A1A4	Humidity and Temperature Transmitter
HMT360 1A22BCA2A4BA5A10	Humidity and Temperature Transmitter
CLB311-230SP	Window Blower
DRW010276SP	Sensor protective grid
HMT330 3E0B015BCAG100A0ACABAA1	Premium Humidity and Temperature Transmitter
HMT330 3G0B111DCAF100A0ACCBAA1	Feuchte und Temperaturmesswertgeber
HMT318 (8A5A1BCJ14BSAC1M2)	Premium Humidity and Temperature Transmitter
GMP251 A2B0C1C1	Carbon Dioxide Probe, GMP251 CO2 series
GMP251 A2B0C1C1	Carbon Dioxide Probe GMP251,CO2
WXT530 6C1B2A1D1B1B	weather sensor
1A22BCA1B2BA5A10 (HMT360)	Messgerät für Feuchte und Temperatur
<u>212483</u>	EX food separator
<u>210664</u>	Sicherheitsbarriere
<u>214101</u>	
JUNCTIONBOX-8	Junctionbox-8 Junction Box With 8-contacts Klemens
WXT530, Order code: 6B1B1A3B2B1B	WXT530 series weather sensor
<u>WAC151</u>	Sensor support arm including terminal box WAC151
HMP360 325A104	Humidity and temperature transmitters
HMT 360 3A22BCD1A4B25A10	Humidaity and Temperature Transmitter
<u>DSC211</u>	Remote Road Sensor
<u>HMT 140</u>	Data Logger
<u>GMP343</u>	Junction Box with 8 contacts
GMD20	Transmitter
HMT360 (p/n 1A22BCA1B2BA5A10 )	Humidity and Temperature transmitter with Sensor Probes
PTU300-11A01A0AAAA1A4ABAE0B3A	Pressure, Humidity and Temperature Transmitter
<u>MI70F10</u>	Measurement Indicator MI70
PTB330	Digital Barometer
HMP155 // A2AB12A4A4A1D0A	Humidity & Temp Probe
DM70 B5A1A3B1	Portable dew point meter
PTU 303 (32D01A1BCPB1A0A1B1B0B0A)	Pressure, humidity and temperature transmitter
1 TO 303 (32D01A1D01 D1A0A1D1D0D0A)	the second of th
HMT330 (340A141BCAD100A0CAABAA1)	Humidity and temperature transducers
HMT330 (340A141BCAD100A0CAABAA1)	Humidity and temperature transducers
<u>HMT330 (340A141BCAD100A0CAABAA1)</u> <u>DM70 B5A0A4B1</u>	Humidity and temperature transducers  Handheld Dewpoint Meter for Spot-Checking Applications
HMT330 (340A141BCAD100A0CAABAA1)  DM70 B5A0A4B1  HM70 B4A1A0DB	Humidity and temperature transducers  Handheld Dewpoint Meter for Spot-Checking Applications  Portable Humidity and Temperature Meter
HMT330 (340A141BCAD100A0CAABAA1)  DM70 B5A0A4B1  HM70 B4A1A0DB  HMD65	Humidity and temperature transducers  Handheld Dewpoint Meter for Spot-Checking Applications  Portable Humidity and Temperature Meter  Humidity and temperature sensors
HMT330 (340A141BCAD100A0CAABAA1)  DM70 B5A0A4B1  HM70 B4A1A0DB  HMD65  7S1D021XCAB200A0EAQBAA1	Humidity and temperature transducers  Handheld Dewpoint Meter for Spot-Checking Applications  Portable Humidity and Temperature Meter  Humidity and temperature sensors  Premium Humidity and Temperature Transmitter
HMT330 (340A141BCAD100A0CAABAA1)  DM70 B5A0A4B1  HM70 B4A1A0DB  HMD65  7S1D021XCAB200A0EAQBAA1  HM70 B0D1A0AB	Humidity and temperature transducers Handheld Dewpoint Meter for Spot-Checking Applications Portable Humidity and Temperature Meter Humidity and temperature sensors Premium Humidity and Temperature Transmitter Handheld Humidity and Temperature Meter
HMT330 (340A141BCAD100A0CAABAA1)  DM70 B5A0A4B1  HM70 B4A1A0DB  HMD65  7S1D021XCAB200A0EAQBAA1  HM70 B0D1A0AB  HM70F4E1A0DB	Humidity and temperature transducers  Handheld Dewpoint Meter for Spot-Checking Applications  Portable Humidity and Temperature Meter  Humidity and temperature sensors  Premium Humidity and Temperature Transmitter  Handheld Humidity and Temperature Meter  Multi-Sample

Vaisala Page 4 / 9





Product	Description
17086SP	temperature sensor for HMD60Y Vaisala
HM46670SP	Sintered Stainless Steel Filter, Male Thread
HMT300TMK	MOUNTING KIT
HMP76	Relative Humidity Measurement Probe
HMP77	5 Meter Extension Cable Humidity Probe
DMPX	Dew Point and Temperature Probe
245931	Dew Form and Temperature Frobe
HMT360 3A22BCG1A2B15A1B	Humidity and Temperature Meter
215619	Duct kit
HMP110V00A0C1B0	Duct Nit
HMT330 350B101XCAL100A0AACBAA1	
	Miniature Dew Point Transmitter
DMT143G1C1A1B3A0ASA	
DMT143 G1G1A1A3A0ASX	Miniature dew point sensor
GMP222C0N0	Probe
HM40 D1BB	Humidity and Temperature Meter
HMW92D	Humidity and Temperature Transmitter
DMT340 6Q0K0A112A1A001A2D6K0C0	Low Dew Point Transmitter
<u>219452SP</u>	Sintered PTFE Filter, Female Thread
<u>DL1700SP</u>	Thermocouple Data Logger
HMT360 3A12BCD2A4B11A10	
HMT330 7T0B101BCAL100A0CALKAA1	hydrometer
DMT143 G1C1A1D3A0ASX	Miniature Dew Point Transmitter
WXT530 4C1B1A2D1B1A	Transmitter
<u>HMT3301A0B101BCAB200A0ACABAA1</u>	Temperature Transmitter with Integral Probe, with Display
<u>DRW010335SP</u>	Sintered filter Ø12 x 20
PTB330 A0AAHAAFEB5A01	Digital Barometer
MI70 C10	Measurement Indicator
<u>MMT162</u>	Sensor for oil humidity and temperature
PDT101-W4C2	Differential Pressure Transmitter
<u>HMM100 45A2DE</u>	Humidity Module for Environmental Chambers
HMW93	
HMP1	Temperature Probe
<u>AQT530</u>	Air Quality Transmitter
<u>TMP115</u>	Wide Range Temperature Probe
HMW88D	Transmitter
PTU300	Transducers for pressure, humidity and temperature
INTERCAPSET-10PCS	Intercap Sensor Spare Part
P/N: R73000350 Type: DSP111	Surface Patrol with display and digital output
P/N: 340B001CBAL100A0ACCBAA1, Type:	
<u>HMT330</u>	Transducers
HM46PROBE	
HTM10SP	Humidity and Temperature Replacement Module
<u>HMS82</u>	Outdoor Humidity and Temperature Transmitter
HMT310 5B5A1BCX14BJDA1A2	Premium Humidity and Temperature Transmitter with metal enclosure
	,

Vaisala





Product	Description
DM70F0B1A3A1	·
WXT530	Weather sensor series WXT530
HM40 D2BB	Hand-held Humidity and Temperature Meter
WMT700 3A1A2B003B1A2	ultrasonic wind sensor series WMT700
HA0C1A022A1A0Z	Humidity Transmitter
DRW010525SP	Grid Filter
WMT701 B1A0C3EDB1B1	Ultrasonic wind sensor series
<u>DMT345</u>	Dewpoint Transmitters
<u>DMT346</u>	Dewpoint Transmitters
<u>867896</u>	LED Bolt
HMS1102D0VA1NN	
TMW92	
DMT143 G1C1A1A0A0ASX	Miniature dew point transducer
GM70 B4A1E1A2B	Portable CO2 meter
HMT330 3F0B101DCAB100B0AAABAA1	humidity and temperature transmitter
<u>WMT700</u>	
HMP63	Vaisala INTERCAP® Humidity and Temperature Probe
<u>GMP222E0N1</u>	
HMD83	transmitter
HMT360: 7D12HLK1A2CW5A1M+210664	Humidity sensor
HM70D4D1A0AB	Handheld temperature & humidity meter
<u>221801</u>	M170 Connection cable
<u>221040</u>	USB PC connection cable
<u>2787HM</u>	membrane filter
<u>HMT315</u>	Humidity & Temperature Transmitter
<u>243261SP</u>	Probe Mounting Flange For GMP251 and GMP252
GMP252 15C0B0N1	
<u>HM41</u>	Humidity and Temperature Meter
DMT143 G1C1A1D3A0ASA	Transmitter
DMT242SC	SAMPLING CELL
DMT242SC2	SAMPLING CELL WITH SWAGELOK
<u>5A1A0A0A0A1</u>	DEW POINT AND TEMPERATURE PROBE
<u>INDIGO201 1A1B0</u>	1A1B0 transmitter analog output
Certificate of Conformity	
G1C1A1A3A0ASX / DMT143	
MMT330 8V0F101CQAE100A02DABCA1	
GMP343 B1A1B0B0N0B	
INDIGO510-B1N1A1AAAN	Transmitter
<u>242659</u>	USB adapter
GMP25214A0B4N1	
HMP77B	Sensor for Handy Humidity Thermometer
HUMICAP	Sensor
<u>HM40</u>	indicator
<u>HMW110</u>	wall mount transmitter
HMP360 (8R5A3N2)	Humidity and temperature probe





Product	Description
DTR504A	Radiation Shield
HMPX 7E1D0A0A0H0	Humidity and Temperature Probe
TMPX 1A1A0A0A0B0	Temperature Probe
INDIGO520 A1N1B1AAAN	Transmitter
USB2	Indigo-compatible USB Adapter
HMPX 3A2A1A0A0C0	Humidity and Temperature Probe
INDIGO520 A3N3A3AAAN	Transmitter
<u>SP-1416-44V</u>	
HMPX 5C1B0A0A000	Humidity and Temperature Probe
INDIGO520 A1N1A4AAAN	Transmitter
<u>GMP251</u>	
SHM40	Humidity and Temperature Measurement Kit
WXT53/ 6G1C1A1A1B1B	Weather sensor
HMP155 A4JB11A0A3A1A0A	Humidity and Temperature Probe
<u>HMPX / HMP7 / 7E1B2A0A0J0</u>	Humidity and Temperature Probe
INDIGO520 /A2N3B5NAAN	INDIGO520 TransmiΣer
<u>HMP7 - 7E1B2A0A0G0</u>	
MMT330 830E 101CPAH100C12DMAAA1	
DM70 DM70F0A1A0A1	Handheld Chew Meter
DM70 DM70F0A0A0A1	Handheld dew Meter
G1G1A1A30ASX	TRANSMİTTER DEWPOINT
HMT310 5A5A1BCX14BJAC1A2	Humidity and Temperature Transmitter
PWD B5NNNNNANENNDN	Weather/visibility sensor
WXT530 / 6B1A2A1C2B1B	
Mounting for PWD (pole with 60 mm diameter)	
Mast cable 35 m, PWD sensors	
HMD82	
HMP110 V00B0C1A0	Humidity and Temperature Probe
<u>HMP155 / A2GB11A0A1A1B0A</u>	
<u>HMP360 / 1A5A1A2</u>	Humidity and Temperature Probe
58PR53GC-A11A1A1A0A0N	process refractometer
MMPX 8A1A0B1D0C0	MMPX Moisture in Oil and Temperature Probe
<u>CBL210896-3MSP</u>	Probe cable
<u>TMS82</u>	Outdoor Temperature Transmitter
<u>DMT143</u>	Miniature Dew Point Transmitter
HMT310 3B5A1BXA15DBAA1A2	
<u>HMP110C15B0C3B0</u>	
HMT330 (340B141BCAD100A0CAABAA1)	Transmitter
Indigo80 + DMP80	
<u>ASM210856SP</u>	MEMBRANE FILTER PC WHITE UV STABILIZED
<u>INDIGO80 (A1A1N1N0)</u>	Handheld Indicator
WXT530 / 6B1B1A3B1A1B	Weather Transmitter
<u>HMT310 5B5A1BCX14BJAA1A2</u>	Transmitter
<u>DMP80 (BG1A5AS0)</u>	Handheld Dew Point Probe





Product	Description
GMP252 (61C0B8H3)	CO2 Probe for ppm Measurements
HMM100 / 12A1CE	COL 1 1000 101 ppm modernmento
HELACCRCAL-1	
PR53AC A 1 1 A 1 A 1 A 1 A 0 N	Refractometer
INDIGO520/ A3N3D0NLAN	Transmitter
CG31	Hanomico
HMP110 / HMP110C15A2C1A0	Humidity and Temperature Probe
HMP75	Trainiary and Temperature 17656
CLE321SP	
PTB330 A1AAHHACPB0A0B	Digital Barometer
DMT143 - L1C1A1A010ASX	Transmitter
RJ45 219685	
HMP155	Humidity & Temperature Sensor, 0-1V outputs, 3.5m cable (11.5 feet)
HMPX 5C1B0A0A0F0	Humidity and Temp. Probe
INDIGO520 B1N1AANAAN	Transmitter
INDIGO520	Transmitter
INDIGOCABLE10M	Probe Connection Cable (M12-M12), 10 m
TMP1	Temperature Probe
5L0B101XCAX100A0ACGGDA1 / HMT330	
HMP155 - A2JB11A0A4A1A0A	
<u>58USB2</u>	USB adaptor
58KWF-2205-010	PR53 process refractometer cable
WXT535 / WXT5305G1A1A1B2B1B	SENSOR
WXT530 6B1B2A2B2B1B	Weather Transmitter
<u>HMP50Z300SP</u>	
WXT530 - 4B1B1A6D2B1A	Weather sensor
<u>19731HM</u>	Calibration Salt
PTB330 B1BAHAACEB0A0A	digital barometer
<u>QML201</u>	Controller
<u>HMPX-7E2B1A0A0B0, HMP7</u>	humidity and temperature probe
DMT143N1C1C1D4A0ASX	TRANSMITTER
<u>229104</u>	Nokeval transducer
<u>229110</u>	Nokeval programming kit
HMP110-C15C0CFB0	Humidity and Temperature Probe
<u>GMP252 11A0A0N1</u>	Pg/Measuring device-CO2 measuring device 1-2
<u>HMT120 KC0A1E12C2A0Z</u>	Humidity and Temperature Transmitter
DTR	
HMT330/ 82013121BCAH100A1CCVBAA1	
HMW88	RH + T Wall mount Transmitter
PR-23-AP-73-BSS-GP-AA	
INDIGOCABLEHD10M	10M Probe Connection Cable, M12-5F - M12-5M, 10 m, Hygienic Design
INDIGO80	INDIGO80 Handheld Indicator D1N1N1N0
HMT370EX	Intrinsically Safe Humidity and Temperature Transmitter
272075SP	Probe Connection Cable (M12-M12), 1.5 m
<u>230245SP</u>	Light carrying case for HM40S / INDIGO80, spare part

Vaisala Page 8 / 9





Product	Description
DMT143 ( N1C1A1D6A0ASX )	Miniature Dew Point Transmitter
<u>WXT536</u>	Compact weather station
<u>WXT532</u>	Ultrasonic Wind Speed And Direction Sensor
HMP7	Relative Humidity and Temperature Probe High Humidities
HMT310 5A5A1BCX14BHAC1A2	HUMIDITY TRANSMITTER
PN: INDIGO2011A1B0	INDIGO201 Analog Output Transmitter
HMP5	Relative Humidity and Temperature Probe
HMT310 7B5A5BCX17BP9A1A2	Humidity sensor
<u>DMP80</u>	
HMP80	
<u>HMP80 L1A1S0</u>	Handheld Humidity and Temperature Probe
INDIGO80 B1N0A1N0	Handheld Indicator
DMT143- L1C1AFA010ASX	Miniature Dew Point Transmitter
INDIGO520 A2A7BANAAN	Transmitter