



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Wilkers

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### onBRAND'WnSA POD

WUCTkdu	AlcdUtputCi
<a href="#">F16F-CF3F0( NF857-)FP</a>	handle
<a href="#">)FR.-C.3.-F.94</a>	-2C way valve
<a href="#">)C3F.Cx.)FF.8</a>	4ylinders
<a href="#">)C3F.RF.1F.8AI</a>	small cylinder
<a href="#">)C3F.xF.F)FF</a>	Kmall cylinder
<a href="#">)C0F.-C.T</a>	
<a href="#">)-CF.xF.)FF.F)</a>	cylinders
<a href="#">)-CF.xF.xF.F)</a>	cylinders
<a href="#">)-CF.0F.CFF.F)</a>	cylinders
<a href="#">)-C).xF.)FF.F).I</a>	
<a href="#">)-C).xF.)3F.F)I</a>	Oylinder GKU )xxxC L S(8A CRx3C
<a href="#">)-0x.xF.xF.FC</a>	
<a href="#">)xFF.(4.x8</a>	8agnetic sensor
<a href="#">)xF).RF.)F</a>	shortLstroke cylinder
<a href="#">)xF).RF.3F</a>	Khort stroke
<a href="#">)xFC.CF.)F</a>	KhortLstroke cylinder
<a href="#">)x)).-C.)FF</a>	short stroke cylinder
<a href="#">)x)).-C.)xF</a>	short stroke cylinder
<a href="#">)1)EC¼.4.(.FFF6A</a>	"roportional pressure regulator
<a href="#">)1CFR 7.7.4</a>	filter regulator
<a href="#">)13-.0F.¼5</a>	pressure translator
<a href="#">C)R2C.xC.xx2C</a>	x2C 9ever Salve
<a href="#">"¼F3)-3.CCF</a>	"¼E/8AMG4 4D9G¼(E5L:xFL8A"¼EMB4L4U5KA2KM5U+E
<a href="#">CC0.xC.3.C1</a>	x2C directional valve
<a href="#">C-FR.xC.FF.-x.FC</a>	
<a href="#">C-FR.xC.FF.-6.FC</a>	x2C valve E¼USA
<a href="#">R)C2).xC.F.F.Kx NCRS2(4P</a>	x2CLWegeventil " )2C
<a href="#">C-F3.xC.FF.-x.FC</a>	x2CLway valve E¼USA
<a href="#">C-)1.CF</a>	profile seal
<a href="#">CRCFAF660R</a>	round cylinder
<a href="#">CR-).xC.FF.-x.F6 NCRS2(4P</a>	x2CLway valve " )2R
<a href="#">CR-).xC.FF.-6.F6 NCRS2(4P</a>	x2CLway valve
<a href="#">CR-).xC.FF.-6.3C</a>	Sentil
<a href="#">CR-x.xC.FF.C6.FC NCRS2(4P</a>	x2C way valve
<a href="#">-Fx.))FF.9LCRS</a>	socket

































Product	Description
<a href="#">GPA-96-606</a>	L holder
<a href="#">L30-C8-000</a>	LUBRICATOR
<a href="#">F23-04-000</a>	muffler
<a href="#">D18-C2-FK00B</a>	
<a href="#">WSA-08-F00</a>	LIQUID SEPARATR
<a href="#">L18-C2-KK00B</a>	compressed air oiler
<a href="#">D08-C2-FKG0B</a>	
<a href="#">R41-CC-L00 K11</a>	Regulator
<a href="#">M31-C6-FMS</a>	Coalescing Filter
<a href="#">M30-08-S00</a>	Coalescing Filter
<a href="#">WDV3-G23BL</a>	Valve
<a href="#">R09-C2-RB00B</a>	PRESSURE REGULATOR
<a href="#">R41-0B-000</a>	Dial Air Regulator
<a href="#">M26-C3-000</a>	
<a href="#">GPA-95-101</a>	VALVE 1/2BSPP
<a href="#">R41-CB-000 H18</a>	
<a href="#">R31-C8-000 M10</a>	
<a href="#">MTP-95-500</a>	Filter Element
<a href="#">BB3-C2-FR00</a>	Filter regulator
<a href="#">L03-C2-000</a>	LUB
<a href="#">B28-C6-FK00B</a>	filter regulator
<a href="#">R31-08-000 F1</a>	
<a href="#">ATP-212HA</a>	
<a href="#">V60-04-B000B</a>	shut-off valve
<a href="#">R41-CB-4299789</a>	regulator
<a href="#">F16-C2-G00</a>	
<a href="#">L50-CC-G00</a>	
<a href="#">GRP-95-089</a>	plastic container
<a href="#">R03-02-M00</a>	Pneumatic Regulator
<a href="#">M28-06-BK00B</a>	compressed air filter
<a href="#">GRP-96-640</a>	O-ring
<a href="#">R12NG02L</a>	NUM 12 SER.REG
<a href="#">F23-C4-M00</a>	
<a href="#">R40-0B-G00</a>	filter
<a href="#">F30-06-FMQ</a>	
<a href="#">C28-04-FG00B</a>	
<a href="#">R18-04-G000B</a>	
<a href="#">K4520N14300</a>	
<a href="#">CB6-02-FM0</a>	Filter / Regulator
<a href="#">F16-C2-FM0</a>	Particulate Filter
<a href="#">M16-C2-FM0</a>	Coalescing Filter
<a href="#">M16-C2-GX0</a>	Coalescing Filter
<a href="#">B18-C3-FK00B</a>	filter regulator

Product	Description
<a href="#">R11-C2-00 J18</a>	
<a href="#">M28-06-CH00B</a>	
<a href="#">R16-03-H00</a>	regulator
<a href="#">X02-C4-M00</a>	
<a href="#">F30-C8-F00A D03</a>	Air Filter
<a href="#">N08-C2-0000</a>	branch block
<a href="#">R26-C4-000A</a>	COMPLETE REGULATOR
<a href="#">R03-C2-000</a>	pressure regulator
<a href="#">R18-C3-F000B</a>	pressure regulator
<a href="#">R28-04-Y0000B</a>	Regulator
<a href="#">B08-C2-FLG0B</a>	
<a href="#">R41-CC-L-00 B H 00</a>	
<a href="#">WSA-06-FM0 D08</a>	
<a href="#">R41-CC-L00</a>	Dial Air Regulator G2"
<a href="#">GRP-96-806</a>	
<a href="#">MXP-95-502</a>	Filter Element
<a href="#">M18-C2-CG00B</a>	Ultrafine filter
<a href="#">CB6-04AG</a>	
<a href="#">R31-08-0000</a>	Regulator
<a href="#">M08-C2-DK00B</a>	
<a href="#">B18-03-FKG0B</a>	filter regulator
<a href="#">F28-C6-SK00</a>	
<a href="#">R28-C6-F000</a>	pressure regulator
<a href="#">X03-C4-000</a>	Adsorption dryer
<a href="#">L28-C6-KL00B</a>	G3/4" compressed air oiler
<a href="#">R18-02-R000B</a>	WILKERSON REG.
<a href="#">V28-C4-0000</a>	Safety shut-off valve
<a href="#">B03-02-M000</a>	
<a href="#">F28-06-SE00</a>	FILTER
<a href="#">F28-C6-SE00B</a>	Filter
<a href="#">F16-C2-000</a>	compressed air filter
<a href="#">M2806BG00B</a>	
<a href="#">F30-C8-000 A</a>	
<a href="#">RRP-95-951</a>	
<a href="#">RRP-96-238</a>	
<a href="#">RRP-96-294</a>	
<a href="#">GRP-95-225</a>	
<a href="#">RRP-95-219</a>	
<a href="#">RRP-95-023</a>	
<a href="#">RRP-95-954</a>	
<a href="#">RPA-95-006</a>	
<a href="#">N18-C4-0000</a>	Diverter Block G ½"
<a href="#">P17-02-B00</a>	

Product	Description
<a href="#">M08-C2-CK00B -085320014</a>	
<a href="#">B18-C2-FL00</a>	
<a href="#">B18-C2-FL00B</a>	filter regulator
<a href="#">B28-C4-FG00B</a>	
<a href="#">RB3-C1-W000</a>	
<a href="#">R03-01-M00</a>	REGULATOR
<a href="#">R40-0B-000</a>	NPT pressure regulator
<a href="#">L28-C4-KK00B</a>	
<a href="#">GRP-95-676</a>	metal container
<a href="#">D18-C4-FKG0B</a>	maintenance unit
<a href="#">R18-C4-G000B</a>	
<a href="#">L08-02-KK00B</a>	
<a href="#">B08-02-FKG0B</a>	Filter regulator
<a href="#">GRP-96-825</a>	
<a href="#">F18-04-SKL0</a>	
<a href="#">F18-C4-SKL0B</a>	particulate filter
<a href="#">M18-C4-CL00B</a>	coalescing filter
<a href="#">R09-C2-RBGB</a>	
<a href="#">C28-06-FKG0B</a>	
<a href="#">R21-06-000 Dial Air Regulator</a>	Air regulator
<a href="#">R03-C2-P00</a>	
<a href="#">F18-C2-SG00B</a>	Compressed air filter G1/4"
<a href="#">MTP-95-548</a>	filter insert
<a href="#">R11-C2-000-007</a>	Dial Air Regulator
<a href="#">M18-C4-CK00B</a>	coalescing filter
<a href="#">M26-C4-F00</a>	G½" coalescent filter
<a href="#">R41-CB-L00</a>	Pressure regulator
<a href="#">B28-C4-FK00B</a>	filter regulator
<a href="#">R16-03-000</a>	pressure regulator
<a href="#">R40-0C-H00</a>	Pressure regulator 2 "-NPT
<a href="#">R40-0B-H00</a>	Pressure regulator 1 ½" -NPT
<a href="#">B18-04-FLG0</a>	1/2"-NP filter regulator
<a href="#">F35-0C-F00</a>	Wilkerson Particulate Filter
<a href="#">R16-C2-H00</a>	adjuster
<a href="#">GRP-95-009</a>	
<a href="#">M35-CC-S00</a>	
<a href="#">maintenance kit for CB6-C2-F00</a>	
<a href="#">K4515N18160</a>	Pressure gauge
<a href="#">PN: 086320020 / R41-CCC-000</a>	Manoregler with self-ventilation
<a href="#">M26-03-F0</a>	
<a href="#">F28-C6-SH00B</a>	filter
<a href="#">R28-C6-F0G0B</a>	regulator
<a href="#">NJ8-C6-D000</a>	Diverter Block

Product	Description
<a href="#">E28-C6-0000</a>	Exhaust Valve
<a href="#">SV105-06</a>	
<a href="#">R09-02-DBG0B</a>	REGULATOR, 0-60 PSI, COMMON PR
<a href="#">B28-06-FK00B</a>	FILTER/REGULATOR 125PSI 3/4NPT
<a href="#">XRP-95-747</a>	
<a href="#">L17-03-000</a>	WILK LUBRICATOR
<a href="#">V73-C6-B000B</a>	
<a href="#">F602-06EJR/M4</a>	
<a href="#">SR2-04-LAS0</a>	Compressed Air Regulator
<a href="#">D18-02-FKG0</a>	
<a href="#">M26-C3-FM0</a>	
<a href="#">GPA-95-918</a>	
<a href="#">F18-C3-SK00B</a>	Compressed air filters
<a href="#">X02-C4-F00</a>	EXTERNAL DRAIN
<a href="#">DO.88-PC-B</a>	
<a href="#">L30-C6-G00</a>	
<a href="#">Type F23-C4-000</a>	filter silencer
<a href="#">R08-02-R0G0B</a>	
<a href="#">RPA-96-733</a>	
<a href="#">FRP-95-015 for M16-02-F00B-C01</a>	plastic cup
<a href="#">R41-CB-R00 / 086320019</a>	Manual for remote control
<a href="#">M30-08-FM0</a>	COALESCING FILTER
<a href="#">M30-08-FS0</a>	COALESCING FILT
<a href="#">R 16-C4-000A L00</a>	
<a href="#">M26-02-F00</a>	
<a href="#">X03-C2-000 M20</a>	filter
<a href="#">RB3-02-R000</a>	
<a href="#">M30-06-S00</a>	FILTER
<a href="#">GRP-95-256</a>	
<a href="#">LRP-95-163</a>	
<a href="#">M30-04-F00</a>	
<a href="#">M03-C2-D00</a>	
<a href="#">R03-01-000</a>	
<a href="#">F33-C6-M00</a>	Filter
<a href="#">FRP-95-508 59-90284</a>	
<a href="#">FRP-95-505 59-90282</a>	
<a href="#">R09-C2-FBG0B</a>	
<a href="#">P3NEA18GSABNN</a>	
<a href="#">P3NLA18LSN</a>	
<a href="#">F16-03-M00</a>	PARTICULATE FILTER
<a href="#">R40-0C-HN0</a>	Pressure regulator
<a href="#">R21-C6-000 B15</a>	PNEUMATIC PRESSURE REDUCER
<a href="#">B18-04-DKG0B</a>	1/2" FILTER/REGULATOR

Product	Description
<a href="#">P31KA00ESA</a>	
<a href="#">M35-0B-FS0</a>	WILK COAL FLTR
<a href="#">GRP-95-022</a>	DPI CAP PLATE/SCREW/ORING KIT
<a href="#">M28-C6-CK00B</a>	
<a href="#">R20-08-000</a>	
<a href="#">P31KA00ESC</a>	
<a href="#">L30-C8-D00</a>	
<a href="#">P32LB14LSNN</a>	
<a href="#">47.22x3.53x NBR-90</a>	
<a href="#">R21-02-L00</a>	REGULATOR
<a href="#">CB7-04-000</a>	
<a href="#">R08-C2-F0G0-KIT</a>	
<a href="#">D18-C3-FK00B</a>	
<a href="#">P32KA00RQ</a>	differential pressure indicator for M18-C2-CL00
<a href="#">C08-C2-FKG0B</a>	maintenance unit with pressure gauge
<a href="#">C08-02-FLG0B</a>	
<a href="#">Certificate of origin for R26-C4-H00</a>	
<a href="#">GRP-95-846</a>	
<a href="#">GPA-96-602</a>	
<a href="#">F18-C4-SL00B</a>	REGULATOR FILTER
<a href="#">ER2-03-BAC0</a>	ELECTRONIC REGULATOR
<a href="#">F28-C4-SL00B</a>	
<a href="#">F16-03-000</a>	FILTER
<a href="#">M16-03-X00</a>	Coalescing Filter
<a href="#">M16-03-F00</a>	Coalescing Filter
<a href="#">DRP-14-514/002</a>	
<a href="#">L08-02-KL00B</a>	
<a href="#">F35-CB-F00</a>	filter
<a href="#">K4515N18060</a>	GAUGE
<a href="#">FDR.04 B4</a>	
<a href="#">RP.11</a>	
<a href="#">L40-0B-G00</a>	LUBRICATOR (1-1/2" FNPT)
<a href="#">L30-06-000</a>	LUBRICATOR, 3/4" NPT
<a href="#">P31VB92LBNN</a>	
<a href="#">B18-04-FGG0B</a>	Filter / Regulator
<a href="#">F28-06-SH00B</a>	FILTER BLOCK
<a href="#">N28-06-0000</a>	BLOCK
<a href="#">V73-06-B000B</a>	VALVE
<a href="#">B18-C4-FK00B / 086520155</a>	Filter rules, PC tank + protection, manual drain, self-bleeding
<a href="#">R08-02-F0G0B</a>	REGULATOR WITH GAUGE