




ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Dynisco

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
MDT462F-1/2-1C-15/46-SIL2	pressure sensor
1390/2/3	TEMP CONTROLLER
1480-4-1-0-0	MAGNIFY
PT462E-7CB-6/18	PT462E-7CB-6/18
1490-4-0-0-0-1	Pressure Transducer
2291SA51B14BSMMAACZZB300	Melt Pressure Transducer
SPX2291SA56K09BSTTCCAZZ (229100000074)	Melt Pressure Transducer
SPX2291SA56K11BSTTCCCZZ (229100000147)	
711600	CONNECTOR
ATC990-4-0-1-1-0-1-000	Temperature Controller
ATC990-4-0-1-1-1-1-0-0	Process Controller
DYMT-S-M18-J-5-15-G-2M-A	THERMOCOUPLE
DYMT-S-M18-J-7-15-G-2M-F13	(Item No. 99880177)
DYMT-S-1/2-J-10-15-G-0.7M-F20	Melt Temperature Sensor
ECHO-MV3-BAR-R21-UNF-6PN-S06-F18-NTR	Pressure Transducer
ECHO-MV3-BAR-R23-UNF-6PN-S06-F18-NTR	Pressure transducer
HDA320-3.5C-5V-S50	Pressure Transducer
IDA354-3.5C-S61 (2V)	Pressure Transmitter
MDA460-1/2-1M-15	Melt Pressure Transducer
MDA462-1/2-3.5C-15/46	Melt Pressure Transducer
MDT 462F-1/2-3.5C-15/4- SIL2	Melt Pressure Transmitter
MDT462F-1/2-2C-15/46	Pressure Sensor
MDT462FH-1/2-2C-15/46	Pressure transmitter
MDT462F-1/2-3.5C-15/4...	Melt Pressure Transmitter
MDT462F-M18-3.5C-50/46-A	Melt Pressure Transmitter
MDT462F-M18-7C-15/46-A	Pressure Sensor
462H0002	pressure sensor +label and coupling
NPV876-1/2-50MPA-25/45	Sensor
0160000132H11	PRESSURE TRANSDUCER
PT 415D-5M-6-B314-B173	Probe-Pressure
PT06A-10-6S SR	connector
PT160-4M-H88	Pressure Transducer
2291NA48K13BSMMCACZZ@10Kgf/cm	Melt Pressure Transmitter
PT4624-35MPA-6/18	Pressure transducer
PT462E-10M-6/18	PRESSURE TRANSDUCER
PT462E-15M-6/18	Pressure Transducer

Product	Description
PT462E-3.5CB-6/18	PRESSURE SENSOR
PT462E-M18-7CB-6/18	Pressure Transducer
2291SA48P21BUMMACAAA 229100000292	Melt Pressure Transducer
22291SA56K21BSMMACAZZ	Pressure Transmitters
TDA463-1/2-1M-15/46	PRESSURE SENSOR BAR 1000 BAR 0-1000
TDT463F-1/2-3.5C-15/46-A	Sensor
TDT463H-1/2-5C-15/46	Melt Pressure Transmitter
TPT432A-5M-6/18	SENSOR-PRESURE
TPT463E-5CB-6/18	Pressure Transducer
P/N: 463L0008 Model: TPT463L-1/2-10M-6/18	Melt Pressure Transmitter
UPR900-4-0-1-1-0-0-0	process indicator
PT482-1/2-5M-6/18-B379 (0482300133B379)	Pressure Transducer
ECHO MA4 MPA R23 UNF 6PN S06 F18 NTR	Schmelzedruck - Sensor
Gegenstecker 6-PIN (connector)	Gegenstecker 6-PIN
MDT422F-M10-2C-7.6/152-A	Melt Pressure Transmitter
MDA460-1/2-5C-32	Melt Pressure Transmitter
MDT462F-M18-7C-15/46-SIL2	Pressure Transducer
ECHO-MV3-MPA-R21-UNF-6PN-S06-F18-NTR	Melt Pressure Transmitter
MDA462-1/2-3.5C-15/46 (0462300636)	Melt Pressure Transducer
DM-INT-400	pressure sensor
TPT4636-M14-50MPA-6/18-TC6	Melt Pressure Transmitter
TDA463-1/2-5C-15/46	Dynisco pressure and temperature transducer
MDT422F-1/2-3.5C-15/46-SIL2	Pressure transmitter
MDT422F-1/2-2C-46/46-SIL2	Melt Pressure Transmitter
TDT463F-1/2-7C-15/46-SIL2	Pressure sensor
TDT432F-1/2-3.5C-15/46-D69/285-SIL2	Melt Pressure Transmitter
DYMT-S-1/2-2xPT100/4-15-15-G	Dynisco Melt Temperature Probe
432F0014S	Pressure Sensor
MDT 422F-M18-35-15/46-A	Melt Pressure Transmitter
MDA462-1/2-3.5C-23/46	Melt Pressure Transducer
ECHO-MV3-BAR-R17-UNF-6PN-S06-F18-NTR	Pressure Transducer
MDA462-1/2-7C-15/46	Pressure transducer
SPX 2281NMDAC5M25A	Melt Pressure Transducer
MDT462F-M18-3.5C-15/46-B171	Melt Pressure Transmitter
PT4624-15M-6/18 range 0-15.000psi 4-20mA	Pressure Transducer
SPX2243-N-A25-B-21-CE-FF-C-CE-ZZ	Melt Pressure Transducer
MDA 422-1/2-3.5C-15/46-T80	Pressure sensor
MDT 422F-1/2-3.5C-15/46-B171-B173-SIL2	Pressure sensor
PT4624-15M-12/18-SIL2	Pressure Transducer
2291SA48K20BSMMAACAK	Melt Pressure Transducer
99880669	Melt Temperature Probe
ECHO-MV3-BAR-R22-UNF-6PN-S06-NFL-NTR	sensor
PT-462F-1/2-5M-6/18-A	Pressure Transducer
PT-4624-1/2-5M-6/18-A	Pressure Transducer
TPT463E-1/2-7.5M-6/18	Melt Pressure Transmitter

Product	Description
ECHO-MV3-PSI-R23-UNF-6PN-S06-F18-TCJ	Pressure Transducer
UPR90031100100	Universal Pressure Controller
TPT432A-3M-6/18	Melt Pressure Transducer with Thermocouple
TPT4634-5M-6/18	Melt Pressure Transmitter
UPR900-3-1-0-0-0-0-0-0	Pressure indicator
IDA334-1M-10V-D06	Pressure Transducer
IDA330-2C	Pressure Transducer
8702BCSX1546P	sensor
PT422A-5M-6/18	Pressure Sensor
5705BPSX1052	Pressure Sensor
TPT4634.5M.6/18.GC9	Transducer
PT4624-1/2-5M-6/18-SIL2	pressure sensor
TPT4634-1/2-5M-6/18-SIL2	pressure sensor
PT4626-1/2-35MPA-6/18	Pressure Transducer
ATC990-411111000 (99000004)	Process Controller
VT460H-3	Pressure Transducer
PT303-2C	Pressure Transducer
MDA462-1/2-5C-15/46	Melt Pressure Transducer
DYMT-S-1/2-J-25-23-G	Melt Temperature Sensor
PTB131-7.5M-M14-6/18-10V-K	High temperatre melt pressure transducer
ATC990202011010	Temperature Controller
PT462E-10M-6/18-B220	Pressure Transducer
ECHO-MA4-MPA-R21-M14-6PN-S06-F18-NTR	Pressure Transducer
PT4624-5M-6/18-B628	Pressure Transducer
TPT4634-35MPA-12/18-SIL2	sensor
TPT463E-10M-6/18-B628	Pressure Sensor
PT462E-1M-6/18	Pressure Transducer
TPT4634-5M-6/18-SIL2	Pressure Sensors With SIL2
PT422A-10M-6/18	Pressure Transducer
TPT4634-3M-6/18-SIL2	Melt Pressure Transmitter
TDT432F-1/2-3.5C-46/46-S137-SIL2	Transmitter
TDT432F-1/2-5C-46/46-S137-SIL2	Transmitter
ATC9904001100000	Temperature Controller
UPR90021000000	Universal Pressure Controller
TPT463E-5M-6/18, 0-5000PS	Pressure Sensor
PT460E-5M-9	Pressure Sensor
2291NA48K13BSMMCACZZ@10K	Melt Pressure Transducer
PT160-4M-M11 4000 PSI	Pressure Transducer
PT160-4M-M11 CAP-4000PSI	Pressure Transducer
TDT432F-1/2-5C-32/46-S137	Melt Pressure Transmitter
MDT462H-1/2-5C-15/46 (462H0002)	Pressure transmitters with integrated amplifier
TDT463F-1/2-5C-15/46-SIL2	Melt Pressure Transmitter
PT06A-10-6S(SR) (711600)	Pressure Connector
4622NA00P24CEDDAFZZGC7	Melt Pressure Transducer
MDT422F-1/2-3.5C-15/46	MELT PRESSURE TRANSDUCER

Product	Description
PT160-5M	Pressure Transducer
UPR900-20000000	Universal Pressure Controller
PT460E-5CB-6	Pressure Transducer
E11711122	Pressure Sensor
E11611131	Sensor
2291NA48K13BUMMACAZZ	Melt Pressure Transducer
2291NA48K11BUTTACAZZ	Melt Pressure Transducer
ECHO-MV3-BAR-R22-UNF-6PN-S06-F30-NTR Artikelnr.: E12711131	Pressure Transducer
9VT00030	Pressure Sensor
1480-1-0-0-0 Artikelnr.: 14801000	Pressure Transducer
UPR90030000000	Pressure Sensor
MDA462-1/2-1M-15/46	Melt Pressure Transducer
UPR900-2-1-1-1-0-0-0-0	Process Indicator
TPT463E-5M-6/18	TRANSDUCTOR
MDA462-1/2-5C-15/46-B171	Melt Pressure Transducer
SPX4222-S-A-00-B-13-EZ-DD-C-AA-ZZ-Z017	Smart Pressure Transmitter
DYMT-S-1/2-RTD-15-15-G	Melt Temperature Probe
0463380636 TDA463-1/2-3.5C-20/46	Pressure and Temperature Transducer
TDT463L-1/2-7C-15/46	Melt Pressure and Temperature Transducer
DYMT-F-1/2-PT100/3-0-32-G	Melt Temperature Probe
MDT422F-1/2-3.5C-32/46-SIL2	Melt Pressure Transducer
DYNA4-1M-15	Pressure Rod
MDT420F-1/2-1M-15-SIL2	Melt Pressure Transducer
PT-CAN 20-1/2-152-1MB	Pressure Transducer
MDT462F-1/2-3.5C-15/91-SIL2	Melt Pressure Transducer
DYMT-S-M18-J-18-15-G	Melt Temperature Probe
PT4624-5M-6/18	Melt Pressure Transducer
PT4624-1/2 -5M-6/18	Melt Pressure Transducer
PT4624-35MPA-6/18-SIL2	Pressure transducer
PT303-3C	PRESSURE TRANSMITTER
TDA463-1/2-3.5C-15/46-PT100 , 0463300636PT100	Melt Pressure and Temperature Transducer
1480-2-0-0-0	Universal Input Indicator
DYMT-S-1/2-J-10-15-G(F13), code: DYMT-0110-N	Melt Temperature Probe
ECHO-MV3-BAR-R23-UNF-6PN-S06-NFL-NTR	Melt Pressure Transducer
MAP350-S-1101	Pressure Sensor
MDT462H-1/2-5C-15/46	Melt Pressure Transducer
TPT4634-35MPA-12/18-RTD-SIL2	Melt Pressure and Temperature Transducer
TPT4634-35MPA-6/18-RTD-SIL2	Pressure Transmitter
ECHO-MV3-BAR-R23-M18-6PN-S06-F18-NTR	melt pressure sensor
DYMT-S-1/2-J-10-15-G-4M	Melt Temperature Sensor
ECHO-MV3-PSI-R21-UNF-6PN-S06-F18-NTR	MELT PRESSURE SENSOR
ECHO-MV3-PSIR22-UNF-6PN-S06-F18-NTR	melt pressure sensors
UPR900-41110000	Universal Pressure Indicator
DYMT-S-1/2-2XPT100/3-20-15-G-0.8M	Dual RTD Melt Temperature Sensor

Product	Description
E12511121	Pressure Sensor
MDA462-1/2-3.5C-10/46-T80	Melt Pressure Transducer
PT462E-5M- 6/18	Melt Pressure Transducer
Model: ECHO-MV3-BAR-R21-UNF-6PN-S06-F18-NTR (E12611121)	Pressure Switch
TPT4634-5CB-18/18-RTD2-SIL2	Pressure transmitter
IDA353-3.5C-D44	PRESSURE SENSOR
PT4626-35MPA-6/18	Melt Pressure Transducer
2291NA48K11BSSRCACZZ (229100000432)	Pressure Transducer
2291NA48K11BSSRCACZZ (229100000514)	Pressure Transducer
MDT422F-1/2-3.5C-32/46-SIL2 (422F0129S)	Melt Pressure Transducer
PT303-2.5C	industrial sensor
2291NA48K11BSSRBACZZ (7 bar) 229100000514	Low-Pressure Transducer
MDA462-1/2-5C-15/46-GC6	Melt Pressure Transducer
MDT462F-1/2-2C-32/46-SIL2	Pressure transmitter
P/N: 99880015 Type: DYMT-F-1/2-J-0-15-G (F13)	heat detector
P/N: 9VT00037 Model: VT460-20	Cable with connector
VT460-40	Melt Pressure Gauge
MDT422F-M18-17-15/46-SIL2	Pressure transmitter
MDT422F-1/2-35-15/46-SIL2	Pressure transmitter
MDT462H-1/2-7C-15/46-B106-D85	Sensor
PT462E-M18-5M-6/18	Melt Pressure Transducer
ECHO-MV3-PSI-R23-UNF-6PN-S06-F18-NTR	Pressure Transmitter
4622NA00P24CEDDAAFZZGC5	Melt Pressure Transducer
MDT462F-1/2-5C-15/46-T80-SIL2	Pressure Sensor
PT462E-3M-6/30	Melt Pressure Transducer
ECHO-MV3-PSI-UNF-R20-6Pn-S06- F30-NTR:	Pressure Transmitter
ATC990411111000	Process Controller
SPX2291SA48P21BUMMACAA	Melt Pressure Transducer
2291SA56K21BSMMACAZZ	Melt Pressure Transducer
SPX 4222SA00B15CEDDAAZZ	Melt Pressure Transducer
MDA422-1/2-3.5C-23/46-GC8	Melt Pressure Transducer
PT4624-15M-6/18-GC7	Melt Pressure Transducer
SPX4622NA00P24CEDDAAFZZGC7	Melt Pressure Transducer
PT4626-7.5M-6/18-B628	Melt Pressure Transducer
2242NA00K23CEFFCACAAB300	Melt Pressure Sensor
DYMT-S-1/2-J-5-15-G-4M-A-F13	Melt pressure sensor
Model: E13612121 (ECHO-MV3-MPA-R21-UNF-HIR-S06-F18-NTR)	Pressure Transmitter
1480-2-1-0-0	Digital Pressure Indicator
1490-2-0-0-0-0	Digital Temperature and Pressure Indicator
1490-2-1-1-1-0	Universal indicator
BP420-1/2-9.5M-6	Melt Pressure Transducer
PT4624-3M-6/18-SIL2 (Art. Nr. 04624000130S)	Melt Pressure Transducer
1490-2-1-0-0-1	Digital Temperature and Pressure Indicator

Product	Description
ECHO-MA4-UNF-BAR-R21-6PN-S06-F18-NTR	Pressure Transmitter
UPR700-1-3-3-B97	Universal Pressure Indicator
ECHO-MV3-BAR-R21-UNF-6PN-S06-NFL-NTR	pressure sensor
ECHO-MV3-UNF-PSI-R23-6PN-.S06-F18-TCJ	Pressure Transmitter
2291SA56K13BSMMCCAZZ	Melt Pressure Transducer
4222SA00B21FEFFBAAZZ	pressure transmitter
4222SA00B17FEFFBAAZZ	pressure transmitter
PT4624-10M-9/18-SIL2	
ECHO-MA4-BAR-R17-UNF-6PN-S06-F18-NTR	Pressure Transmitter
UPR900-2-1-0-0-0-0-0-0-0	Universal Pressure Indicator
1490-410000	Pressure Indicator
1490-4-1-0-1-1	Panel Indicator
ATC990300011000	Process Controller
IDA353-5C-10V-D30/400	Transmitter
DYN-X-MA-5M-6/18-SIL2	Melt Pressure Transducer
IDA-354-SC- 5788-1	Melt Pressure Transducer
DYMT-S-M18-J-7-15-G-2M-A-F13	Melt Temperature Sensor
PT422A-1M-6/18	Pressure Transducer
ECHO-MV3-PSI-R22-UNF-6PN-S06-F18-TCJ	Pressure Transmitter
MDT422F-1/2-2C-15/46-SIL2	MDT4X2F Series Pressure Sensors With SIL2
pressure indicator for E12611121	Universal Pressure Indicator
ECHO-MV3-PSI-R21-UNF-S06-F18-NTR	Pressure Transmitter
Model: PT4626-10M-6/18-T80	Melt Pressure Transducer
PT4626-5M-6/18	Melt Pressure Transducer
PT311JA-1M	TRANSDUCER
TDT432F-1/2-3.5C 32/46 -S147A	Melt Pressure and Temperature Transducer
MDA460-M18-7C-15	Melt Pressure Transducer
2280SGKAC5P34AK296 (228000000236)	Pressure sensor
BP420-1/2-7M-6	Melt Pressure Transducer
PT422A-50MPA-9/18-C16	
TI422JA-060-1-P3B	Temperature Sensor
0432000135	Universal Pressure Indicator
TPT412-10M-6/18	Melt Pressure Transmitter
BP420-1/2-8.5M-6	Melt Pressure Transducer
TG422J-203-90-2-210-1	Temperature Sensor
MDT462F-1/2-1M-15/46-SIL2 (462F0166S)	SENSOR
2281SLDCA4K 27A	STRAIN GAUGE TRANSMITTER
MDT422F-1/2-3.5C-15-76-SIL 2	TRANSMITTER
PT4624-5M-6/18 0-5000PSI	Pressure Transmitter
IDA353-7C	Melt Pressure Transducer
14804101	panel indicator
PT482-15M 6/18	
2243NA25B14CEFFBCEZZ	PRESSURE TRANSMITTER
2243NA25B21CEFFCCEZZ	PRESSURE TRANSMITTER
2243NA25B20CEFFBCEZZ	PRESSURE TRANSMITTER

Product	Description
2243NA25B16CEFFCCEZZ	PRESSURE TRANSMITTER
DYMT-S-1/2-J-5-15-G-0.7M-F13	probe
IDA354-5C-10V-S78B-1	Pressure sensor
MDT462F-1/2-3.5C-15/46-T80-GC9	Pressure Transmitter
P/N: 103444,Type: CET1-AX-LDA-00-50X-SC	SECURITY SYSTEMS
VERT-MA4-MM1-NDC-BAR-R21-UNF-6PN-S06-F18-NTR-NCC	PRESSURE TRANSDUCER
PT4624-7.5M-6/18-T80-GC9	Melt Pressure Transducer
TPT 463 E-1.5M 6/18	Pressure Transducer
ECHO-MA4-UNF-BAR-R23-6PN-S06-F18-NTR	Pressure Transmitter
PT4624-5M-6/18-SIL2	pressure sensor
MDA462-1/2-3.5C-15/46 09-15-08342258	Melt Pressure Transducer
MDA462-1/2-1C-15/46	Melt Pressure Transducer
TPT463E-10M-9/18	Melt Pressure Transmitter
14804100; sn: 786051010 002	Universal Pressure Indicator
PG442R-5M-6/30	Melt Pressure Gauge
PT4624-5M-6/18-A	MELT PRESSURE SENSOR
PT415D-7.5M-6-B314	Pressure Sensor
IDA 334-2C	TRANSMITTER
1490-2-1-1.0	Digital Indicator
PT422A-3M-6/30	Melt Pressure Transducer
DYMT-F-1/2-J-15-15-1	TEMP SENSOR
901383 type J	Melt Temperature Sensor
Model: MDT422F-1/2-2C-32/46-B171-SIL2	Pressure transmitter
PT4624-35MPA-12/18-SIL2	Melt Pressure Transducer
4622NA00B21CEDDAAFZZGC7	Melt Pressure Transducer
DYMT-S-1/2-PT100/4-30-15-G	Melt Temperature Sensor
MDA460-1/2-7C-15	transducer
MDT420F-1/2-7C-15-SIL2	Melt Pressure Transducer
PT462E-5M-6/30	Melt Pressure Transmitter
NP4624-1/2-35MPA-15/45-SIL2 PT4624-35MPA-6/18-SIL2)	PRESSURE TRANSMITTER
NP4634-1/2-35MPA-J-SIL2 TPT4634-35MPA-6/18-SIL2)	PRESSURE TRANSMITTER
MDA422-1/2-5C-15/45	pressure Sensor
PT4624-7.5M-9/18-A	Transducer diaphragm
PT4626-10M-12/18	TRANSDUCER
IDA354-3.5C-10V-S78B	pressure sensor
MDT460L-1/2-1M-15	sensor
cable for MDT460L-1/2-1M-15	cable
PT4624-50MPA-6/18-A	pressure sensor
200925	Melt Pressure Sensor
TPT4634-5M-6-30-SIL2	Melt Pressure Transmitter
ECHO-MA4 BAR R21 UNF 6PN SO6 F18 NTR	sensor
4622NA00P24FEDDAAFZZGC8	Melt Pressure Transducer
4622NA00B20CEDDAAFZZGC6	Melt Pressure Transducer
socket for PT4624-20MPA-6/18-SIL2	socket
MDT462F-M18-2C-32/46-GC6	Melt Pressure Transducer

Product	Description
DYMT-S-M18-PT100/4-5-38-G	Melt Temperature Sensor
4622NA00B20FEDDAAFZZGC0	Melt Pressure Transducer
149041000	Digital Indicator
PT4624-5M-6/30-SIL2	Melt Pressure Transducer
MDT422H-1/2-7C-15/46-SIL2	mass pressure sensor
MDT462F-1/2-5C-15/46-SIL2	Pressure transmitter sensor
MDA462-1/2-2C-15/46	Melt Pressure Transducer
BP420-1/2-5.5M-6	Melt Pressure Transducer
ECHO-MV3-BAR-R21-UNF-S06-F18-NTR	Pressure Transmitter
234908	thermocouple for sensor Model TPT
TPT484-5M-6/30-B379	Probe
470000172	Probe
PT4624-10MPa-6/18-SIL2	Probe
DYMT-S-1/2-PT100-4-15-23-G-4	Melt Temperature Sensor
149010000	Digital Process Indicator
MA4-PSI-R23-UNF-6PN-S06-F18-NTR	Pressure Transmitter
PT4624-2CB-6/18-B171-SIL2	TRANSMITTER, MELTING PRESSURE
MDT422F-1/2-2C-15/46-B171-SIL2	BCF EXTRUDER PRESSURE SENSOR
DYKE-1/2-J-0-15G (F13)	Melt Temperature Sensor
PT-462E-5M-12/18	Melt Pressure Transducer
ECHO-MA4-BAR-R23-UNF-6PN-S06-F18-NTR	Pressure Transmitter
301AUSX1546 (IDA332-5C-4-20MA)	Melt Pressure Transducer
NP462-1/2-50MPa-15/45 (MDA462-1/2-5C-15/46)	pressure sensor
PT422A-7.5M-6/30	Melt Pressure Transducer
ECHO-MA4-BAR-R21-UNF-6PN-S06-F18-NTR	Pressure Transmitter
ECHO-MV3-PSI-R22-UNF-6PN-S06-F30-NTR	Pressure Transmitter
E22711121	Pressure Transmitter
462L0010	pressure sensor
MDT462F-M18-7C-15/46-GC9	Pressure Transducer
E32711121	Pressure Transmitter
4672SA00B21EADDAAAZZ	Melt Pressure Transducer
ATC990400110000	Advanced Process Controller
149021000	Digital Indicator
0462000133B70	Melt Pressure Transducer
929008	Connector cable
PT 4624-1/2-70MPa-15/45-B171-S1L2	Melt Pressure Transducer
PT462E-7.5M-6/30-T80	pressure probe
4622NY00P22CEDDAAFZZGC9	Pressure Sensor
ECHO-MV3-PSI-R21-6PN-S06-F18	Pressure Transmitter
MDT462F 1/2 5C 15/46	Melt Pressure Transducer
IDA354-5C-S78B	Shutdown Tonnage Pressure Sensor
MDT422F-1/2-2C-32/46-B171-SIL2	Pressure transmitter
422F-1/2-3.5C-15/46-SIL2	Melt Pressure Transducer
PT462E-50MPa-6/18	Melt Pressure Transducer
MDT462F-1/2-3.5C-15/46-GC8	Housing transducer

Product	Description
TDA463-1/2-3.5C-25/46	sensor
NP422-1/2-70MPA-15/45	PRESSURE TRANSMITTER
BP420-1/2-5M-6	Melt Pressure Transducer
MDA462-1/2-3.5C-32/46	Melt Pressure Transducer
PT462E-10M-6/8	Transducer
PT4624-3.5CB-6/18-SIL2	Melt Pressure Transmitter
4622SA00B21FEDDAAZZ	Melt Pressure Transducer
PT199-2.5C	Melt Pressure Transducer
MDT422F-1/2-3.5C-15/46-GC7	Pressure Transmitter
MDT422F-M10-3.5C-15/76-GC7	Pressure transmitter
DYMT-S-1/2-Pt100/3-10-15-G	Temperature probe
TPT463E-10M-6/18	Melt Pressure Transducer
MDT462F-1/2-3.5C-15/46-B171-SIL2	Pressure transmitter
ATC990-3-1-1-1-1-0-1-1	Pressure controller
PT462E-35MPA-6/18	Melt Pressure Transducer
4222SA00B15FEFFBAAZZ	Melt Pressure Transducer
TPT4634-3M-12 / 18-RTD1-SIL2	TRANSDUCER
TPT4634-35B-6/18-S137-SIL2	PRESSURE TRANSDUCERS
TDT432F.1/2.5C.32/46.S137	MELT PRESSURE TRANSDUCER
ECHO-MV3-PSI-R21-UNF-6PN-S06-F18-NTR	Pressure Transmitter
ECHO-MV3-BAR-R22-UNF-6PN-S06-F18-TCJ	Dynisco pressure and temperature transducer
MDA460-1/2-1M-15 (0460300642)	PRESSURE TRANSDUCER
E13512121	PRESSURE TRANSDUCER
ATC990.2.0.0.0.1.0000	PRESSURE REGULATOR
MDT422H.1/2.7C.15/46 24V	MELT PRESSURE TRANSDUCER
TPT4636H-10M 6/18	MELT PRESSURE TRANSDUCER
MDT460L-1/2-7C-15	Melt Pressure Transducer
BP420-1/2-7.5M-6-1/4NPT	Melt Pressure Transducer
PT4624-3M-6/30-SIL2	PRESSURE MELT TRANSMITTER
4P708013 / It Plug – Blind stop	Gauge Plug
DYMT-F-M18-Pt100/4-0-23-G	
VT460-16	Pressure cable
VT460-10	Pressure cable
TDT463FH-1/2-3.5C-15/46-SIL2	Melt Pressure and Temperature Transducer
LMFI-1NNNNNN	Linear Displacement Sensor
MDT462H-1/2-5C-15/46-SIL2	Melt Pressure Transducer
MDT462H-1/2-3.5C-15/46-SIL2	Melt Pressure Transducer
MDT462H-1/2-1M-15/46	Pressure Sensor
VERT-MV3-MM1-NDC-PSI-R23-UNF-6PN-S06-F18-TCJ-NCC	Pressure Transmitter
MDT460F-1/2-5C-15-M1100-GC3	Melt Pressure Transducer
E12511211 / 09-10-14392175	Pressure Transmitter
ECHO-MV3-BAR-R20-UNF-6PN-S09-NFL-NTR	Pressure Transmitter
IDA354-2C-10V-S143	Pressure transmitter
PT462E-M10-35MPA-15/46	Melt Pressure Transducer
0051-30	Piston Assembly

Product	Description
MDT462F-M18-2C-23/46-GC6	Sensor
PT460E-5M-6	sensor
ECHO-MV3-PSI-R21-6PN-S06-NFL-NTR	sensor
SPX 2242-S-A-00-M-20-CE-DD-B-AC-ZZ-SIL2-J8	Melt Pressure Transducer
ECHO-MV3-BAR-R20-UNF-6PN-S06-F18-NTR	Pressure Transmitter
PT462E.3.5CB-6/18-GC8	Melt Pressure Transducer
MDA422.1/2.3.5C.15/46.GC8	Melt Pressure Transducer
MDT422F-1/2-2C-15/16-B171-SIL2	Melt Pressure Transducer
MDT462F-1/2 2C-15/45-A	Melt Pressure Transducer
4622NA00B2OCEDDAAFZZGC6 / SN12-14-11403626	Melt Pressure Transducer
MDT462F-1/2-3-5c-15/76-T80-GC9	PRESSURE TRANSDUCERS
DYMT-S-1/2-J-10-15-G	Melt Temperature Sensor
TMDT 462F-1/2-3.5C-15/91-A	PRESSURE PROBE
2243 SA 25 M 14 CEFFACAPA	Melt Pressure Transducer
MDA462-G3-5C-15/46	Melt Pressure Transducer
MDA460-G3-5C-15	Melt Pressure Transducer
VERT-MA4-MM1-HT1-BAR-R21-UNF-6PN-S06-F18-NTR-NCC	pressure transmitter
DYMT-S-1/2-2XPT100/3-20-15-G-0.5M	Melt Temperature Probe
14804100 S/N: 1090029 030 013	Digital Pressure Indicator
VERT-MA4-MM1-NDCBAR-R22-UNF-6PN-S06-F18-NTR-NCC	PRESSURE TRANSDUCER
ECHO-VT1-PSI-R23-UNF-6PN-S06-F18-NTR	Pressure Sensor
DYMT-S-M18-J-5-15-G-2M	Melt Temperature Sensor
UPR900-2-0-1-0-0-0-0-0	Universal Pressure Indicator
SPX2281SDDCA4B30B	Melt Pressure Transducer
ECHO-MV3-MPA-R21-6PN-S06-F18-NTR	pressure sensor
TPT-463E-10M-12/18	Pressure Sensors
PT4626-7.5M-6/18	Pressure sensor
MDT462F-1/2-5C-15/46-B171-SIL2	Melt Pressure Transducer
ECHO-PSI-VT1-R23-6PN-S06-F18-NTR	Pressure Transmitter
TPT463E-5M-6/18 RTD1	Melt Pressure and Temperature Transmitter
NP422-1/2-10MPA-23/45	PRESSURE SENSOR
mdt 462F-1/2-3.5C-15/46	Melt Pressure Transducer
PT303-5C	Pressure Transmitter
PT4624-7.5M-6/18-SIL2	Melt Pressure Transducer
TPT4636-10M-6/18-B171	Melt Pressure Transmitter
MDT462F-M18-35Mpa-32/46-SIL2	Melt Pressure Transducer
MDT462F-5C-1/2-15/46-B171-SIL2	pressure transducer
NP460-G3-35MPA-23	pressure sensor
ECHO-MA4 BAR-R22-M18-6PN-S06	Pressure Transmitter
CABLE8	Sensor Extension Cable
CABLE10	Sensor Extension Cable
CABLE15	Sensor Extension Cable
E21911122	Pressure Transmitter
IDA354-3.5C-2V-S78	Melt Pressure Transducer
TPT4636.10M.6/18	Melt Pressure Transmitter

Product	Description
TPT432A-5M-12/18	PRESSUREM SENSOR
MDT422H-1/2-5C-15/46-B171-SIL2	Melt Pressure Transducer
PT4626-10M-6/18-B628	pressure trasnmitter
VT460-3	PRESSURE TRANSMITTER CONNECTOR
PT4624-10M-6/18-SIL2	PRESSURE TRANSDUCERS
ECHO-MA4-PSI-R21-UNF-6PN-S06-F18-NTR	Pressure Transmitter
929009	Connector
148041000	Panel Indicator
V462F31410	Pressure Transducer
TPT463-5M-6/18	Melt Pressure Transmitter
MDT460F-1/2-1M15SIL2	mass pressure transmitter
4622NA00B14CEFFAAFFZZ	Melt Pressure Transducer
MDA460-1/2-3.5c-15	Melt Pressure Transducer
SPX4 622 S A05 B 15 CE DD A AA ZZ	Melt Pressure Transducer
PT462E-20MPA-6/30	Melt Pressure Transducer
BP420 1/2 12 5M 6	Burst Plugs
IDA 354-3.5C-5V	Melt Pressure Transducer
ECHO-MV3-MPA-R20-6PN-S06-F12-NTR	Pressure Transmitter
E22811131	Pressure Transmitter
TDT463F-1/2-3.5C-15/46-SIL2	Pressure Sensor
TDA463-1/2-7C-15/46-B170	Sensor
ECHO-MV3-PSI-UNF-R23-6PN-S06-F18-NTR	Pressure Transmitter
MDT422F-1/-3.5C15/46-516-2	Pressure Transmitter
VT460-5m	Cable
MDA465XL-1/2-1M-B225 / 04650300642B225	Melt Pressure Transducer
2291SA48K20BSMMAACZZ	Melt Pressure Transducer
TPT4634-5C-12/30-SIL2	Pressure Transducer
ECHO-MA4-BAR-R22-UNF-6PN-S06-F12-TC	Pressure Transmitter
04620020130	Melt Pressure Transducer
NP460-G3-50MPA-32 / 0460C11410	Melt Pressure Transducer
PT4624-10M-12/30-SIL2	Pressure Transducers
TDA463-M18-5C-15/46	Melt Pressure and Temperature Transducer
MDT462L-1/2-7C-15/46	Melt Pressure Transducer
BP1010	Melt Pressure Gauge
224200002283	Melt Pressure Transducer
MDT462F-1/2-2C-32/46-B171-SIL2	Melt Pressure Transducer
MDA460.M18.5C.15	PRESSURE MELT TRANSDUCER DYNISCO
MDT 462H-1/2-5C-15/46... 0-500 bar	Melt Pressure Transducer
MDT 462L ½ 3.5C-15/46 0-350 bar	Melt Pressure Transducer
MDA 462-1/2 -2C-15/46 ..0-200	Melt Pressure Transducer
224200002104	PRESSURE TRANSMITER
224200003156	PRESSURE TRANSMITER
224200002845	PRESSURE TRANSMITER
DYMT-S-1/2-RTD-10-15-G	TEMPERATURE PROBE
PT460E-7.5M-6-T80	Melt Pressure Transducer

Product	Description
PT4624-35MPA-18/18-SIL2	Melt Pressure Transducer
MDA482-1/2-2C-15/46	Melt Pressure Transducer
MDT462F-1/2-7C-15/46-B171-SIL2	Melt Pressure Transducer
DYMT-S-M18-J-7-15-G-2M-A	THERMOCOUPLE
BP420-1/2-6.5M-6	Melt Pressure Transducer
BP420-1/2-3M-4	Melt Pressure Transducer
BP420-1/2-3M-6	Melt Pressure Transducer
902344	Bursting screws
MDA462-M18-3.5C-32/46	pressure transducer
DYMT-S-1/2-PT100/3-25-15	TEMPERATURE SENSOR
PT4624-M18-35MPA-6/18-SIL2	Melt Pressure Transducer
PT4626-50MPA-6/36	Pressure Transducer
E12611121	Pressure Transmitter
PT4624-5M-15/18-SIL2	PRESSURE SENSOR
TDA463-1/2-3.5C-25/46-S137/1	PRESSURE TRANSMITTER
4222SA00B21FEDDBAAZZ	Pressure Transmitter
ECHO-MA4-MPA-R24-M22-6PN-S09-F18-TCK-N	Pressure Transmitter
PT462XL-30M-6/18	Melt Pressure Transducer
ECHO-MA4-MPA-R24-M22-6PN-S09-F18-TCK	Pressure Transmitter
ECHO-MA4-BAR-R23-M18-6PN-S06-F18-NTR	Pressure Transmitter
929026	Melt Pressure Transducer
TDA463-1/2-7C-15/46	Melt Pressure and Temperature Transducer
1490-4-1	Digital Process Indicator
ECHO-MV3-BAR -R22-UNF-6PN-S06-Tcj	Pressure Transmitter
ECHO-MA4-BAR-R22-UNF-6PN-S06-F18-NTR	Pressure Transmitter
1480-4-1	Panel Process Indicator
MDT462F-M10-3.5C-7.6/107-SIL2	Melt Pressure Transducer
SJ-600H-U4	Melt Pressure Sensor
ECHO-MA4-BAR-R21-UNF-6PN-S06-F18-TCJ.	Pressure Sensor/Transducer
ECHO-MA4-PSI-R21-UNF-6PN-S06-F18-TCJ	melt pressure sensors
TPT4634-7CB-6/18	Melt Pressure Transmitter
UPR90020111000	Universal Pressure Indicator
PT-160-5M-H88	PRESSURE TRANSDUCER
PT462E-10M-6/18-GC5	Melt Pressure Transducer
462200000351	Melt Pressure Transducer
462200000306	Pressure Sensor
200100	Mounting hole cleaning kit
711660	Connector for Transducers
MDT420L-1/2-7C-15-J8	pressure sensors
710700	Pressure Transducer
PT462E-7.5M-6/30	Melt Pressure Transducer
PT450TA 1M	Melt Pressure Transmitter
PT462F-1/2-3.5C-15/46	Melt Pressure Transmitter
PT4624-10MPA-12/18-SIL2	Melt Pressure Transmitter
PT4626-5M-6/18 0-5.000	PSIG PRESSURE SENSOR

Product	Description
ECHO-MV3-PSI-R22-UNF-6PN-S06-F30-T C	Melt Pressure Sensor
TPT463E-7.5M-6/18	Melt Pressure and Temperature Transducer
MDA422-1/2-1C-23/46	Melt Pressure Transducer
PT124B-10M-M14-6/18-10V	Pressure transmitter
ECHO-VT1-MPA-R22-UNF-6PN-S06-F18-TCJ	Melt Pressure Sensor
PT462E-10M-6/18-GC7	pressure transducer
PT462E-5M-6/18-GC7	pressure transducer
ECHO-MV3-MPA-R23-UNF-6PN-S06-F18-NTR	Melt Pressure Sensor
SPX2242SA00B21CEFFBACPK	Melt Pressure Transmitter
TPT4634-3.5CB-6/18-SIL2	PRESSURE TRANSDUCER
ECHO-VT1-BAR-R21-UNF-6PN-S06-F18-NTR	PRESSURE TRANSDUCER WITH
MDT462F-1/2-7C-15/46-B171-A	Melt Pressure Transmitter
MDT462F-M18-3.5C-8/46-B171-SIL2	Pressure Sensor
MDT462N-1/2-2C-15/46-SIL2	Pressure Sensor
ECHO-VT1-BAR-R22-UNF-6PN-S06-F18-TCJ	PRESSURE PROBE
pt3034c	Heavy Duty Pressure Transmitter
VERT-MV3-MM1-NDC-BAR-R22-UNF-6PN-S06-NFL-NTR-NCC	Melt Pressure Sensor
462200000322	Melt Pressure Transducer
ECHO-MA4-BAR-R23-UNF-6PN-S06-F18-TCJ	Massedrucksensor
462F0152S	sensor
PT415-5M-6-B314	
MDT422F-M10-3.5C-15/46-SIL2	Pressure transmitter
E21711122	pressure transducer
ECHO-MA4-BAR-R22-UNF-6PN-S06-F18-TCJ	
32581	DIGITAL PRESSURE INDICATOR
BP240-1/2-9.5M-6	
MDT-422F-1/2-2C-32/46-B-171A	Sensor
NP463-1 2-3.5CK-1545-J	PRESSURE AND TEMPERATURE SENSOR
BP420-1/2-3.5M-1.81	RUPTURE DISC
DYMT-S-1/2-PT100/3-2.5-15-G	
BP420123M12PROV	
99880109	
CB-05-(PT06A-10-6S(SR))	6 pin connector
TPT4634-1MB-6/18-SIL2	PRESSURE TRANSDUCER (DOUBLE THERMOCOUPLE)
UPR900-3-0-1-0-0-0-1-0	PROCESS INDICATOR
MDT462F-1/2-3.5C-7.6/46-SIL2	
LMFI55-1NNNNNN	Base model melt flow indexer
MDA460/420-1/2-5C-T80	
2242NA00P20AWAABAHZZM1121	SENSOR
PT422A-7.5M-6/18	pressure sensor
MDT462FH-1/2-3.5C-15/46-SIL2	
PT4624- 5 M-6/18-SIL2	
VT420	Cable
ECHO-MA4-BAR-R21-M14-6PN-S06-F18-NTR	

Product	Description
PT160-4M-H11	