



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Proxitron

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">2021D</a>	G Inductive proximity switch
<a href="#">2052N-5 IKN 070.05 G</a>	inductive proximity switch
<a href="#">2052Q-5</a>	Inductive Proximity Switch
<a href="#">Nr. 2065U Type IKQ 100T.38 GS4 (Teach)</a>	Inductive proximity switch
<a href="#">2331H</a>	Induktiver Analog-Sensor
<a href="#">2377C-5 IKL 015.05 GH</a>	Inductive proximity switch
<a href="#">2446H IKU 021T.28 GS4</a>	Inductive sensor strip
<a href="#">2451F, Type: IKU 031T.28 GS4 (Teach)</a>	Inductive sensor strip
<a href="#">8032B</a>	
<a href="#">8032B / FKM 230.13 GS4</a>	Air flow monitor
<a href="#">8381BT</a>	
<a href="#">9842J (ST 043/3-10PURH)</a>	
<a href="#">8041A FKM 230.18 GS4</a>	airflow monitor
<a href="#">IKM 070.33 G</a>	inductive proximity switch
<a href="#">IKN 070.05 G 2 m Kabel</a>	Induktiver Näherungsschalter
<a href="#">IKUD 031.28 G S4</a>	Inductive Sensor Bar
<a href="#">LLK4</a>	Fiber optic cable
<a href="#">MKK 050.194 S4 SA1</a>	Analogue inductive sensor
<a href="#">OAA 703</a>	Optics for fiber optic cables
<a href="#">OKS 7 T10.14 S9</a>	Piro S Infrared Sensor
<a href="#">OSA 6747.13 G S5 / 6134Q</a>	Piros infrared sensor
<a href="#">R5T285L383-003(1/4)-00-8HN34</a>	
<a href="#">2474A (IDL 015.05 G.)</a>	Inductive speed monitor
<a href="#">9848A</a>	Inductive Sensor
<a href="#">2193B (IKU 341T.38 GS4)</a>	Inductive area sensor
<a href="#">9841D (ST 041/4-2)</a>	Connection cable
<a href="#">2451A (IKU 031.28 GS4)</a>	Inductive sensor bar
<a href="#">2190G Type IKU 131T.38 G</a>	inductive surface sensor
<a href="#">2092G Type IKU 251T.38 G</a>	Inductive surface sensor
<a href="#">2049Q</a>	Induktiver Näherungsschalter
<a href="#">2409E</a>	Induktiver Näherungsschalter
<a href="#">2490A IKU 015T.28 GS4</a>	Inductive sensor strip
<a href="#">8032B Type: FKM 230.13 G S4</a>	airflow monitor
<a href="#">IKZ 475.33 GS4</a>	Inductive proximity switch
<a href="#">IKZ 475.33 G S4 F / 2409F</a>	Induktiver Näherungsschalter
<a href="#">ZSU A01.82</a>	Drehzahlwächter

Product	Description
<a href="#">IKN 070.05 G 5 m Kabel</a>	Induktiver Näherungsschalter
<a href="#">2229H-5</a>	Induktiver Näherungsschalter
<a href="#">2319E</a>	Induktiver Näherungsschalter
<a href="#">2319Q-5</a>	Induktiver Näherungsschalter
<a href="#">2159M MKZ 120.59</a>	Inductive Analogue Sensor
<a href="#">IKN 070T.38 GN S4 2050C</a>	Inductive proximity switch
<a href="#">FKE 604.18 GS4 8382BT</a>	
<a href="#">GS4 2451A</a>	Inductive sensor strip
<a href="#">2409F</a>	Inductive proximity switch
<a href="#">2409E Type: IKZ 475.33 G S4</a>	Inductive proximity switch
<a href="#">IKZ 807.23 GH 2491B</a>	
<a href="#">6410A</a>	Piros Infrared Sensor
<a href="#">9816B HM 2</a>	
<a href="#">9816B</a>	articulated mounting foot
<a href="#">2451A</a>	Inductive sensor strip
<a href="#">2491B</a>	
<a href="#">IKK 050.38 GS4</a>	inductive proximity switch
<a href="#">FKM 231.13 G S4 / 8043B</a>	Air flow monitor
<a href="#">IKK 060.38 GS4</a>	Inductive proximity switch
<a href="#">2452A</a>	Inductive sensor bar
<a href="#">IKL 025.33 GHS4</a>	Induktiver Näherungsschalter
<a href="#">ST041/4-5H</a>	PP-Kabel
<a href="#">MKZ 120.59 (2159M)</a>	
<a href="#">KKH 020.04 G</a>	
<a href="#">ST 043/3-10PURH (9842J)</a>	S4 Clutch
<a href="#">FKM 130.13 G (8008A-5)</a>	
<a href="#">IKL 015.33 GH (2319D-10)</a>	Inductive proximity switch
<a href="#">IKL015.33GH (23119D-15)</a>	Inductive proximity switch
<a href="#">Art.Nr.: 2331F , Type: MKK 050.190 S4</a>	Analog Inductive sensor
<a href="#">IPOH150.38 GS4</a>	
<a href="#">FKM 230.13 G</a>	
<a href="#">p/n 2052N Type IKN 070.05 G</a>	Inductive proximity switch
<a href="#">2319D-5</a>	
<a href="#">Type: IKN 070T.38 GS4 ( Art. Nr.2049T )</a>	Inductive Proximity Switch
<a href="#">Type: LLK 2 ( Art. Nr. 6436F)</a>	Fibre Optic Cable
<a href="#">IKM 070T.38 GS4</a>	inductive proximity switch
<a href="#">ST 041/4-2</a>	actuator
<a href="#">2319D</a>	Inductive proximity switch
<a href="#">IKU 031.28 GS4 (2451A)</a>	Inductive sensor bar
<a href="#">MKK 050.194 S4</a>	Analog Inductive sensor
<a href="#">FKF 604.18 GS4</a>	Flow sensor
<a href="#">2331G</a>	
<a href="#">IKZ 807.23 GH5 (Art. 2491D)</a>	Induktiver Näherungsschalter
<a href="#">2065S Type IKQR 100T.38 MG</a>	Induktiver Näherungsschalter
<a href="#">6302B</a>	

Product	Description
<a href="#">9850R</a>	
<a href="#">9828R</a>	
<a href="#">9861F</a>	
<a href="#">LAB 201.5 L</a>	
<a href="#">2002G-20 Type IKH 020.05 GH</a>	Inductive proximity switch
<a href="#">FKEN 604.18 GS4</a>	
<a href="#">2065W Type IKQA 100T.38 MG</a>	Inductive proximity switch
<a href="#">5116A Type LTZ 185.28 GS4</a>	light sensor
<a href="#">2319D-20</a>	Inductive proximity switch
<a href="#">IKOH 101.05 GS5 (2060L)</a>	Inductive proximity switch
<a href="#">6048A</a>	Optics for optical cable LLK
<a href="#">6436F</a>	fiber optic cable
<a href="#">FKM 230.12 GS4</a>	airflow monitor
<a href="#">IKQ 100T.38 GS4</a>	inductive proximity sensor
<a href="#">LSB 201.53 GLK</a>	Piros disposable light barrier
<a href="#">2450D</a>	Inductive proximity switch
<a href="#">2413B-15</a>	Inductive proximity switch
<a href="#">IKZ 307.28 GH</a>	Inductive proximity switch
<a href="#">2452G Type IKU 051T.28 GS4 L</a>	Inductive Sensor Strip
<a href="#">IKL 015.33GH (2319D-15)</a>	Inductive proximity switch
<a href="#">IKZ 301 28GH</a>	Inductive proximity switch
<a href="#">IKZ 182.23 GH</a>	Inductive proximity switch
<a href="#">OKA 704.05 G</a>	Infrared-Sensor
<a href="#">IKU245.33G ( Teil -Nr. 2091C )</a>	Inductive surface sensor
<a href="#">IKU 031.28 G54</a>	SENSOR STRIP
<a href="#">IKU 325T.38 GS4</a>	Inductive area sensor
<a href="#">IKU 225.33G</a>	Inductive area sensor
<a href="#">IKU231.33G</a>	Inductive area sensor
<a href="#">2052Q</a>	Inductive proximity switch
<a href="#">FKE 604.18 G Art. 8382AT</a>	Flow-Sensor F6, G 1/2"
<a href="#">IKU 8101T.38 G S4</a>	Inductive surface sensor
<a href="#">IKU 885T.38 G S4</a>	Inductive surface sensor
<a href="#">9812A</a>	Clamp
<a href="#">2374X-5, Type: IKZ 302.28 CG</a>	Proximity Switch.
<a href="#">9841D, Type: ST 041/4-2</a>	Angle coupling with 2 m cable
<a href="#">IKV 015.23 GS4</a>	sensor
<a href="#">IKV 025.23 GS4</a>	sensor
<a href="#">ST 041/3-2</a>	Coupling with 2 m cable
<a href="#">FKF604.18GS4 /ecz</a>	
<a href="#">2369A ZSU A01.82</a>	Speed monitor
<a href="#">OKB 2047.18 G</a>	Piros infrared sensor
<a href="#">IKLT 015.38 GH</a>	SENSOR with 5 meter cable TEFLON
<a href="#">6920E</a>	Piros S Infrared-Sensor / Pyrometer
<a href="#">9847B</a>	female connector
<a href="#">6913E</a>	Mounting unit adjustable

Product	Description
<a href="#">6913I</a>	Interface cable and Software for OKS pyrometer
<a href="#">6450A</a>	Piros Infrared-Sensor
<a href="#">6050A</a>	Optic
<a href="#">9850J</a>	female connector
<a href="#">9816D</a>	Piros-Mounting Bracket
<a href="#">6913G</a>	Laser pilot light attachment
<a href="#">9828H</a>	Adapter M40 for mounting of accessory
<a href="#">9828A</a>	Tubus
<a href="#">2369B ZSU A01.52</a>	Speed monitor
<a href="#">2490C IKU 015T.28 GS4 L</a>	Inductive sensor bar
<a href="#">IKOH 100T.38 GS4</a>	Inductive proximity switch
<a href="#">IKL 015.33 GN</a>	Inductive proximity switch
<a href="#">FKM 230.19</a>	
<a href="#">ST 041/5-10 (9850H)</a>	
<a href="#">6302C OXA 2029.3A GK S4</a>	Piros infrared sensor
<a href="#">9850C ST 043/5-2</a>	
<a href="#">9861F SIC 485U S6</a>	Interface Converters
<a href="#">IKZ 475.38 GDV</a>	inductive proximity switch
<a href="#">LAB 600.3 S4</a>	
<a href="#">LSB 600.38 GV S4</a>	
<a href="#">IKU 881T.38 G S4</a>	Inductive surface sensor
<a href="#">6417A</a>	sensor
<a href="#">IKU 051.28 GS4</a>	
<a href="#">9816G</a>	mounting bracket
<a href="#">9816I</a>	mounting brackets
<a href="#">2046D-3</a>	Inductive proximity switch
<a href="#">2046D-5</a>	Inductive proximity switch
<a href="#">6036G / OAC 204 M</a>	recording optics with LLK connection
<a href="#">2323A</a>	Inductive proximity switch
<a href="#">2474D (IDL 010.05 G)</a>	Inductive speed monitor
<a href="#">9614B</a>	Extended connection cable
<a href="#">IKOA 120.38 GS4 / 2314C</a>	Inductive proximity switch
<a href="#">6436I</a>	fiber optic cable
<a href="#">9844B</a>	S5 coupling
<a href="#">IKOA 120.38 GS4F / 2314F</a>	Inductive proximity switch
<a href="#">2600B MXL 025.194 S4</a>	Inductive analog sensor
<a href="#">2601B MXZ 475.194 S4</a>	Inductive analog sensor
<a href="#">IKL 015.38 G S4</a>	Inductive proximity switch
<a href="#">2374G-10</a>	Inductive proximity switch
<a href="#">IKN 070.05G/2052N</a>	Inductive proximity switch
<a href="#">8382AT Type: FKE 604.18 G</a>	Flow-Sensor F6,
<a href="#">p/n: 6202E Type: OKA 0529.38 G S4</a>	Piros infrared sensor
<a href="#">P/N: 2002P-5 Type: IKH 020.05 GH</a>	inductive proximity switch
<a href="#">IKK060.38G</a>	inductive sensor
<a href="#">IKQ 015.38G</a>	INDUCTIVE SENSOR

Product	Description
<a href="#">IKQ 021.05 G</a>	
<a href="#">OKB 2047.63 LK</a>	
<a href="#">Nr.2377C-5 Type IKL 015.05 GH</a>	inductive proximity switch
<a href="#">Nr. 2065Z-5C Type IKQ 100T.38 G</a>	Inductive proximity switch
<a href="#">MKZ 471.194 S4 / 2330F</a>	Inductive analog sensor
<a href="#">MKH 035.19 S4</a>	inductive analog sensor
<a href="#">2323P-5 (IKLT 020.05 GH1)</a>	Inductive proximity switch
<a href="#">2354E IKQ 100.38 G S4</a>	Inductive proximity switch
<a href="#">ST S5-DC/4-5 / 9844B</a>	coupling
<a href="#">IKL 015.33 GHS4 / 2319G</a>	inductive proximity switch
<a href="#">IKU 031T.28 GS4 L</a>	Inductive sensor bar
<a href="#">5041A</a>	Thru-beam sensor transmitter
<a href="#">5040C</a>	Thru-beam sensor receiver
<a href="#">6049A</a>	Optics for light guide cables LLK
<a href="#">FKF 704.86 G</a>	Flow-Sensor F7, G 3/4"
<a href="#">2510A</a>	inductive proximity switch
<a href="#">OXS 402T.2A G S8</a>	INFRARED PYROMETER
<a href="#">ST S8-2</a>	S8 (M12) coupling
<a href="#">SIC 485U 9861B</a>	interface converter
<a href="#">ST S8 S4/5-2</a>	connection cable
<a href="#">IKN 070T.38 GS4</a>	Inductive proximity switch
<a href="#">Nr. 2377M Type IKL 015.04 GH1</a>	inductive proximity switch
<a href="#">ST S9/5-2</a>	coupling
<a href="#">IDL 015.28 G</a>	Inductive speed monitor
<a href="#">MXK 050.194 H1 S4</a>	inductive analog sensor
<a href="#">8032A</a>	airflow monitor
<a href="#">IKOH 100.05 GS5</a>	Inductive proximity sensor
<a href="#">MXK 060.194 S4</a>	Inductive analog sensor
<a href="#">2510A IPN 105.38 G S4</a>	inductive proximity sensor
<a href="#">ART-NR: 6410A-10 / TYPE OKA 204.05</a>	Piros-Infrarot-Sensor
<a href="#">IKK 060.17 G</a>	Inductive proximity sensor
<a href="#">IKK 060T.38 G</a>	inductive proximity switch
<a href="#">2421F</a>	
<a href="#">#OKB 2029.38 G S4 ART# 6204E</a>	
<a href="#">TYPE #ST043/4-5H ART# 9842P</a>	Coupling with PP cable
<a href="#">TYPE# HM 2 ART# 9816B</a>	joint mounting foot
<a href="#">IKU 215T.38 G S4</a>	Inductive area sensor
<a href="#">5200G</a>	
<a href="#">9851K</a>	
<a href="#">9855B</a>	
<a href="#">9861E</a>	
<a href="#">9828S</a>	
<a href="#">ST 043/4-2</a>	
<a href="#">9828R OL 35</a>	
<a href="#">OKA 2029.38 G S4 (6204D)</a>	Piros infrared sensor

Product	Description
<a href="#">OKB 2069.18 GLK</a>	hot metal detector
<a href="#">LLAB 600.3 S4</a>	
<a href="#">IKU 011T.28 G S4, P/N: 2405J</a>	
<a href="#">IKU 021.28 G S4 , P/N: 2446C</a>	
<a href="#">2465A /IKZ 122.23 GH3</a>	inductive proximity switch
<a href="#">6204E</a>	PHOTOCELL model Piros infrared sensor
<a href="#">IKK 060T.38 G S4</a>	inductive proximity switch
<a href="#">2012V</a>	
<a href="#">IKL 010.05G</a>	inductive proximity switch
<a href="#">2481B / IKON 125.05 G S5</a>	Inductive proximity switch
<a href="#">MKZ 471.19 S4 2330A</a>	inductive analog sensor
<a href="#">2333D</a>	
<a href="#">IKZ 301.23 GH4 / 2469B-10</a>	inductive proximity switch
<a href="#">OKA 204.05 GS5</a>	
<a href="#">LSA 201.53 GK</a>	Piros one-way light barrier
<a href="#">OSA 6747.18 G</a>	Infrared-Sensor
<a href="#">IKU 341.38 G S4</a>	Inductive area sensor
<a href="#">OKA 203 33 G (6109A)</a>	
<a href="#">2474A-10</a>	inductive sensor
<a href="#">9828U</a>	
<a href="#">2004D-5</a>	
<a href="#">5038C</a>	one-way photoelectric receiver,
<a href="#">5037E</a>	one-way light barrier transmitter
<a href="#">LXUA 600.3A GV S8</a>	Universal light barrier
<a href="#">9850N</a>	
<a href="#">9853B</a>	power supply
<a href="#">9851E</a>	
<a href="#">2405G IKU 011.28 G S4</a>	
<a href="#">IKL 015.33 GH (20m cable)</a>	inductive proximity switch
<a href="#">IKOH 100.38 GS4</a>	inductive proximity switch
<a href="#">IKUS 010.23 G S49</a>	Inductive sensor strip
<a href="#">LMB 101</a>	
<a href="#">ST S12-10S</a>	
<a href="#">SIC 485UD</a>	
<a href="#">KSS HJI 08</a>	
<a href="#">KSV M20H</a>	
<a href="#">KS KR 16/13</a>	
<a href="#">6920E / OKS 4 GA13.14 S9</a>	
<a href="#">9847B ST S9/5-2</a>	coupling
<a href="#">6913B DAK 302</a>	cooling jacket
<a href="#">6913E DAK 305</a>	mounting angle adjustable
<a href="#">9999D</a>	Test certificate for pyrometers
<a href="#">2503A IPK 080.38 G S4</a>	
<a href="#">Art:2046F-5 -IKK 060T.38 G</a>	
<a href="#">2029S</a>	inductive proximity switch



Product	Description
<a href="#">6436L</a>	fiber optic cable
<a href="#">IKL 010.33 GH 2434H-10</a>	SENSOR, PROXIMITY
<a href="#">6410A-10 OKA 204.05 G</a>	Infrared Sensor