



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Ağaoğlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Selet

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">B01CF22NO</a>	
<a href="#">B01EG82PC</a>	Inductive Sensors
<a href="#">B01F3.5NC</a>	Inductive Sensors
<a href="#">B50G184V010</a>	Inductive Sensors
<a href="#">OCV88/D1PNSCR</a>	photocell
<a href="#">OCV88/D2PNSCM</a>	photocell
<a href="#">OCV88/D2PNSCRM</a>	M18 Photoelectric Cylindrical Multifunction Sensor 400mm Pnp/npn Sc
<a href="#">SI0 63 MZ 720 SP 2 MA 8</a>	Encoder
<a href="#">SI1 40/MS/50/OCF/2/C5R-6</a>	Encoder
<a href="#">SIC 40/BS/20/EAP/9/MP3A-6S</a>	encoder
<a href="#">OCV81/CC3NOR</a>	photocell
<a href="#">B50E189V010C5</a>	Inductive sensor
<a href="#">COON185-D1S448</a>	Selet Sensor
<a href="#">COON185-DIS448</a>	Sensors
<a href="#">K14EG50PO</a>	Selet kapazitiv
<a href="#">B06E124POC5</a>	proximity switch
<a href="#">B01G122PO</a>	Prox switch
<a href="#">B01G122PC</a>	Prox switch
<a href="#">SI-1-40-BS-200-OCF-2-C5R-6</a>	Sensor Encoder
<a href="#">1040952</a>	
<a href="#">B01EG188PO</a>	Sensor
<a href="#">K01E30POC5</a>	Selet kapazitiv
<a href="#">K01EG30PO</a>	
<a href="#">B01F5PO / Sensor Selet induktiv</a>	
<a href="#">K0118POC5</a>	Sensor
<a href="#">B01AN10POV6</a>	PROXIMITY IND. ANELLO
<a href="#">SI-0-63-BZ-1000-EA-2-CR-8</a>	Drehgeber
<a href="#">B50EG189V010</a>	inductive proximity switch
<a href="#">B01EG124PO</a>	Inductive sensor
<a href="#">B00EG124-DIS376</a>	Sensor
<a href="#">K01G30PSC</a>	Sensor Selet kapazitiv
<a href="#">B01G122PSC</a>	Sensor Selet induktiv
<a href="#">OCV81/600-DIS8</a>	Sensor
<a href="#">B01QEO4020PSC</a>	B01QEO4020PSC
<a href="#">B01QEO4020PSC ( price for 10 pcs.)</a>	

Product	Description
<a href="#">OCV91/D1PSCMR</a>	Sensor
<a href="#">B01G122NO</a>	Sensor Selet induktiv
<a href="#">B01G122NC</a>	Sensor Selet induktiv
<a href="#">OCV91/D1PSCRM</a>	SENSOR
<a href="#">OCV88/D2PNSCR</a>	Sensor Selet Photoelectric
<a href="#">OCV88/D1PNSCRM</a>	Sensor Selet Photoelectric
<a href="#">B02185POC5</a>	Sensor
<a href="#">SI158-ABZ -1000-OCF-2-CR-6</a>	Sensor
<a href="#">SA2 63/GR/4096/EAP/9/HR/10</a>	
<a href="#">B50EG188A420</a>	Inductive analogue sensor
<a href="#">OCV88/D2PNSCRM-K6</a>	
<a href="#">B01F5PO</a>	Fork Sensor 5mm Gap
<a href="#">SI-0-63-BZ1000EA9-CR10</a>	
<a href="#">OCV88/CPNSCRM</a>	Sensor
<a href="#">CARTER SCT15Leiterplatte</a>	
<a href="#">B50 EN187 V03</a>	Prox switch
<a href="#">B01AN63PO</a>	Inductive Switch
<a href="#">B01AN10P0V6</a>	
<a href="#">S12-40-BS-2000-EA-6-CR-6.E225</a>	
<a href="#">B01AN30POV6</a>	ring sensor
<a href="#">MB526PLAV6</a>	Inductive sensor
<a href="#">SIC 40/MS/20/EA/9/MP3A-6</a>	encoder
<a href="#">MB526-DIS351</a>	INDUCTIVE SENSOR
<a href="#">B06122POC5</a>	Sensor Selet inductive
<a href="#">B50122V010C5</a>	ANALOGUE INDUCTIVE SENSOR
<a href="#">V60500-KFL</a>	Sensor Connector
<a href="#">V70500-KFL</a>	Sensor Connector
<a href="#">V80500-KFL</a>	Sensor Connector
<a href="#">V90500KFL</a>	Sensor Connector
<a href="#">L90500KFL</a>	Sensor Connector
<a href="#">K1320POC5</a>	capacitive sensor
<a href="#">K1320PCC5</a>	capacitive sensor
<a href="#">OCV81/D2PNOR</a>	Sensor Photoelectric
<a href="#">B0281POC5</a>	Inductive sensor
<a href="#">SI-1-40-BS-100-OCF-2-C5R-6</a>	Sensor Encoder
<a href="#">B01G81.5PO</a>	Selet inductive sensor
<a href="#">B0281POV6</a>	Inductive Sensor
<a href="#">A01AN22</a>	PROXIMITY IND. NAMUR RING
<a href="#">A01EG188</a>	Prox switch
<a href="#">A01F3.5</a>	Inductive Sensors
<a href="#">B01122PCC5</a>	Inductive Sensors
<a href="#">B01122POC5</a>	Inductive Sensors
<a href="#">B01122PSCC5</a>	Inductive Sensors
<a href="#">B01185POC5</a>	Inductive Sensors
<a href="#">B01AN10NO</a>	

Product	Description
<a href="#">B01AN15NO</a>	Inductive Sensors
<a href="#">B01AN22PO</a>	Inductive Sensors
<a href="#">B01AN22POC5</a>	Inductive Sensor
<a href="#">B01AN22POV6</a>	Inductive Sensors
<a href="#">B01AN22PSCV8</a>	Inductive Sensors
<a href="#">B01AN30NO</a>	Inductive Sensors
<a href="#">B01AN3NOV6</a>	Inductive Sensors
<a href="#">B01AN44NO</a>	Inductive Sensors
<a href="#">B01AN44PO</a>	Inductive Sensors
<a href="#">B01AN5NO</a>	
<a href="#">B01AN63POC5</a>	Inductive Sensors
<a href="#">B01E124POC5</a>	Inductive Sensors
<a href="#">B01E124PSCC5</a>	Inductive Sensors
<a href="#">B01E82POC5</a>	Inductive Sensors
<a href="#">B01EG124NO</a>	Inductive Sensors
<a href="#">B01EG124PSC</a>	
<a href="#">B01EG3015PC</a>	Inductive Sensors
<a href="#">B01G185NO</a>	prox switch
<a href="#">B01G185PO</a>	inductive proximity switch
<a href="#">B01G81.5PC</a>	Inductive Sensors
<a href="#">B01Q81.5POT14V6</a>	Prox switch
<a href="#">B026.51POV6</a>	
<a href="#">B02G122PC</a>	Inductive Sensors
<a href="#">B02G122PSC</a>	Inductive Sensors
<a href="#">B02G81.5PO</a>	Inductive Sensor
<a href="#">B03188PCC5</a>	Inductive Sensors
<a href="#">B03188PSCC5</a>	Inductive Sensors
<a href="#">B0383PCV6</a>	Inductive Sensors
<a href="#">p/n: 261247, Type: UC400-F77-IU-IO-V31</a>	Inductive Sensors
<a href="#">B03E3035NOC5</a>	Inductive Sensors
<a href="#">B03E84POC5</a>	Inductive Sensors
<a href="#">B03EG84PO</a>	Inductive Sensors
<a href="#">B03G188N0</a>	
<a href="#">B03G188PO</a>	Inductive proximity switch
<a href="#">B03G83PO</a>	Inductive Sensors
<a href="#">B04124PCC5</a>	
<a href="#">B0482NCV6</a>	
<a href="#">B04E84POC5</a>	Inductive Sensors
<a href="#">B04E86POV6</a>	Inductive Sensors
<a href="#">B04G6.53PO</a>	Inductive Sensors
<a href="#">B50E124V010C5</a>	Prox switch
<a href="#">B50E187V03C5</a>	Inductive Sensors
<a href="#">B50E188A420C5</a>	Prox switch
<a href="#">B50E3015V010C5</a>	Inductive Sensors
<a href="#">B50EG124V010</a>	Prox switch

Product	Description
<a href="#">B50EG3015V010</a>	Inductive Sensors
<a href="#">B50G3010V010</a>	Inductive Sensors
<a href="#">B60G185NC</a>	Inductive Sensors
<a href="#">B87EG124NO</a>	Inductive Sensors
<a href="#">B87G122PO</a>	Proximity sensor
<a href="#">BCR1G3010PO</a>	Inductive Sensors
<a href="#">C01EG188AO</a>	Inductive Sensors
<a href="#">C01N185AO</a>	Inductive Sensors
<a href="#">MB526NFC</a>	Inductive Sensors
<a href="#">MB526PFAV6</a>	Sensor
<a href="#">K0132POC5</a>	capacitive sensor
<a href="#">K01E30PSCC5</a>	CAPACITIVE PROXIMITY SENSORS
<a href="#">K01EG50PO</a>	CAPACITIVE PROXIMITY SENSORS
<a href="#">K01G18PO</a>	CAPACITIVE PROXIMITY SENSORS
<a href="#">K01G50AO</a>	capacitive sensor
<a href="#">K14E22POC5</a>	capacitive sensor
<a href="#">K14EG30AC</a>	Capacitive proximity sensors
<a href="#">K14G30PSC</a>	Ensor Selet capacitive
<a href="#">K15E32POC5</a>	Capacitive sensor
<a href="#">OCV18/D0PNORMC5</a>	PHOTOCELL
<a href="#">OCV50/CCASC</a>	photocell
<a href="#">OCV50/CCASCC01</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV80/BPNOC5</a>	photocell
<a href="#">OCV80/D1NNO</a>	photocell
<a href="#">OCV81/BPNOMC5</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81/D1C3NOR</a>	photocell.
<a href="#">OCV81/D1NSCR</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81/D2AC3NORM</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81/D2AC3NORM C5</a>	Sensor Photoelectric
<a href="#">OCV81/D2PNCC5</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81/D2PNOC5</a>	photocell
<a href="#">OCV81/D2PNORMC5</a>	photoelectric sensor
<a href="#">OCV81/D2PSCRM5</a>	Photocell
<a href="#">OCV81/D3PNORM</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81/DAPSC</a>	M18 CYLINDRICAL PHOTOELECTRIC SENSOR - DIFFUSE TYPE
<a href="#">OCV81/PRMC5</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV81P/CPNORMC5</a>	PHOTOELECTRIC SENSORS
<a href="#">OCV84/DNSC</a>	photocell
<a href="#">OCV88/D2PNSCRMC5</a>	PHOTOELECTRIC SENSORS
<a href="#">OLT84/BPNO</a>	PHOTOELECTRIC SENSORS
<a href="#">FOV03PNNCRV8</a>	label detector
<a href="#">FOV20PNSCV8</a>	photocell
<a href="#">FOV30PNSCV8</a>	photocell
<a href="#">N613313A</a>	

Product	Description
<a href="#">N618313</a>	connector
<a href="#">SIG6-6/6</a>	
<a href="#">C011-01/24VDC</a>	COUNTER
<a href="#">CGY60/110</a>	DIGITAL INSTRUMENTS
<a href="#">1BS/W/220</a>	Supply units & interface for sensors
<a href="#">K13G20PO SP122</a>	
<a href="#">K14EG32PC CAP21-32PFCPKL</a>	capacitive sensor
<a href="#">K13G20PO</a>	sensor
<a href="#">SS124IMC21Q0E06-0500</a>	ENCODER
<a href="#">B0483POV6</a>	Inductive Sensors
<a href="#">B60122PCC5</a>	Selet Sensor
<a href="#">MB526PFA</a>	
<a href="#">B01185POC3</a>	switch
<a href="#">N619307</a>	
<a href="#">B01G81P0-L50</a>	prox. switch
<a href="#">SI0 63/BZ/360/EA/2/MR-8</a>	Encoder
<a href="#">SS122IDE62SE225-2000 SI2 40/BS/2000/EA/6/CR-6.E225</a>	encoder
<a href="#">B01EG124N0</a>	
<a href="#">B0281P0V6</a>	
<a href="#">K13G22NO-K5</a>	
<a href="#">Cod. SA2 63/GR/4096/EAP/9/HR-10</a>	ENCODER
<a href="#">OCV81/CNN0C5</a>	photocell
<a href="#">Cod. OCV50/D5PNSC</a>	photocell
<a href="#">SIE-40-ABS-200-EA-2-CR-6-E71</a>	Encoder
<a href="#">B01N3010P0</a>	
<a href="#">SS120IDE22QE300-0200 SI0 40/BS/200/EA/2/CR-6.E300</a>	ENCODER
<a href="#">K01G18P0</a>	PROXIMITY CAP M18 BRASS T.S
<a href="#">SI0-63-BZ-1000-EA-2-MA-8</a>	encoder
<a href="#">SS332IDF14E0E23-1000 SI2-58-BS-1000-CL-1-M0-8.E23</a>	ENCODER
<a href="#">SIC 40/BS/20/EAP/9/MP3A-6</a>	Encoder Incremental
<a href="#">SS430IDL62E0E58-0500</a>	ENCODER
<a href="#">SI-0-58-MZ-360-SP-2-CR-8</a>	Encoder
<a href="#">SC120IAE22P0000-0090 SIC 40/MS/90/EA/2/CR-6</a>	encoder
<a href="#">mb526pfa-k5</a>	
<a href="#">SS120IEE62R0000-1000 SI0 40/BZ/1000/EA/6/CR-6</a>	ENCODER
<a href="#">B00122-DIS487</a>	
<a href="#">SS430IBB24E0000-0720 SI0 63/MZ/720/SP/2/MA-8</a>	ENCODER
<a href="#">Art. B01EG124N0</a>	INDUCTIVE SENSOR
<a href="#">MB526PLA-K5</a>	
<a href="#">MB526PLA</a>	
<a href="#">B16G81.5PO</a>	Prox switch